



## J2 TECHNICAL ARTICLE

Number 199

June 20, 1984

From Octagon Heaven

### BONNET HOLD DOWNS ON UNDER BONNET SIDE VALANCES

If you have purchased new under bonnet side valances and do not have the holes in the pieces for the bonnet hold downs, I would suggest the following process to be used to locate the plates:

- a) Mount bonnet in position.
- b) Mount under bonnet side valances in position.
- c) Place hold down on bonnet on the pin and allow to hang in vehicle position.
- d) extend spring to place plate in position. mark and drill.

The position of the rear hold down mounting plate is along the edge of the inset, just ahead of the screws that hold the under bonnet side valance to the brackets. (see sketch below)

The position of the front hold down is on the flat part of the under bonnet side valance, along the front of the first web. It should be out far enough from the vertical surface to allow the bonnet to set behind it but not to far out to pull the bonnet out from the bottom. (see sketch below)

Mounting hardware should be chrome plated machine screws with washers and nuts on back and under.

