

A method to seal the splines

Fill this space with paint-thinner two or three times, and let the thinner run down along the splines. When all is clean and totally oil-free, let some diluted Silicon-Gasket-Cement run down the splines, and repeat that several times until no more soaks down.

