

J2 TECHNICAL ARTICLE

Number 237

April 1, 1985

From Octagon Heaven

END PLAY ON CAMSHAFT

Question: Where do you measure end play on the camshaft and why do you blue the gears?


- A. First the "Blueing of the gears is to check for mesh and alignment.

 After application of "Blueing and rotation of the gears, you
 can check on how the gears mesh (where they touch and rub) and
 see if alignment is correct.
 - B. As to checking end play of the camshaft I would suggest a dialindicator with the ball against the center of the camshaft at the
 bevel gear (see below)

 By rotation of the engine you can watch for movement of the dial.

 If you are on center, there will be no face run-out picked up and
 the only movement of the dial will be to end play.

If you use a dial-indicator with a magnet base-mount, it will fasten firmly onto the front of the engine.



Showing position of Dynamo Coupling and Camshaft Gears for T.D.C. (M, D, J, P, F, L, K, KN and N Models),

