

## J2 TECHNICAL ARTICLE

Number 68  
From Octagon Heaven  
December 24, 1981

### LUBRICATION - POINTS, FREQUENCY, AND TYPE

On the back side of this page is a copy of a Lubrication Wall Chart for the P Type, PB Type, J1 & J2 Types.

The chart shows the lub points, the recommended lub frequency and the type lubrication that is recommended.

Even though there is a symbol explanation at the bottom of the chart, it is important to study that prior to reading the chart itself.

The note in the upper left corner of the chart explains the numbers on the chart.

Note also that there are lubrication points where they recommend the use of heavy oil instead of grease as most people would want to use.

I discovered that previous owners of my car had used grease in the central lubrication system and in order for me to convert back to the use of the gear oil, the old grease must be cleaned out.

In going through the chart, I can not find anything that goes against any special "Information Sheet" published by the M.G. Car Company.

# THE WAKEFIELD LUBRICATION WALL CHART

FOR THE

## M.G. MIDGET

**NOTE.**—Figures in the symbols indicate periods at which attention is required in 10's of miles—i.e. 20 denotes 2,000 miles, 5—500, etc.

"F.T." "P.M." II. & III Types

**WARNING.**—Do not ask for "NL" or "AXL" when you require PATENT CASTROL. Ask for PATENT CASTROL "NL" or PATENT CASTROL "AXL".

**Front Spring Anchorage, Steering King Pin, Steering Drag Link and Steering Connecting Link.**—Every 500 miles apply CASTROL Swanshot Gear Oil with the oilgun at points indicated.

**Brake Camshaft.**—Every 2,000 miles apply Wakefield CASTROLEASE Heavy to the Stauffer greaser and give an occasional turn to the cap. On first miles use grease gun at points indicated.

**Wheel Bearing.**—Every 10,000 miles remove the hub cap and repack hub with CASTROLEASE Heavy.

**Brake Cable Conduits, Front and Rear Spring Shackles and Brake Cross Shaft.**—Every 500 miles lubricate these points by applying oilgun to nipples grouped on the plate indicated. Use CASTROL Swanshot Gear Oil.

**Clutch Release Bearing.**—Every 2,000 miles apply a little CASTROL UNIQUINT Grease (a special non-separating grease) to the clutch race.

**Gearbox.**—Every 2,000 miles check oil level and replenish to level of filter plug with CASTROL Swanshot Gear Oil. After first 1,000 miles, and subsequently every 5,000 miles strain gearshift and refill with fresh oil to level of filter plug. It is important that oil be maintained to this level.

The rate of oil will be required for complete replenishment after draining. On 1934 miles "J" type 1/2 pins only will be required. Use 1933, 1 part.

**Universal Joint Sealing Shaft.**—Every 500 miles apply CASTROL Swanshot Gear Oil with the oil gun at the nipple indicated. Prior to Chassis No. PA 1235, the propeller shaft must be lubricated at both ends with CASTROL UNIQUINT Grease.

**Wheel Hub.**—Every 2,000 miles remove the wheel and apply the grease gun filled with CASTROLEASE Heavy to nipple inside the axle hub.


**Rear Brake Camshaft.**—Every 2,000 miles add Stauffer grease with CASTROLEASE Heavy and give an occasional turn to the cap. On first miles use grease gun at points indicated.

### Also Requiring Attention.

Every 1,000 miles go round your M.G. car applying a few drops of Wakefield OILIT to the carburetor and ignition control rod joints, door blinges, bonnet fasteners and other minor points which are subject to friction.

**Dynamotor.**—Every 1,000 miles apply a few drops of Wakefield OILIT at the points provided but do not over-lubricate.

**Distributor.**—Every 1,000 miles put a few drops of OILIT in the distributor shaft oiler (on 1933 model fill and screw down the greasecup). Every 3,000 miles give the cam the lightest smear of vaseline. Every 3,000 miles place a single drop of OILIT on the contact Breaker Pivot.



### EXPLANATION OF SYMBOLS.

