



Price 1/6

List of Spare Parts
for
The 8/33 M.G. Midget Sports
Series D
(Long Chassis)

The M.G. Car Company Ltd.
Abingdon-on-Thames
Berks

Phone : 251 Abingdon (3 lines). Wire : "Emgee, Abingdon."

ALL PREVIOUS LISTS CANCELLED.

It is absolutely essential, when ordering parts, that the CHASSIS NUMBER is quoted.

The Company only fits the highest grade and best-known proprietary fitments, but it gives no guarantee whatsoever in respect of tyres, lamps, magnetoës, electrical equipment, speedometers, clocks, or any other proprietary fittings of any type supplied with its car or otherwise inasmuch as such proprietary fittings are usually covered by a guarantee issued by their respective manufacturers.

All questions involving the replacement or repair of any such proprietary fittings should, therefore, be taken up direct with the manufacturers concerned, and not with The M.G. Car Company Ltd.

All proprietary fitments are subject to special discounts.

May, 1932.

List of Spare Parts for the M.G. Midget.

CHASSIS FRAME ASSEMBLY AND DETAILS.

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P233	Chassis Frame Assembly comprising 2 Side Members, 5 Cross Tube Assemblies, 2 Front and 2 Rear Dumb Irons, 2 Front Sliding Trunnion Brackets and 2 Rear Spring Suspension Pins. Chassis Nos. Do251 to D3350	1		9	17	6
P301	Chassis Frame Assembly comprising 2 Side Members, 5 Cross Tube Assemblies, 2 Front and 2 Rear Dumb Irons, 2 Front Sliding Trunnion Brackets and 2 Rear Spring Suspension Pins. Comm. Ch. No. Do351	1	1	9	17	6
1184	Side Member O.S. Ch. Do251—Do350	1		1	6	11
1185	" " N.S. Ch. Do251—Do350	1		1	6	11
1029	" " O.S. comm. Ch. Do351	1	1	1	6	11
1030	" " N.S. comm. Ch. Do351	1	1	1	6	11
623	Front Dumb Iron O.S.	1	1	5	10	
624	" " " N.S.	1	1	5	10	
625	Taper Washer	2	2			4
626	Front Sliding Trunnion Brkt. O.S.	1	1	10	1	
627	" " " " N.S.	1	1	10	1	
632	Cover for Front Sliding Trun. Brkt.	2	2	1	7	
633	Front Sliding Trunnion Roller	2	2	3	8	
P232/1	" Cross Tube Assembly	1	1	7	6	
634	" Cross Tube	1	1	3	2	
635	" " " Bushes	2	2	1	1	
P232/2	Engine Bearer Cross Tube Assembly	1	1	1	5	7
636	Front Engine Mounting	1	1	2	11	
637	" " " Cap	1	1	2	0	
638	" " " Bolt	2	2			11
639	Steering Box Bracket	1	1	3	6	
640	Bracket for Cross Tube	2	2	2	6	
641	Engine Bearer Cross Tube	1	1	4	0	
P233/3	Third Cross Tube Assembly	1	1	14	4	
923	" Cross Tube	1	1	4	4	
640	Bracket for Cross Tube	2	2	2	6	
827	Brake Cross Sh. Steady Brkt. (Fixed)	1	1	2	9	
921	Combined Cross Tube End Bracket and Brake Cross Shaft Support	2	2	4	10	
P232/4	Rear Spring Front Cross Tube Ass.	1	1	1	3	0
643	Cross Tube	1	1	5	0	
640	Bracket for Cross Tube	4	4	2	6	
806	Rear Spring Front Suspension Pin	2	2	5	4	

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P233/5	Rear Cross Tube Assembly	1	1	2	3	0
832	Rear Dumb Iron	2	2		3	8
647	Rear Cross Tube	1	1		5	9
819	Rear Sliding Trunnion Roller	2	2		3	8
820	Washer for Rear Sliding Trunnion	2	2			6
872	Cap for Rear Cross Tube	2	2		4	9
873	Distance Piece for Rear Cross Tube	2	2			11
795	Rear Engine Bearer Bracket	2		2	9	
	Ch. Do251—Do350					
1005	Bearer Bracket O.S.	1	1	2	6	
	comm. Ch. Do351					
1040	Bearer Bracket N.S.	1	1	2	6	
	comm. Ch. Do351					
828	Bush for Engine Mounting	2	2			4
804	Rubber Buffer and Plate	2	2		1	7
805	Backing Plate for ditto	2	2			4
815	Rear Striking Pad	2	2			3
817	Setscrew for ditto	2	2	doz.	2	0
874	Combined Greaser and Setscrew	2	2			10
893	Brake Pedal Brkt. ceased Ch. Do350	1			9	3
1367	" " " comm. Ch. Do351	1	1		9	3
1002	Body Bracket	4	4			8
979	" " Support (Short)	4	2		2	7
	(2 only used after Ch. Do350)					
1001	' U ' Clip for Body Bracket (Short)	4	2			4
	(2 only used after Ch. Do350)					
1211	Body Bracket Support (Long)	2	2		3	0
	comm. Ch. Do351					
1212	' U ' Clip for Body Bracket (Long)	2	2			6
	comm. Ch. Do351					
1039	Battery Carrier	1	1		5	4
1229	Shock Absorber Tie Bar	1	1		2	2
S1/5	Tecalemit Greaser	2				3
	ceased Ch. Do350 for Part No. 874					
1587	Front Body Bracket	2	2			10

FRONT AXLE ASSEMBLY AND SPRINGS.

P234	Front Axle Ass. less Springs and Whls.	1	1			
P234/100	Front Axle Beam	1	1	2	6	6
P101/105	Steering Knuckle O.S.	1	1	1	2	6
P101/106	" " N.S.	1	1	1	2	6
P101/101	" " Bolt	2	2		6	6
P101/113	" " " Slt'd. Nut O.S.	1	1		1	0
P101/114	" " " " " N.S.	1	1		1	0
P101/115	" " Washer	2	2	doz.		9
P101/109	" " Distance Washer	2	2		1	0
P101/107	" " Bush Top	2	2		2	8
P101/149	" " " Bottom	2	2		2	6
PX101/6	" " Disc for Top Bush	2	2	doz.	1	0
P101/102	" " Bolt Cotter	2	2			5
P101/104	" " " Thrustwasher	2	2		1	3
P234/104	Front Hub O.S. Rudge Whit.	1	1		14	6
P234/105	" " N.S. " "	1	1		14	6

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P234/103	Front Hub Stud	12	12			9
PX234/1	" " Nuts	12	12	doz.		10
P101/116	" " Bearing (Large)	2	2		10	6
P101/117	" " " (Small)	2	2		10	9
P101/110	" " " Distance Piece	2	2		1	0
P101/118	" " Felt Washer	2	2			3
P234/1	Brake Drum Assembly	2	2	1	5	5
P101/152	" Anchor Bracket with Bearings	2	2		5	6
P101/125	" Shoe	4	4			
P101/126	" " Link	8	8		7	6
P101/127	" " Plate	4	4			
P234/108	" " Lining	4	4		3	0
P101/134	" " " Rivets	32	32	doz.		5
P101/129	" " Spring	4	4			4
574	Vibration Damper Weight	4	4		2	0
575	" " " Spring	8	8			3
576	" " " Clevis Pin	8	8			3
P101/120	Brake Cam	2	2		8	6
P101/124	" " Lever	2	2		4	4
P101/123	" " Fulcrum Pin	2	2		2	6
P101/133	" " " " Nut	2	2			3
P101/132	" " Bush	4	4		2	4
P101/121	" " Washer (Inner)	2	2	doz.		9
P101/122	" " " (Outer)	2	2	doz.		9
P101/3	Track Rod Assembly	1	1		18	6
P101/135	" " Tube	1	1		6	0
P234/101	" " Lever N.S.	1	1		9	4
P234/102	" " " O.S.	1	1		9	4
P101/136	Locknut R.H.T. for Track Rod and Draglink	2	2			4
P101/137	" " L.H.T. for ditto	2	2			4
P101/145	Plug for Ball Joint for ditto	4	4		1	3
P101/140	Adj. End R.H.T. for Trk. Rod only	1	1		5	6
P101/141	" " L.H.T. for Track Rod and Draglink	2	2		5	6
P102/102	" " R.H.T. for Draglink only	1	1		5	6
P101/138	Steering Ball for Track Rod and Draglink	4	4		2	0
P101/139	" " Nut for ditto	4	4			4
P101/142	" " Cup for ditto	4	4			10
P101/143	End Cup for Ball Joint on Track Rod	2	2		1	0
P102/105	" " " " " Draglink	1	1		1	0
P101/143	" " " " " " (Small)	1	1		1	0
P101/144	Spring for Ball Joint on Track Rod and Draglink	4	4			3
P102/106	End Plug for Ball Joint	1	1			3
P235	Draglink Assembly	1	1		17	2
P235/100	" Tube	1	1		5	0
P236	Front Spring comp. with S.A. Brkt. and Bottom Plate O.S. and N.S.	2	2	1	5	0
P236/100	Front Spring Top Leaf	2	2		4	2
P236/101	" " 2nd Leaf	2	2		4	7
P236/102	" " 3rd or Main Leaf	2	2		7	0
P236/103	" " 4th Leaf	2	2		3	9
P236/104	" " 5th Leaf	2	2		3	8

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P236/105	Front Spring 6th Leaf	2	2		3	6
P236/106	" " 7th Leaf	2	2		3	2
1045	" Shock Absorber Bracket O.S.	1	1		4	2
1046	" " " " N.S.	1	1		4	2
1190	" Spring Bottom Plate	2	2		1	6
101	Bolts for Front Spring Plate	8	8			8
801	Front Spring Suspension Pin	2	2		2	5
802	" " " " Tab Wshr.	2	2			4
803	" " Rubber Dust Excluder	2	2		1	0
882	Brake Cable Stop Bracket	2	2			4
1629	Stauffer Grease Cup for Brake Cam					
	Lever comm. Ch. D0451	2	2			9

REAR AXLE ASSEMBLY, PROPELLOR SHAFT AND SPRINGS.

P238	Rear Axle Ass. less Springs & Wheels	1	1		23	0	6
P238/107	" " Casing	1	1		2	0	6
P238/110	" " Rear Cover	1	1				
P238/108	" " " " Oil Filler	1	1			7	9
P238/109	" " " " " " Adaptor Ring	1	1				
P105/117	" " Oil Filler Plug	1	1			1	2
PX105/9	" " " " " Washer	1	1	doz.		1	0
PX105/11	" " Taper Drain Plug	1	1				4
P105/133	" " Front Cover	1	1		1	13	4
P105/103	" " Front & Rear Cover Gasket	2	2				4
PX105/1	" " Front Cover Screws Short	6	6	doz.		1	3
PX105/2	" " " " " Long	2	2	doz.		1	3
PX105/7	" " Rear Cover Screw	8	8				3
PX105/10	" " Spring Packing Washer						
	for Cover Screw	8	8	doz.			11
P105/157	" " Dowel	8	8				3
P105/111	" " Shaft	2	2			19	6
P105/102	" " Spring Pad	2	2			11	4
P105/141	Differential Case N.S.	1	1		1	0	4
P105/142	" " " " O.S.	1	1			18	4
P105/124	" " " " Bolt	6	6				10
P105/116	" " " " Castle Nut	6	6				3
P105/106	" " Bearing	2	2			14	3
P105/107	" " " " Lockwasher	2	2				3
P105/143	" " " " Nuts	2	2			1	9
P105/134	" " " " Cap	2	2			6	2
P105/125	" " " " Stud	4	4				3
P101/139	" " " " Castle Nut	4	4				3
P105/120	" " Wheel	2	2			13	6
P105/121	" " Pinion	2	2			7	4
P105/122	" " " " Pin	1	1			1	0
P105/123	" " " " Dowel	1	1	doz.			9
P238/101	Crown Wheel	1	1				
P238/102	Bevel Pinion	1	1		2	7	10
P105/131	Bevel Pinion Bearing	1	1			13	3
PX105/6	" " Roller Bearing	1	1			18	6
P105/137	" " Washer	1	1				5
P105/174	" " Bearing Distance Washer	1	1			1	0
P105/103	" " Shims .003"		as requ'd.				3

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P105/104	Bevel Pinion Shims .005"		as requ'd.			3
P105/105	" " " .007"		as requ'd.			3
P105/129	" " Housing	1	1	16		4
PX105/5	" " " Spring Ring	1	1			7
P105/126	" " " Stud	4	4			3
P105/135	" " " Cap	1	1	7		9
P105/127	" " " " Screw	2	2			3
P234/1	Brake Drum Assembly	2	2	1	5	5
P101/152	" Anchor Bracket with Bearings	2	2		5	6
P101/125	" Shoe	4	4	}	7	6
P101/126	" " Link	8	8			
P101/127	" " Plate	4	4			
P234/108	" " Lining	4	4			
P101/129	" " Spring	4	4			4
P101/134	" " Lining Rivets	3 ²	3 ²	doz.		5
574	Vibration Damper Weight	4	4		2	0
575	" " " Spring	8	8			3
576	" " " Clevis Pin	8	8			3
P101/120	Brake Cam	2	2		8	6
P101/124	" " Lever	2	2		4	4
PX105/14	" " " Bolt	2	2			3
P101/123	" " Fulcrum Pin	2	2		2	6
P101/133	" " " " Slotted Nut	2	2			3
PX101/4	" " Key (No. 3 Woodruff)	2	2			3
P101/132	" " Bush	4	4		2	4
P101/121	" " Washer (Inner)	2	2	doz.		9
P101/122	" " " (Outer)	2	2	doz.		9
P238/104	Rear Hub N.S. Rudge Whitworth	1	1		14	6
P238/103	" " O.S. " "	1	1		14	6
P238/105	" " Studs	12	12			9
P105/112	" " Ball Bearing	2	2		16	0
P105/158	" " " " Nut O.S.	1	1		1	10
P105/159	" " " " " N.S.	1	1		1	10
P238/2	" " Brg. Housg. Assy. w. Studs	2	2		11	6
P238/106	" " Bearing Housing	2	2		9	10
P105/162	" " " " Gasket	2	2			3
P105/113	" " " Lockwasher	2	2			3
P105/114	" " Oil Retaining Felt	2	2		1	2
P105/115	" " " " Washer	2	2			3
A236	Propellor Shaft (Hardy Spicer)	1	1	2	3	4
	Ch. Do251—Do350					
A244	" " (Hardy Spicer)	1	1	2	3	4
	comm. Ch. Do351					
P238/100	" " Flange (Axle End)	1	1		9	4
811	" " " Bolts	12	12			4
PX105/13	" " " Washer	1	1			3
PX105/12	" " " Slotted Nut	1	1			3
809	Washer for Rear Sprg. Suspension Pin	2	2			6
810	Radius Washer for ditto	2	2			6
812	Rear Spring 'U' Clip	4	4			11
1364	Rear Axle Spring Pad & Steady Brkt.	2	2		7	0
814	" " Strap	2	2		1	5
816	" " Rubber Block	2	2		1	0
P237	" Springs comp. with S.A. Brkt. and Top Plate O.S. and N.S.	2	2		1	10 0

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P237/100	Rear Springs Top Leaf	2	2	4	6	
P237/101	" " 2nd Leaf	2	2	5	0	
P237/102	" " 3rd or Main Leaf	2	2	7	6	
P237/103	" " 4th Leaf	2	2	4	3	
P237/104	" " 5th Leaf	2	2	4	3	
P237/105	" " 6th Leaf	2	2	3	11	
P237/106	" " 7th Leaf	2	2	3	8	
P237/107	" " 8th Leaf	2	2	3	4	
P237/108	" " 9th Leaf	2	2	3	2	
936	" Sh. Absorb. Brkt. O.S. & N.S.	2	2	4	2	
1054	" Spring Top Plate	2	2	2	4	
818	Rubber Dust Excluder for Rear Spring	2	2	1	2	
882	Brake Cable Stop Bracket	2	2			4
1629	Stauffer Grease Cup for Brake Cam					
	Lever comm. Ch. D0451	2	2			9

POWER UNIT.

P239	Power Unit complete with Gearbox and Gear Control Assembly	1	1	75	0	0
------	---	---	---	----	---	---

CRANKCASE AND CYLINDER HEAD.

P110/100	Cylinder Block (Studded) with Joints	1	1	4	2	9
P110/103	" Jacket Cover Plate	2	2	1	1	
P110/104	" " " " Gasket	1	1	2	8	
PX110/4	" " " " Setscrew	28	28			3
P110/1	" Head Assembly	1	1	14	1	8
P110/457	" " Bare	1	1	3	4	0
P110/312	" " Gasket	1	1			3 0
PX110/8	" Stud 4 $\frac{5}{8}$ " Long	3	3	1	6	
PX239/1	" " " 4 $\frac{1}{2}$ " Long	2	2			11
PX110/16	" " " (Holdg. Dn.) 4 $\frac{3}{8}$ "	3	3			11
PX110/17	" " " (Locating)	1	1	1	2	
PX287/3	" " " "	1	1	1	2	
PX105/3	" " " Nut	10	10	doz.	1	3
PX110/18	" " " Washer (Steel)	2	2	doz.		4
P239/118	" " Cover	1	1	1	14	4
P110/313	" " " Gasket	1	1			2 0
P110/295	" " " Screw	2	2			3 0
P110/297	" " " Strap (Front)	1	1	}	2	8
P110/298	" " " " Nut	1	1			
P110/299	" " " " Clip	1	1			
P110/442	" " " Strap (Rear)	1	1	}	2	8
P110/298	" " " " Nut	1	1			
P110/299	" " " " Clip	1	1			
PX239/4	Copper Packing Washer	2	2	doz.		6
P110/182	Stud Hole Liner for Rear of Cyl. Head	1	2			7
P110/490	Patent Number Plate	1	2			4
1462	Instruction Plate	1	1			3 4
P110/226	Water Outlet Pipe	1	1			8 6
P110/306	" " " Gasket	1	1			10
P110/291	" Inlet Pipe	1	1			2 6
PX110/38	Core Disc	4	4			4

BELL HOUSING.

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P239/101	Bell Housing Bushed	1	1	2	11	8
P110/109	" " Plug	1	1		1	6
PX110/9	" " Bolt	5	5			4
PX105/3	" " " Nut	5	5	doz.	1	3
PX110/11	" " Setscrew	2	2			3
P110/314	" " Gasket	1	1			4
P110/443	" " Banjo Union	1	1		1	0
P110/479	" " " Lockplate	1	1			4
PX110/12	" " " Cpr. Wshr.	1	1	doz.	1	8
PX110/2	Setscrew, Bell Housing to Cyl. Block		6			3

FLYWHEEL.

P239/108	Flywheel	1	1	1	17	9
P110/141	" Bolt	4	4			0
PX105/3	" " Nut	4	4	doz.	1	3
PX110/30	" Setscrew	6	6			3
PX110/27	Lockwire for Ball Brg. in Flywh. Boss	1	1			3

CAMSHAFT.

P239/110	Camshaft	1	1	1	3	9
PX110/41	" Nut	1	1			3
PX101/4	" Key	1	1			3
P110/170	" Bevel Wheel	1	1		18	10
Not supplied separately. See P110/193.						
P110/198	Camshaft Bevel Wheel Nut	1	1			7
P110/199	" " Washer	1	1	doz.		8
P110/171	Bevel Thrustwasher	2	2			11
P110/172	Belleville Washer	2	2			4
P110/212	Camshaft Front Bearing	1	1		18	2
PX110/46	" " " Stud (Short)	2	2			3
PX110/6	" " " " (Long)	2	2			3
PX101/1	" " " Nut	4	4	doz.	1	3
P110/214	" " " Cap	1	1		4	4
P110/223	" " " Bush (Top)	2	2		1	0
P110/224	" " " " (Fr. Btm.)	1	1		1	0
P110/225	" " " " (Rr. Btm.)	1	1		1	0
P110/215	" Rear Bearing	1	1		11	6
PX110/46	" " " Stud (Short)	1	1			3
PX110/6	" " " " (Medium)	2	2			3
PX110/35	" " " " (Long)	1	1			3
PX101/1	" " " Nut	4	4	doz.	1	3
P110/217	" " " Cap	1	1		2	6
PX110/47	" " " Lock. Scr.	2	2			3
P110/221	" " " Bush (Btm.)	1	1		1	9
P110/222	" " " " (Top)	1	1		1	3
PX110/49	" Bearing Dowel	4	4	doz.		8
PX110/48	Copper Washer	2	2	doz.		3

VERTICAL DRIVE.

P110/193	Camshaft Driving Bevel Pinion	1	1	17		7
Not supplied separately. See P110/170.						
PX110/43	Camshaft Driving Bevel Pinion Key	1	1			3

Part No.	Description	No. Used		Price Each	
		Open	Closed	£	s. d.
P110/194	Bevel Pinion Bearing Sleeve	1	1		9 0
PX110/44	Hyatt Roller Bearing	2	2		5 10
P110/196	Bevel Pinion Oil Thrower	1	1		7
P110/210	" " Thrustwasher (Thick)	1	1		7
P110/211	" " " (Thin)	1	1		7
P110/202	" " Washer	1	1		1 0
P110/201	Bearing Retainer Plate	1	1		3 4
PX110/98	" " Felt Washer	1	1		3
P110/4	Dynamo Coupling Disc Assembly	1	1		5 6
P110/197	Universal Joint Fork for Bevel Pinion	1	1		4 9
P110/282	Dynamo Coupling Washer .010"		as requ'd.	doz.	1 4
P110/283	" " " .020"		as requ'd.	doz.	1 4
P110/284	" " " .030"		as requ'd.	doz.	1 4
P110/285	" " " .040"		as requ'd.	doz.	1 4
P110/286	" " " .050"		as requ'd.	doz.	1 4
P110/277	" " Bolt	4	4		6
PX101/1	" " Nut	4	4	doz.	1 3
P110/281	Locking Screw for Bottom Bev. Pinion	1	1		3
P110/276	Tab Washer for " " "	1	1	doz.	1 9
P110/257	Shim for Dynamo .003"		as requ'd.		4
P110/258	" " " .005"		as requ'd.		4
P110/259	" " " .007"		as requ'd.		5
P110/260	" " " .015"		as requ'd.		7
P110/198	Dynamo Spindle Nut	1	1		7
P110/199	" " " Washer	1	1	doz.	8
P110/255	" " Oil Guard (Outer)	1	1		5 6
P110/256	Universal Joint Fork for Dynamo	1	1		

ROCKERS AND VALVES.

P110/174	Valve Rocker	8	8		7 0
P110/175	Eccentric Bush for Valve Rocker	8	8		4 9
P110/176	" " Locknut	8	8		4
P110/177	" " Lockwasher	8	8	doz.	1 0
P110/178	Distance Piece $1\frac{1}{8}$ " Long	1	1		5
P110/179	" " $\frac{3}{4}$ " Long	2	2		4
P110/445	" " 1" Long	1	1		5
P110/180	" Spring $2\frac{5}{8}$ "	1	1		4
P110/446	" " $\frac{3}{4}$ "	2	2		3
P110/447	" " $1\frac{3}{4}$ "	1	1		3
P110/189	Rocker Shaft (Long)	1	1		4 9
P110/190	" " (Short)	1	1		4 9
P110/181	" " Steady Bracket	1	1		4
PX110/37	" " " Washer	1	1	doz.	8
PX110/42	Brazing Peg	2	2		9
PX110/42	Brazing Peg	2	2	doz.	9
P110/192	Rocker Shaft Collar	1	1		19
P110/183	Inlet and Exhaust Valve	8	8		3 8
P110/184	Split Collars for Valve	16 Hlvs.	16 Hlvs.		1 0
P110/444	Valve Spring	8	8		1 0
P110/185	" " Cup	8	8		6
P110/186	" " Cover	8	8		4
P110/188	" Guide	8	8		2 3

Part No.	Description	No. Used Open	No. Used Closed	Price Each £ s. d.
CRANKSHAFT AND FRONT BEARING HOUSING.				
P110/29	Crankshaft	1	1	2 11 0
PX110/23	" Key (Woodruff)	2	2	3
PX110/24	" "	1	1	6
P239/107	Auto. Patent Double Row Ball Bearing	1	1	2 0 0
P110/107	Crankshaft Front Brg. Retainer Plate	1	1	1 3
PX110/26	" " " " Setscr.	4	4	3
P110/134	" " " " Lockplate	2	2	2 3
P110/110	" Rear Bearing	1	1	10 6
PX110/13	" " " Grub Screw	1	1	2
P110/142	" Flange	1	1	1 0 4
P110/135	" " Nut	1	1	2 8
P110/136	" " " Lockwire	1	1	3
P110/272	" Bevel Wheel	1	1	1 13 10
P110/271	Bottom Bevel for Vertical Shaft	1	1	
P110/267	Shim for Crankshaft Bevel .003"	as requ'd.		4
P110/268	" " " " .005"	as requ'd.		4
P110/269	" " " " .007"	as requ'd.		4
P110/263	Thrustwasher for Crankshaft			
	Location C.H.N.S.	1	1	2 2
P110/266	" for Crankshaft			
	Location P.B.	1	1	2 5
970	Front Engine Nose Piece (Two Parts)	1	1	1 7 0
P239/115	Bolt for Engine Nose Piece	4	4	5
PX110/41	Nut " " " "	4	4	doz. 1 3
P110/273	Shim " " " " .003"	as requ'd.		4
P110/274	" " " " " .005"	as requ'd.		4
P110/275	" " " " " .007"	as requ'd.		4
P239/102	Front Bearing Housing	1	1	1 9 3
PX105/14	" " " " Setscr. $\frac{7}{8}$ " Long	2	2	3
PX110/2	" " " " " $\frac{1}{2}$ " Long	6	6	3
P110/317	" " " " Gasket	1	1	4
PX110/95	Setscrew for Oil Pump	3	3	3
PX105/14	" " " " Dynamo Flange	4	4	3
PX110/3	" " " " Oil Drain Pipe Flange	2	2	3
PX110/11	" " " " Front Cover	4	4	3
PX110/93	Dowel for Locating Bearing Housing	1	1	doz. 9
P110/265	Starting Dog	1	1	2 4
PX110/29	Plug for Crankshaft Pin	3	3	11
P110/264	Fan Pulley Distance Piece	1	1	2 3
P239/114	" Pulley (Driver)	1	1	7 8

CONNECTING RODS AND PISTONS.

P239/104	Connecting Rod Metalled	4	4		1	0 10
P110/122	" " Cap Metalled	4	4			
P110/493	" " Bolt	8	8		1	8
PX110/22	" " " " Nut	8	8			3
P110/127	Piston	4	4		10	10
P110/128	" Ring	8	8		1	3
P110/129	" Scraper Ring	4	4		1	4
P239/105	Gudgeon Pin	4	4		2	4
P239/106	" " Setscrew (Small End)	4	4			4

Part No.	Description	No. Used Open	No. Used Closed	Price Each £ s. d.
LUBRICATING SYSTEM.				
P110/106	Tap Cyl. Block to Oil Pressure Gauge	1	1	2 3
880	Oil Base	1	1	2 9 8
PX110/19	Plug for Oil Base	1	1	1 6
949	Stud " " "	8	8	9
PX101/1	Nut " " "	8	8	doz. 1 3
PX105/14	Setscrew for Oil Base	4	4	3
PX101/2	Washers for Plug	2	2	doz. 9
P110/496	Gauge for Oil Base	1	1	10 0
P110/485	Gasket " " "	2	2	2 9
P265	Oil Strainer Assembly	1	1	9 0
947	" " Fibre Washer	1	1	doz. 10
P110/459	Oil Filler	1	1	5 8
PX110/1	" " Setscrew	1	1	3
P110/143	" " Clamp Plate	1	1	4
P110/469	" " Cap with Baffle	1	1	4 2
P239/117	Dip Stick	1	1	3 8
P110/3	Oil Pump Assembly	1	1	1 16 6
P110/494	" " Body	1	1	14 4
P110/492	" " " Gasket	1	1	doz. 1 0
PX110/31	" " Stud	3	3	3
PX101/1	" " " Nut	3	3	doz. 1 3
PX110/32	" " Plug $\frac{9}{16}$ " dia.	1	1	6
P110/497	" " " for Oil By-pass			
	2BA Thread	2	2	3
P110/451	" " Spindle and Driving Gear	1	1	8 6
PX110/43	" " Key	1	1	3
P110/152	" " Idle Spindle	1	1	5
P110/153	" " Spiral Gear (Driven)	1	1	13 7
P110/262	" " " (Driving)	1	1	10 10
P110/154	" " Driven Gear	1	1	5 0
P110/155	" " Cover	1	1	1 3
P110/160	" " Gasket	1	1	doz. 9
P239/109	" Relief Valve	1	1	7
P110/157	Relief Valve and Priming Plug	1	1	2 6
P110/158	" " Spring	1	1	4
PX110/33	Priming Plug Washer	1	1	doz. 1 4
P239/112	Oil Suction Pipe, Strainer to Pump	1	1	
P110/476	" " Nut	1	1	4 4
PX239/3	" " Nut	1	1	
P110/240	Cyl. Head Oil Drain Pipe (Front)	1	1	
P110/241	" " " " Flange (Top)	1	1	10 5
P110/228	" " " " Flange (Bottom)	1	1	
P110/235	Front Drain Pipe (Short)	1	1	5 0
P110/227	Cyl. Head Oil Drain Pipe (Rear)	1	1	10 5
P110/228	" " " " Flange	2	2	
P239/111	" " Feed Pipe	1	1	
P110/230	" " " Flange and Nut	1	1	3 8
PX239/2	" " " Union	1	1	
PX239/6	" " " Fibre Washer	1	1	doz. 4
PX110/39	" " " Flge. Setscrew	1	1	3

Spare Parts. Page Ten

Part No.	Description	No. Used		Price Each	
		Open	Closed	£	s. d.
PX110/40	Cyl. Head Feed Pipe Flange				
	Fibre Washer	1	1	doz.	4
P239/119	" " " " Gasket	1	1		5
PX110/100	" " Oil Drain Pipe (Top)	1	1	doz.	1 0
	Gasket	1	1	doz.	1 0
PX239/5	" " " " " (Rear)	2	2		5
PX239/5	" " " " " (Front)	1	1		5
P110/173	Oil Feed Choke	1	1		1 6
P110/200	" Drain Housing	1	1		7 4
PX110/6	" " " " Stud	2	2		3
PX101/1	" " " " Nut	2	2	doz.	1 3
P110/204	" " " " Shim .003"		as requ'd.		3
P110/205	" " " " " .005"		as requ'd.		3
P110/206	" " " " " .007"		as requ'd.		3
P110/207	" " " " " .010"		as requ'd.		5
P110/208	" " " " " .015"		as requ'd.		5
P110/209	" " " " " .020"		as requ'd.		8
PX110/45	" " Pipe Stud	2	2		3
PX101/1	" " " " Nut	2	2	doz.	1 3
PX110/6	" " Flange Stud	2	2		3
PX101/1	" " " " Nut	2	2	doz.	1 3
PX110/6	" Return Flange Stud	2	2		3
PX101/1	" " " " Nut	2	2	doz.	1 3

INLET AND EXHAUST MANIFOLD.

P110/292	Exhaust and Inlet Manifold	1	1	2 4	0
P110/302	Exhaust and Interport Gasket	1	1		9
P110/303	Inlet and Exhaust Rear End Gasket	2	2		9
PX110/101	Carburettor Gasket	1	1		4
PX110/36	Exhaust Manifold Stud	4	4		3
P110/167	" " " Nuts	4	4	1	0
PX110/37	" " " Washers (Steel)	4	4	doz.	8
PX110/54	Carburettor Flange Stud	2	2		3
PX110/55	" " " Nut	2	2	doz.	1 3

CLUTCH.

P239/122	Clutch Plate	1	1 }		
P239/123	" Centre	1	1 }	12	6
PX110/102	" Plate Rivets	6	6	doz.	4
P239/124	" Lever	3	3		3 6
P239/126	" Adjust. Screw	3	3	doz.	2 0
PX101/1	" " " Locknut	3	3	doz.	1 3
PX110/61	" " Felt Washer	6	6	doz.	1 2
PX110/62	" " Brass Washer	12	12	doz.	5
P110/334	" " Pin	3	3		4
P239/130	" " Spring	6	6		3
P239/125	" Fabric	2	2	4	8
P110/324	" Operating Pin	3	3		4
P239/128	" " " Bush	3	3		4
PX110/63	" " " Screw	6	6	doz.	11
P239/131	" Spring	6	6		5
P110/326	" Operating Sleeve	1	1		6 8

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P239/127	Clutch Cover with Friction Disc	1	1	1	1	8
P239/129	" Pressure Plate with Friction Discs and Thrustbutton	1	1	15	3	
PX110/65	" Pressure Plate Rivet $\frac{3}{8}$ " Long	6	6	doz.	4	
PX110/66	" " " $\frac{7}{8}$ " Long	6	6	doz.	4	
P110/338	" Thrust Bearing	1	1	13	0	
P110/333	" " " Cover	1	1	1	0	
P110/339	" Operating Shaft	1	1	10	10	
P239/132	" Driving Studs	6	6		3	
P110/348	" Operating Shaft Bush O.S.	1	1	3	5	
P110/349	" " " " N.S.	1	1	1	6	
PX110/71	" " " " " Locking Screw	2	2		3	
P110/387	" Inspection Cover	1	1	1	0	
PX110/4	" " " " Setscrew	2	2		3	
P110/363	" Centre Oil Feed Choke	1	1		6	
797	" Pedal	1	1	5	4	
1144	" " Return Spring	1	1		3	
1145	" " Spring Anchor Bracket	1	1		3	
1286	" " Stop Stud	1	1		4	
1388	" " " " Nut	1	1		4	
P110/422	" " " " Cotter Pin	1	1		5	

GEARBOX.

P110/340	Gearbox Studded	1	1	2	4	6
P110/109	" Plug	2	2		1	6
PX110/67	" " Fibre Washer	2	2	doz.	10	
P110/385	" Front Cover	1	1		4	9
P110/386	" " " Gasket	1	1	doz.	1	0
PX110/46	" " " Stud	4	4		3	
PX101/1	" " " " Nut	4	4	doz.	1	3
1146	" Rear Cover	1	1		11	10
P110/390	" " " Gasket	1	1		4	
P110/384	" Top Cover Gasket	1	1		1	4
PX110/6	" " " Stud $1\frac{1}{2}$ " Long	3	3		3	
PX110/68	" " " " $1\frac{3}{4}$ " Long	1	1	doz.	1	2
PX101/1	" " " " Nut	4	4	doz.	1	3
PX110/69	" Stud (Rear Facing)	4	4		3	
PX239/7	" " " " "	1	1		3	
P110/351	First and Reverse Sliding Gear	1	1	1	1	3
P110/352	Second and Third Speed Sliding Gear	1	1	1	3	11
P110/409	Speedometer Drive Bearing	1	1		8	9
P239/136	" Driving Gear	1	1		5	0
P239/137	" Driven Gear	1	1		5	6
P110/412	Layshaft Gear Large	1	1	2	4	3
P110/413	" " Centre	1	1			
P110/414	" " Small	1	1			
P110/415	Reverse Gear Large	1	1	1	12	7
P110/416	" " Small	1	1			
P110/418	Rivets for Layshaft & Reverse Gear	2	2	doz.	4	
P110/484	Gear Thrust Washer	4	4		1	6
P110/354	Layshaft Gear Bush (Const. Mesh End)	1	1		3	10
P110/355	" " " (First Speed End)	1	1		3	10

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P110/356	Reverse Gear Bush (Large Gear End)	1	1	3	0	
P110/357	" " " (Small Gear End)	1	1	3	0	
PX110/88	Layshaft Gear Key	3	3			3
	I only used on Eng. Nos. D500—631					
P110/389	Speedometer Gear Thrustbutton	1	1	1	0	
P110/358	Reverse Shaft	1	1	2	6	
P110/359	Layshaft	1	1	3	0	
P110/360	First Motion Shaft	1	1	10	10	
P110/361	Main Shaft	1	1	19	0	
PX105/12	" " Nut	1	1			3
PX105/13	" " " Washer	1	1			3
P110/362	Reverse & Countershaft Locking Screw	2	2			2
P110/366	First Motion Shaft Oil Thrower	1	1			4
P110/440	" " " " " Oil Retainer	1	1			4
P110/364	" " " Plug	1	1	doz.	1	0
P110/367	" " " Brg. Adj. Nut	1	1		5	2
PX110/74	" " " " " Lockwire	1	1			3
PX110/75	" " " " " Joint	1	1			6
PX110/73	" " " " " Spring Ring	1	1			7
PX110/76	" " " " " Shim .003"		as requ'd.			4
PX110/77	" " " " " .005"		as requ'd.			4
PX110/78	" " " " " .007"		as requ'd.			4
PX239/8	" " " " " .010"		as requ'd.			4
P239/133	" " " " " .015"		as requ'd.			5
PX110/79	Main Shaft Lock Ring	1	1	doz.	1	3
PX110/80	" " " Bearing Joint	1	1			4
PX110/81	" " " " " Spring Ring	1	1			6
P110/375	" " " Oil Thrower	1	1			4
P110/377	" " " Distance Piece (Short)	1	1			6
P110/378	" " " " " (Long)	1	1	1	2	
P110/380	" " " Stiffening Washer	1	1			2
P238/100	Propellor Shaft Flange	1	1	9	4	
PX110/85	Ball Bearing (First Motion Shaft)	1	1	8	9	
PX110/86	" " (Main Shaft)	1	1	11	6	
PX110/87	Roller Bush (Main Shaft Spigots)	1	1	11	6	
PX110/28	Ball Brg. (Tail End First Motion Shaft)	1	1	8	9	

CHANGE SPEED MECHANISM.

P225	Gear Control Assembly	1	1	4	10	0
704	Tube for Change Speed Lever	1	1	5	7	
703	Change Speed Lever	1	1	8	0	
1399	" " " Knob	1	1	1	3	
793	Locating Pin for Gear Lever	2	2	2	9	
708	Gear Control Gate	1	1	10	10	
692	Bush for Ch. Speed Lever (Rr. End)	1	1	2	9	
695	" " " " " (Fr. End)	1	1	5	4	
972	Change Speed Lever Plunger	1	1	1	7	
971	Plunger Spring	1	1			4
694	Change Speed Lever Felt Washer	1	1			11
698	Grub Screw for Gear Change	2	2			8
697	Circlip for Lever Pin	4	4			4

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
705	Change Speed Lever Pin	2	2		1	7
702	Selector Lever	1	1		4	9
701	Change Speed Shaft	1	1		5	4
699	Gearbox Top Cover	1	1	1	0	6
S1/5	Tecalemit Greaser	1	1			4
1489	Dome Nut $\frac{5}{16}$ "	2	2		6	
950	Second and Third Change Speed Rod	1	1		2	4
P110/396	Distance Piece for ditto	1	1			4
951	First and Reverse Change Speed Rod	1	1		2	4
P110/398	Distance Piece for ditto 1.062" Long	as requ'd.				4
P110/495	" " " 1.094" Long	as requ'd.				4
P110/399	Locking Bar	1	1			9
P110/400	Change Speed Operating Fork	2	2		5	10
PX110/83	Spring for ditto	2	2			4
PX110/84	Steel Ball for Fork and Locking Bar	4	4	doz.	1	6
P110/403	Locking Plate for Change Speed Rods	1	1			8

ENGINE SUPPORT.

1378	Rear Engine Support Block	2	2			9
129	Bolt Seat (Rubber)	2	2			5
130	Special Steel Washer	2	2	doz.	1	6
1375	Fibre Washer	2	2			2
881	Rear Eng. Bearer Dist. Pce. $1\frac{3}{4}$ " Long	2	2			3
1396	" " " " " $\frac{1}{2}$ " Long	2	2			2
1377	" " " " " $2\frac{3}{4}$ " Long	2	2			4
Supersedes Part Nos. 881 and 1396						

BRAKE GEAR.

P245	Brake Push Rod Assembly	1	1		5	7
875	Brake Push Rod	1	1		1	10
879	Yoke for ditto	2	2			11
933	Clevis Pin for ditto	2	2			6
P240	Brake Cross Shaft Assembly	1			2	15 10
	ceased Ch. Do350					
P302	" " " Assembly	1	1		2	15 10
	comm. Ch. Do351					
837	Brake Cross Shaft	1	1		7	0
841	Roller for Brake Cross Shaft	32	32	Set	2	6
842	Roller Bearing Retainer	1	1		2	6
861	Brake Cable Pulley	2	2		6	1
862	" " " Key	2	2			3
844	Cross Shaft Tube Blanking Disc	1	1			3
859	Foot Brake Actuating Lever (Fixed)	2	2		4	5
839	" " " " (Free)	1			4	5
	for P240					
1368	" " " " (Free)	1	1		2	9
	for P302					
860	" " " Adjusting Rod	1	1			8
858	Clevis Pin for ditto	1	1			4
846	Hand Brake Adjusting Nut	2	2		2	9
843	Collar for Brake Cross Shaft	1	1			8
840	Brake Cross Shaft Steady Brkt. (Free)	1	1		1	3
847	Hand Brake Lever	1	1		8	6

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
857	Hand Brake Lever Ratchet Pawl	1	1	2	2	2
850	" " " Tube	1	1	2	5	
849	" " " Knob	1	1	1	3	
853	" " " " Screw	1	1			4
852	" " " Pawl Spring	1	1			4
854	" " " Rod	1	1			8
856	" " " Screw	2	2			8
855	" " " Stud	1	1			4
845	" " " Adjusting Rod	1	1	3	11	
848	" " " Actuating Lever	1	1	2	5	
851	" " " Lever Clevis Pin	1	1			4
838	Bush for Brake Cross Shaft	1	1	1	6	
1071	Fibre Washer for ditto	2	2			4
922	Brake Cross Shaft Trunnion	2	2			8
877	Hand Brake Ratchet	1	1	4	2	
878	" " " Lever Stop	1	1	2	2	
QS805	Rubber Buffer	1	1			4
1051	Hand Brake Lever Return Spring	1	1			3
P266	Front Brake Cable Assembly	2	2	15	3	
P267	Rear Brake Cable Assembly	2		14	3	
	Ch. Do251—Do350					
P284	" " " Assembly	2	2	14	6	
	comm. Ch. Do351					
1047	Ferrules for Frame Slots	4	4			4
269	Foot Brake Pedal Return Spring	1	1			3
1365	Roller for Brake Pedal	23	23	Set	1	9
1007	Brake Pedal Fulcrum Pin	1	1			9
798	Foot Brake Pedal ceased Ch. Do350	1				5
1366	" " " comm. Ch. Do351	1	1			5
270	Brake Pedal Return Spring Bracket	1	1			7

CONTROLS.

P268	Accelerator Cross Shaft Assembly	1	1	16	3	
1060	Accelerator Cross Shaft	1	1			11
1061	" " Pedal	1	1	2	5	
1062	Actuating Lever	1	1	1	10	
463	Slow Running Lever	1	1	1	2	
186	Plummer Blocks	3	3	1	6	
1103	Jet Control Lever	2	2	1	8	
1102	" " Cross Shaft	1	1	4	5	
1104	" " Return Spring	1	1			3
P122	Coupling Rod to Throttle	1	1	1	4	
265	Accelerator Return Spring	1	1			4
266	" " " Bracket	1	1			7
1113	" " Pedal Stop	1	1			7
P276	Lucas Ignition Control Assy. IC/42	1	1	8	6	
1108	Jet Control Rod	1	1			4
1106	" " Connecting Rod	1	1			6
1111	Anti-Rattle Spring for Controls	3	3	doz.	1	4
1109	Slow Running Control Rod	1	1			4
1107	Control Rod Knob for					
	Part Nos. 1108 and 1109	2	2			6
132	Slow Running Rod Spring	1	1			7
1110	" " " Bracket	1	1	1	0	

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
1105	Control Rod Steady Bracket	1	1	2	6	
1112	Rubber Bushes for Controls	2	2		3	
1597	Guard Bracket for Jet Control Lever	1	1	1	3	

STEERING GEAR ASSEMBLY.

P242	Steering Gear Unit less Wheel	1	1	6	0	0
P242/100	Column Tube	1	1	10	0	
P242/101	Outer Steering Column	1	1	14	4	
P112/104	Steering Thrust Screw	1	1		9	
P112/106	Washer	1	1	1	3	
P112/107	Column Clamp	1	1	4	4	
P112/110	Ball Race (Upper)	1	1	6	10	
P112/111	Ball Race (Lower)	1	1	2	10	
P112/113	Column Coupling Tube	1	1	3	0	
P112/119	Plug	1	1	4	9	
P112/103	Locking Washer	1	1	doz.	7	
P112/108	Lower Ball Race Housing	1	1	2	1	
P112/126	Setscrew for Locking Washer	1	1		3	
P112/127	Locknut for Thrust Screw	1	1		3	
P112/128	Steering Ball Race	1	1	1	3	
A186	Steering Wheel 16"	1	1	2	0	
P112/109	Setscrew	1	1	1	4	
P112/112	Washer	1	1		8	
P112/120	Key	1	1		4	
P112/121	Felt Washer	1	1		4	
P112/137	Box	1	1	16	4	
P112/116	Bush (Long)	1	1	3	8	
P112/117	Bush (Short)	1	1	2	6	
P112/102	Nut	1	1	2	6	
PX110/54	Stud	4	4		4	
P112/114	Cover	1	1	4	9	
P112/115	Gasket	1	1		4	
P112/118	Worm	1	1	13	0	
P112/131	Wheel	1	1	17	10	
P242/102	Drop Arm	1	1	5	0	
P242/103	Stop Stud	2	2		11	
P112/135	Plate	1	1		7	
PX105/4	Spg. Washer	2	2	doz.	1	0
P112/132	Coupling Tube Pin	4	4	doz.	9	
P112/136	Drop Arm Bolt	1	1		3	
154	Column Support Bracket	1		2	6	
1433	" " " "		1	4	3	

RADIATOR AND CONNECTIONS.

P282	Radiator Complete	1	1	11	0	0
P214/100	Cap	1	1	12	0	
P214/101	Rubber Ring	1	1		7	
P282/100	Drain Tap	1	1	1	9	
P214/103	Fibre Washer	1	1		2	
1066	Mounting Washer	2	2		3	
1140	Water Hose Connection (Top)	1	1	1	7	
1141	" " " (Bottom)	1	1	1	7	

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
A245	Hose Connection Clips Top	2	2			10
A110	" " " Bottom	2	2			10
938	Radiator Stay Rod	2	2			9
1069	" " " Fork End	4	4			6
1068	" " " Eye Bolt	2	2			4
130	" Mounting Washer	2	2	doz.	1	6

SILENCER AND EXHAUST PIPES.

141	Exhaust Pipe Gasket	1	1			6
799	Front Exhaust Pipe Ch. Do251—Do350	1				8 9
1139	" " " comm. Ch. Do351	1	1			8 9
807	Silencer Ch. Do251—Do350	1				12 7
1208	" comm. Ch. Do351	1	1			12 7
831	" Clips	2	2			8
1092	'U' Bolt for Sil'cer Ch. Do251—Do350	1				3
1207	" " " " comm. Ch. Do351	1	1			3
1091	Exhaust Pipe Rear	1				7 2
830	" " Clip	1	1			1 10
1369	" " Rear		1			6 8

PETROL TANK AND PIPES.

1115	Petrol Tank less Cap	1				2 2 8
1196	Petrol Pipe with Unions 27½" Long Tank to Reserve Supply Pipe	1	1			3 0
1197	Petrol Pipe with Unions 30" Long Tank to Main Supply Pipe	1	1			3 4
1198	Petrol Pipe with Unions 52" Long Main Supply	1	1			3 4
1199	Petrol Pipe with Unions 52" Long Reserve Supply	1	1			3 4
1200	Petrol Tap ¼" Gas	1	1			6 1
1201	Petrol Pipe with Unions 56" Long Petrol Tap to Petrol Lift (Dull Plated)	1	1			3 11
	ceased Ch. No. Do450					
A242	S.U. Petrol Lift Moriscot	1	1			2 10 0
1202	Petrol Pipe with Unions 25½" Long Petrol Lift to Carburettor (Dull Plated)	1	1			2 0
S2/19	Combined Petrol Pipe & Tecalemit Clip	2	2			4
S2/11	Petrol Pipe Clip ⅝" dia.	7	7			3
S2/18	" " " ⅝" dia. Short	2	2			3
S2/23	" " " (Two Pipes) ⅝" dia.	1	1			7
1415	Distance Piece for Part No. S2/23	1	1			2
1410	Petrol Tank Dipstick	1				2 7
1409	" " "		1			2 7
1402	" " Strap	2				10
1428	" " "		2			11
1429	" " Mounting Block		2			4
1464	" " Cap	1	1			4 2
1251	" " less Cap		1			2 2 8
1563	" Pipe Petrol Tap to Petrol Lift 64" Long comm. Ch. Do451	1	1			4 1

Part No.	Description	No. Used Open	No. Used Closed	Price Each £ s. d.
ACCESSORIES AND SUNDRIES.				
P277	Shock Absorbers, Hartfords	1 Set	1 Set	8 0 0
P277/1	Shock Absorber O.S. Front	1	1	1 19 9
P277/2	" " N.S. Front	1	1	1 19 9
P277/3	" " O.S. Rear with Brkt.	1	1	2 3 9
P277/4	" " N.S. " " "	1	1	2 3 9
P277/100	" " Pin Front Top	2	2	2 0
P277/101	" " " Bottom	2	2	2 0
P277/102	" " " Rear	2	2	2 0
P277/103	" " " Nuts	6	6	3
A294	Wheels 19" x 3½" Rudge Whit. Unpntd.	5	5	1 5 6
A294	" " 19" x 3½" " " Painted			1 15 0
1123	Hubs Caps Rudge Whit. O.S. & N.S.	4	4	9 7
178	Number Plate Front	1	1	2 4
1124	" " " Rear	1	1	2 4
1456	" " " Bracket Rear		2	1 0
1219	Instruction Plate for Petrol Tap and Foot Brake Adj.	1	1	10
1226	" " " for Mixture Control	1	1	4
1227	" " " " Slow Run. Con.	1	1	4
1221	" " " " Grease Nipples			
	O.S.	1	1	1 1
1220	" " " " " Nipples			
	N.S.	1	1	1 1
P278	Tecalemit Grouped Nipple Syst. comp.	1	1	2 10 0
P278/100	Pipe 5/32" dia. x 4" Long	1	1	1 1
P278/101	" " " x 1' 7" "	1	1	2 0
P278/102	" " " x 1' 8½" "	2	2	2 0
P278/103	" " " x 2' 7" "	2	2	2 7
P278/104	" " " x 2' 11½" "	2	2	2 9
P278/117	" " " x 5' 9" "	2	2	4 3
	comm Ch. D0351			
P278/105	" " " x 7" with 7" Flex Tube	2	2	2 9
P278/106	" " " x 5' 4½" "			
	with 7" Flex Tube	2	2	5 5
P278/107	Zerk Battery Plate Fitting	4	4	1 3
P278/108	" " " " Two-way	2	2	1 5
P278/109	Adj. Feed Plug One-way ⅝" B.S.F.	4	4	11
P278/110	" " " " Two-way "	4	4	11
P278/118	" " " " Three-way "	2	2	1 3
P113/110	Fibre Washers Thick	8	8	doz. 4
P113/111	" " " Thin	32	32	doz. 4
P113/109	Clip for One Pipe	4	4	doz. 1 0
P278/111	" " Two Pipes	5	5	doz. 1 7
P278/112	" " Three Pipes	2	2	doz. 1 7
P278/113	2BA x ⅝" Bolt with Nut	11	11	doz. 2 2
Si/4	TZ65 Plug ⅝" B.S.F.	14	14	each 5
Si/6	TZ6 Plug ⅝" B.S.F. for Prop. Shaft	2	2	each 4
P278/119	Support Plate for Three Pipes	2	2	each 4
P278/120	Cone for 5/32" Pipe	4	4	doz. 1 7
P278/121	Cap for ditto	4	4	doz. 6
1480	Spring Clips for Starting Handle	3	3	2
A289	License Holder	1	1	6

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
DASHBOARD AND FUME EXCLUDERS.						
1121	Dashboard Wall O.S.	1	1	4	7	
1122	„ „ N.S.	1	1	4	7	
1142	Dash Panel	1	1	15	3	
978	Fume Excluded for Dash Panel					
	79" Long	1 Lgth.	1 Lgth.	3	8	
1170	Clutch Housing Draught Excluder					
	Plate Ch. Do251—Do350	1		8	4	
1175	Clutch Housing Draught Excluder					
	Plate comm. Ch. Do351	1	1	8	4	
978	Rubber Seal for Draught Excluder					
	Plate 32" Long	1 Lgth.	1 Lgth.	1	6	
1171	Undertray Ch. Do251—Do350	1		9	10	
1176	„ comm. Ch. Do351	1		9	1	
1172	Draught Excluder Rubber	2		4		
	Ch. Do251—Do350					
1177	„ „ Rubber	2	2	4		
	comm. Ch. Do351					
1173	Clip for Draught Excluder Rubber	2	2			3
130	Distance Washer for Dashboard Wall	2	2	doz.	1	6
1461	Draught Excluder for Steering Column	1	1		1	10
1618	Undertray		1			

ELECTRICAL EQUIPMENT AND INSTRUMENTS.

A246	Instrument Panel 12v. Rotax FT74	1	1	2	15	0
P292/1	Speedo Instrument Smith's 80 m.p.h.	1	1	2	15	0
P292/2	Speedo Cable Inner and Outer	1	1	13	0	
P292/100	" " Inner	1	1	6	6	
P292/101	" " Outer	1	1	6	6	
A259	Oil Indicator, Jaeger	1	1	1	10	0
1192	Oil Gauge Pipe with Unions	1	1	3	6	
335	Washers for ditto	2	2			1
A247	Starter Switch S2F Short	1	1	7	6	
1189	" " Bracket	1	1	2	2	
1320	" " " Backing Plate	1	1			7
A249	Cut-out and Junction Box 12v.	1	1	1	5	0
A250	Battery 12v. RW9B comp.	1	1	5	15	0
A251	Headlamps 12v. K624	2	2	Pair	4	17 0
A188	Switch for O.S. Headlamp 2909	1	1	2	6	
A252	Side Lamps 12v. 1130 Chrom. & Black	2	2	Pair	1	1 0
650	Side Lamp Packing	2	2			8
A253	Tail Lamp 12v. TF201	1	1	8	6	
A254	Coil 12v.	1	1	1	0	0
A255	Horn 12v. HF318	1	1	1	4	6
A193	Horn Push	1	1	2	6	
A256	Harnessed Cables	1	1	2	2	0
P291	Windscreen Wiper 30F less Tubing	1	1	1	10	6
A257	Driving Mirror No. 160TMS	1		13	6	
A286	" " No. 20S		1	5	0	
A248	Auxiliary Junction Box C30	1	1	2	6	
P239/113	Dynamo DDS12	1	1	7	12	6
P239/116	Distributor DJ4 12v.	1	1	1	5	6
P110/288	" Securing Screw	1	1			3

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
P239/120	Starter M35AF Type 12v.	1	1	5	5	0
PX110/12	„ Fixing Bolt	1	1			3
PX101/10	„ „ „ Nut	1	1	doz.	1	3
PX110/10	„ „ „ Setscrew	2	2			3
P110/111	„ „ „ Packing Piece	1	1		1	9
P308	Carburettor S.U.	1	1	5	0	0
P110/461	Sparking Plugs Champion No. 7	4	4		5	0
P239/121	H.T. Leads	1 Set	1 Set		5	3
1393	Rubber Bush for Cables on Dash Panel	3	3			4
1394	„ „ „ Oil Gauge Pipe	1	1			3
1484	„ „ „ Tail Lamp Cables	1				3
1558	Chrom. Plated Tubing for Windscreen Wiper	2' 6"	2' 6"		2	0
1559	Copper Tubing for ditto	4'	4'		2	6
1560	Rubber Tubing for ditto	1'	1'			3

BONNET, WINGS AND FAIRINGS.

1041	Front Wing O.S. unptd.	1	1		2	1	4
1041	„ „ O.S. painted	1	1		2	18	10
1042	„ „ N.S. unptd.	1	1		2	1	4
1042	„ „ N.S. painted	1	1		2	18	10
1127	Wing Stay Tie Rod	1	1			2	9
1064	Headlamp and Wing Stay Brkt. O.S.	1	1			4	0
1065	„ „ „ „ N.S.	1	1			4	0
1070	Rubber Washer for ditto	2	2				8
1094	Distance Piece for Wing Stay Brkt.	4	4	doz.	1	4	
1093	Front Wing Rear Stay O.S.	1	1			2	2
1099	„ „ „ „ N.S.	1	1			2	2
1178	Rear Wing O.S. unptd.	1	1		1	5	10
1178	„ „ O.S. painted	1	1		1	19	10
1179	„ „ N.S. unptd.	1	1		1	5	10
1179	„ „ N.S. painted	1	1		1	19	10
1100	Front Fairing unptd.	1	1			17	4
1100	„ „ painted	1	1		1	5	10
1125	Side Fairing O.S. unptd.	1				10	6
Ch. Do251—Do350							
1125	„ „ O.S. painted	1				16	0
1126	„ „ N.S. unptd.	1				10	6
1126	„ „ N.S. painted	1				16	0
1230	„ „ O.S. unptd.	1	1			8	7
comm. Ch. Do351							
1230	„ „ O.S. painted	1	1			14	1
1231	„ „ N.S. unptd.	1	1			8	7
1231	„ „ N.S. painted	1	1			14	1
1129	Bonnet with cutting allowance unptd.	1	1		2	0	0
1129	„ „ „ „ painted	1	1		4	10	0
A262	Bonnet Fasteners	4	4			4	2
259	„ Rod Lug	1	1				8
1372	„ Hinge Rod Bracket	1	1				5
1370	„ Fastener Bracket Rear O.S.	1				1	3
ceased Ch. Do350							
1416	„ „ Bracket Rear N.S.	1				1	3
ceased Ch. Do350							
1373	„ „ Bracket Front O.S.	1	1			1	7

Part No.	Description	No. Used		Price Each £ s. d.
		Open	Closed	
1374	Bonnet Fastener Bracket Front N.S.	1	1	1 7
1465	Front Wing Side Fairing O.S. unptd.	1	1	2 6
1466	" " " " N.S. "	1	1	2 6
1485	Side Fairing Fixing Bracket O.S.	1	1	1 2
1486	" " " " N.S.	1	1	1 2
1481	Bonnet Fastener Stirrups	4	4	4
1550	Bonnet Fastener Bracket Rear O.S. comm. Ch. Do351	1	1	1 8
1551	" " Bracket Rear N.S. comm. Ch. Do351	1	1	1 8

BODY DETAILS.

PROPELLOR SHAFT SHROUD AND FOOTWELL.

1101	Propellor Shaft Shroud	1		1 3 10
	Ch. Do251—Do350			
1181	" " Shroud	1	1	1 3 3
	comm. Ch. Do351			
1183	" " Shroud Bottom Plate	1		4 2
	Ch. Do251—Do350			
1223	" " Shroud Bottom Plate	1	1	3 11
	comm. Ch. Do351			
1438	" " Shroud Platform	2	2	1 4
361	Dome Nuts $\frac{1}{4}$ " B.S.F.	6	6	6
979	Support Bracket for Platform	2	1	2 7
	1 only used after Ch. Do350			
1001	' U ' Clip for ditto	2	1	4
	1 only used after Ch. Do350			
1211	Support Bracket for Platform	1	1	3 0
	comm. Ch. Do351			
1212	' U ' Clip for ditto	1	1	6
	comm. Ch. Do351			
1114	Footwell Ch. Do251—Do350	1		10 4
1174	" comm. Ch. Do351	1	1	9 10
1434	Angle Plate (Short) for Footwell			
	Front End ceased Ch. Do350	2		4
1435	" Plate (Short) for Footwell			
	Rear End ceased Ch. Do350	2		4
1436	" Plate (Long) for Footwell			
	Front End comm. Ch. Do351	2	2	4
1437	" Plate (Long) for Footwell			
	Rear End comm. Ch. Do351	2	2	4

SPARE WHEEL CARRIER.

1193	Spare Wheel Hub	1	}	1 7 0
1194	" " Locknut and Sleeve	1		
B220/110	" " Carrier Block	1		11 0
B220/111	Bolts for ditto	4		2 4
P316	Spare Wheel Carrier Assembly with R.W. Centre		1	2 7 4
1620	" " " Bracket		1	2 6
1322	" " " Distance Tube		1	8
1619	" " " Support Channel		1	10 10

Part No.	Description	No. Used		Price Each £ s. d.
		Open	Closed	
1616	Spare Wheel Carrier Special Wing Nut	1		5 4
1615	" " " Tie Bar	1		8 6
1384	" " " Trough	1		3 8
1617	" " " Tyre Clip	1		8 6
1386	" " " Body Support	1		4 9
1389	" " " Body Fitting L.H.	1		2 1
1391	" " " Nut for Body Sppt.	2		4 4
1392	" " " Trough Support	1		1 7
1395	" " " Special Washer for Tie Bar	1		3
1479	" " " Trough Clip	1		8 6
1455	" " " Rubber Bush for Body	1		6
P309	" " " Centre (Rudge Whit.)	1		7 0

LUGGAGE CARRIER ASSEMBLY.

P307	Luggage Carrier Assembly	1		1 12 0
1418	Slide Fitting in Flap for Support Arm N.S.	1		3 6
1419	" " " Flap for Support Arm O.S.	1		3 6
1420	Luggage Carrier Support Arm	2		5 6
1421	Wing Nut for ditto	2		1 8
1422	Grub Screw for ditto	2		3
1424	Support Clip on Flap for Arm	2		3
1426	N.S. Hinge on Body	1		1 6
1431	N.S. Hinge on Flap	1		1 3
1427	O.S. Hinge on Body	1		1 6
1432	O.S. Hinge on Flap	1		1 3
1430	Swivel Pin Bracket for Hinge	2		1 10
1423	Bottom Fixing Block for Support Arm	2		3 11
1425	Body Fixing Brackets for ditto	2		4
1439	Studs for ditto	4		3

HOOD AND SIDE SCREENS.

B220/131	Hood Canopy Ch. Do251—Do350	1		2 10 0
B221/105	" " comm. Ch. Do351	1		2 10 0
B220/149	" Bag Ch. Do251—Do350	1		15 0
B221/106	" " comm. Ch. Do351	1		15 0
B220/134	" Rest O.S.	1		7 0
B220/135	" " N.S.	1		7 0
B220/137	" Strap	2		2 0
B220/138	" to Screen Attachment	2		4 6
B220/125	Rigid Sidescreen O.S.	1		1 1 0
	Ch. Do251—Do350			
B221/103	" " O.S.	1		1 1 0
	comm. Ch. Do351			
B220/126	" " N.S.	1		1 1 0
	Ch. Do251—Do350			
B221/104	" " N.S.	1		1 1 0
	comm. Ch. Do351			
B220/127	Side Flap Rear O.S.	1		11 0
B220/128	" " " N.S.	1		11 0
B128/119	" Curtain Socket	4		10

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
FLOOR BOARDS AND MATS.						
B220/116	Floor Board Large O.S.	1		7	0	
	Ch. Do251—Do350					
B221/101	„ „ „ O.S.	1		7	0	
	comm. Ch. Do351					
B222/102	„ „ „ O.S.		1	7	0	
B220/117	„ „ „ N.S.	1		7	0	
	Ch. Do251—Do350					
B221/102	„ „ „ N.S.	1		7	0	
	comm. Ch. Do351					
B222/103	„ „ „ N.S.		1	7	0	
B220/118	„ „ „ Small O.S.	1	1	5	0	
B220/119	„ „ „ N.S.	1	1	5	0	
1469	„ „ „ Pedal Strip	1	1			3
B220/104	Carpet Mat O.S. Front	1	1	9	0	
B220/105	„ „ „ N.S.	1	1	9	0	
B220/106	„ „ „ Centre Ch. Do250—Do350	1		7	0	
B221/100	„ „ „ „ comm. Ch. Do351	1	1	7	0	
B220/107	„ „ „ for Footwell	1	1	7	0	
B220/108	„ „ „ for Heel Board	1	1	6	0	
B220/109	Rubber Mat	2	2	2	0	
B128/7	Lift the Dot Fastener comp.	as requ'd.				6

SEATS AND FIXINGS.

B220/100	Bucket Seat	2		2	10	0
B222/100	" " "		2	2	10	0
B220/101	" " " Cushion	2	2	1	5	0
B220/112	" " " Adjusting Plate	4	4	}	2	6
B220/113	" " " Wing Nut	4	4			
1459	Seat Fixing Draught Excluder Plate	4	4			6
B220/102	Rear Seat Cushion	1	1	3	0	0
B220/103	" " " Squab	1		1	5	0
B222/101	" " " "		1	1	5	0
B220/140	" " " Pan	1	1	1	15	0
B220/147	Air Bag for Bucket Seat	2	2		15	0
B220/148	" " " for Rear Seat	2	2		15	0

LOCKS AND HANDLES.

B220/120	Door Handle O.S.	1		5	0	
B220/121	" " " N.S.	1		5	0	
B222/1	" " " with Lock and 2 Keys		2	15	0	
B220/129	" " " Lock O.S.	1		3	3	
B220/130	" " " N.S.	1		3	3	
B128/120	Boot Lid Lock	1	2	2	0	
B128/113	" " " Key	1	1	1	0	
B128/121	Escutcheon Plate for ditto	1	2	1	6	
B222/5	Sliding Roof Lock		2	10	0	
B222/106	" " " Handle		1	1	0	
B222/113	Inside Door Handle O.S.		1	5	0	
B222/114	" " " " N.S.		1	5	0	

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
WINDSCREEN AND DOOR GLASSES.						
B220/141	Windscreen Glass	1		1	18	9
B222/111	" "		1	2	1	3
B220/142	" " Frame comp. less Glass	1		6	10	0
B222/112	" " comp. less Glass		1	6	10	0
B222/115	Door Glass Rear		2	1	3	5
B222/116	" " Front (for Bodies with Window Winder)		2	1	8	4
B222/123	" " " (Sliding Type)		2	1	4	10
B222/117	Rear Light Glass		1	1	6	7

MISCELLANEOUS FITTINGS.

B222/2	Window Winder O.S.		1	1	0	0
B222/3	" " N.S.		1	1	0	0
B222/104	" " Handle O.S.		1		5	0
B222/105	" " " N.S.		1		5	0
B220/139	Tool Box	1	1		15	0
B220/122	Bonnet Rest O.S.	1	1		5	6
B220/123	" " N.S.	1	1		5	6
B128/118	" " Tape	1	Lgth.	1	Lgth.	2 6
B222/6	Roof Lamp					8 0
B222/4	Rear Window Blind with Fittings			1		1 5 0
B220/143	Facia Board	1				2 0 0
B222/118	" "		1			2 0 0
B220/136	Rear Number Plate Tie Bar	1				3 0
B222/108	Door Check Strap		2			2 0
B222/107	Sliding Roof Channel		2			10 0
B128/109	Aluminium Body Beading	1 Set				
	(Top of Body) 1 $\frac{1}{4}$ " wide					
B220/144	" Body Beading					15 0
	(Top of Body) $\frac{5}{8}$ " wide	1 Lgth.				
B222/120	" Body Beading					
	(Bottom of Body) 1 $\frac{1}{8}$ " wide			1	Lgth.	15 0
B222/109	Drip Beading $\frac{3}{4}$ " wide	1 Set				
B222/119	Rain Channel for Roof complete					1 16 0
B220/124	Rubber Door Buffer	2	2			1 0
B220/145	Door Hinge O.S.	2				2 6
B220/146	" " N.S.	2				2 6
B222/121	" " O.S.		2			2 6
B222/122	" " N.S.		2			2 6
1408	Plates for Body Mounting Rear	4	4			7
1482	Rubber Seal Fixing Plate	2	2			2
1457	Support Bracket for Glove Pocket		2			1 1

TOOL KIT.

Tool Roll	1	1	4	0
Screwdriver 10"	1	1	1	6
Tyre Levers	2	2		9
Adjustable Spanner	1	1	2	8
Pliers 6" Pair	1	1	1	0
Box Spanner $\frac{1}{2}$ "	1	1		10

Part No.	Description	No. Used		Price Each		
		Open	Closed	£	s.	d.
	Box Spanner $\frac{9}{16}$ "	1	1	1	1	
	" " $\frac{7}{16}$ " and $\frac{3}{8}$ " D.E.	1	1			10
	" " $\frac{5}{16}$ " and $\frac{1}{4}$ " D.E.	1	1			8
	" " $\frac{1}{4}$ " and $\frac{3}{16}$ " D.E.	1	1			6
	Tommy Bar	1	1			3
	Tappet Spanner with Feeler Gauge	1	1	1	0	
	" " (Locking)	1	1			9
	Spanner $\frac{1}{4}$ " $\times$ $\frac{3}{16}$ " D.E.	1	1			6
	" $\frac{3}{8}$ " $\times$ $\frac{5}{16}$ " D.E.	1	1			10
	" $\frac{1}{2}$ " $\times$ $\frac{7}{16}$ " D.E.	1	1	1	3	
	" $\frac{1}{4}$ "	1	1			10
	Contact Breaker Spanner	1	1			6
	Grease Gun	1	1	10	6	
	Tyre Pump	1	1	7	0	
	Jack with Handle					
	(Shelley Double Lift)	1	1	1	1	0
1401	Starting Handle	1	1			3 8
	Hammer for Rudge Hubs	1	1			6 6
1182	Special Engine Spanner	1	1			1 6
A288	Grease Gun for Propeller Shaft	1	1			6 0