

PRICE 2/6

THE SPARE PARTS LIST FOR

THE



MIDGET

(J Type)

JANUARY, 1935

IMPORTANT

When ordering replacements it is of the greatest assistance to our Service Department if the part required is given its correct reference number and description, and the chassis and engine numbers should be quoted in all correspondence as well as on the order itself, as delay and misinterpretation of orders are thus avoided.

We would also draw your attention to the fact that you will get quicker service if you place all your orders with our Distributors in your territory, who are holding very adequate stocks of M.G. Spares.

The name and address of the nearest Distributors is given in Instruction Manual supplied with the car, and we feel sure that all your requirements will receive every consideration and attention.

May we request you therefore to get into touch with our Distributors for all your future orders ?

The prices quoted are nett at the Distributors' or Dealers' premises, but in the event of parts having to be forwarded, packing and posting charges will of course be extra.

Except in the case of those who have opened approved accounts, all parts that can be will be forwarded C.O.D.

We cannot stress too highly the *danger* of fitting non-genuine M.G. parts.

Unfortunately cases have come to our notice where accidents have actually been caused by this practice, and we strongly advise all M.G. owners to insist and see that for all repairs and replacements only genuine M.G. parts are fitted.

M.G. parts are specially designed and manufactured to withstand the stresses imposed by a high-speed sports car, and we would warn all owners that the fitting of non-genuine parts renders the guarantee *null and void*.

The Company only fit the highest grade and best known proprietary fitments, but we give no guarantee whatsoever in respect of tyres, lamps, electrical equipment, speedometers, clocks, or any other proprietary fittings of any type supplied with the car or otherwise, as such proprietary fittings are usually covered by a guarantee issued by their respective manufacturers.

All questions involving the replacement or repair of any such proprietary fittings should therefore be taken up direct with the manufacturers concerned, and not with The M.G. Car Company Ltd.

G.K.—G.T.



CHASSIS NUMBER.....

ENGINE NUMBER.....

BODY NUMBER.....

REGISTRATION NO.....

NAME

ADDRESS

DATE.....

AGENT

**PLEASE FILL IN AND QUOTE REFERENCES IN
CORRESPONDENCE AND WHEN ORDERING
PARTS.**

INDEX

	<i>Sheet</i>
Accelerator Gear	12
Accessories	14—15
Axle (Front)	1—2
Axle (Rear)	2—4
Body and Details (Two-seater)	19—20
Body and Details (Four-seater)	20—21
Body and Details (Saloon)	21—22
Bonnet	18
Brake Gear	11—12
Chassis Frame and Details	1
Controls	12
Dashboard and Fume Excluders	15
Electrical Equipment	15—16
Exhaust System and Silencers	13
Fairings	17—18
Instruments	15—16
Petrol Tank and Pipes	14
Power Unit and Installation	4—12
Bell Housing and Rear Main Bearing	5
Carburettors	7—8
Clutch Details	9
Connecting Rods and Pistons	6
Crankshaft and Intermediate Main Bearings	5
Cylinder Block	4—5
Cylinder Head	6—7
Dynamo and Vertical Drive	8
Electrical Details.. .. .	9
Engine Nosepiece and Front Main Bearing	5
Flywheel	5
Gearbox and Remote Control	10—11
Lubrication Details	8—9
Manifolds, Inlet and Exhaust	7—8
Propeller Shaft Shroud and Fittings	18
Radiator and Connections	13
Shock Absorbers	14
Spare Wheel Carrier and Fittings	18—19
Springs (Front)	2
Springs (Rear)	4
Steering Gear	12—13
Sundries.. .. .	14—15
Tool Kit	22
Wings (Front and Rear)	16—17

Do not forget to quote Chassis, Engine and Body Numbers in all correspondence.

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
CHASSIS FRAME AND DETAILS							
P347	Chassis frame assembly comprising:—2 side members, 5 cross tube assemblies, 2 front and 2 rear dumb-irons, 2 front sliding trunnion boxes and 2 rear spring suspension pins						
	Ceased Chassis No. J3437	1	—	—	11	17	6
MG472	Chassis frame assembly as above	1	—	—	11	17	6
	Comm. Chassis No. J3438	1	—	—	11	17	6
P361	Chassis frame assembly as above	—	1	1	11	17	6
1879	Side member O/S	Ceased Chassis No. J3437	1	—	—	1	6 11
1880	" " N/S	Ceased Chassis No. J3437	1	—	—	1	6 11
2819	" " O/S	Comm. Chassis No. J3438	1	—	—	1	6 11
2820	" " N/S	Comm. Chassis No. J3438	1	—	—	1	6 11
2039	" " O/S		—	1	1	1	6 11
2040	" " N/S		—	1	1	1	6 11
623	Front dumb-iron O/S		1	1	1	5	10
624	" " N/S		1	1	1	5	10
625	Taper washer for ditto		2	2	2	4	
626	Front sliding trunnion bracket	O/S	1	1	1	10	1
627	" " " " " " N/S		1	1	1	10	1
632	Cover for ditto		2	2	2	1	7
633	Roller for ditto		4	4	4	3	8
P232/1	Front cross tube assembly		1	1	1	7	6
P347/2	Engine bearer cross tube assembly		1	1	1	1	5 7
637	Cap for engine mounting		1	1	1	2	0
638	Special bolt for ditto		2	2	2		11
P233/3	Third cross tube assembly		1	1	1	14	4
921	Combined cross tube end bracket and brake cross shaft support		2	2	2	4	10
P232/4	Rear spring front cross tube assembly		1	1	1	1	3 0
806	Rear spring front suspension pin		2	2	2	5	4
640	End bracket for cross tube		2	2	2	2	6
P233/5	Rear cross tube assembly		1	1	1	2	3 0
819	Rear spring sliding trunnion roller		4	4	4	3	8
820	Distance washer for ditto		2	2	2		6
873	Distance piece for ditto		2	2	2		11
872	Cap for rear cross tube		2	2	2	4	9
804	Rubber buffer and plate for front axle stop		2	2	2	1	7
805	Backing plate for ditto		2	2	2		4
815	Rear axle striking pad (rubber)		2	2	2		3
817	Set screw for ditto		2	2	2	doz.	2 0
874	Combined greaser and set screw for rear spring front suspension		2	2	2		10
1367	Brake pedal bracket		1	1	1	9	3
FRONT AXLE AND SPRINGS							
MG374	Front axle assembly less springs and wheels		1	1	1	12	17 6
P234/100	Axle beam		1	1	1	2	6 6
P101/10	Steering knuckle (bushed) O/S		1	1	1	1	7 8
P101/11	" " (bushed) N/S		1	1	1	1	7 8
P101/107	Bush for steering knuckle (top)		2	2	2	2	8
P101/149	" " " " (bottom)		2	2	2	2	6
P101/115	Washer for steering knuckle (outer)		2	2	2	doz.	9
P101/113	Slotted nut for steering knuckle O/S		1	1	1	1	0
P101/114	" " " " N/S		1	1	1	1	0
P101/101	Steering knuckle king pin		2	2	2	6	6
P101/104	Thrust washer for steering knuckle		2	2	2	1	3
MG374/1	Cotter pin for ditto		2	2	2	1	2
X101/1	Nut for cotter pin		2	2	2	doz.	8
X101/2	Spring washer for ditto		2	2	2	doz.	8
X101/6	Disc for steering knuckle (top)		2	2	2	doz.	1 0
P234/101	Steering arm N/S		1	1	1	9	4
P234/102	" " O/S		1	1	1	9	4
P101/8	Brake anchor bracket assembly		2	2	2	5	6
P101/132	Bush for brake cam		2	2	2	2	4
X234/2	Bolt for brake anchor bracket (1 $\frac{1}{16}$ " long)		4	4	4		3
X101/8	" " " " (2 $\frac{5}{16}$ " long)		2	2	2		3
X101/9	" " " " (2 $\frac{1}{8}$ " long)		2	2	2		3
X101/10	Nuts for ditto		8	8	8	doz.	1 3
X101/11	Spring washers for ditto		8	8	8	doz.	8
P101/120	Brake cam		2	2	2		8 6
P101/121	Washer for ditto (inner)		2	2	2	doz.	9
P101/122	" " " " (outer)		2	2	2	doz.	9
P101/124	Brake cam lever		2	2	2		4 4

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	MG	DESCRIPTION	MG	No. Used			Price Each		
				3-seater	4-seater	Saloon	£	s.	d.
S1/8		Stauffer grease cup for ditto...		2	2	2			9
N101/4		Key for ditto ...		2	2	2			3
N101/5		Pinch bolt for ditto ...		2	2	2			3
N101/1		Nut for ditto ...		2	2	2	doz.	1	3
N101/2		Spring washer for ditto ...		2	2	2	doz.		8
P101/132		Bush for brake-shoe fulcrum pin		2	2	2		2	4
P101/123		Brake-shoe fulcrum pin		2	2	2		2	6
P101/133		Nut for ditto ...		2	2	2			3
N101/3		Washer for ditto ...		2	2	2	doz.		6
MG374/2		Brake-shoe assembled with lining		4	4	4		12	3
P234/4		Brake-shoe ...		4	4	4		7	6
MG374/100		Lining for brake-shoe ...		4	4	4		3	0
MG374/101		Rivets for brake-shoe lining		32	32	32	doz.		5
574		Vibration damper weight		4	4	4		2	0
576		Clevis pin for ditto ...		8	8	8			3
575		Spring for ditto ...		8	8	8			3
N101/12		Washer for ditto ...		16	16	16	doz.		8
P101/129		Brake-shoe spring		4	4	4			4
P101/118		Felt for front hub		2	2	2			3
P101/109		Distance washer for front hub		2	2	2			0
P101/116		Hub bearing (inner)		2	2	2		10	6
P101/110		Distance piece between bearings		2	2	2			0
P101/117		Hub bearing (outer)		2	2	2		10	9
P234/5		Front hub (studded) O/S		1	1	1		14	6
P234/6		" " (studded) N/S		1	1	1		14	6
P234/103		Hub studs		12	12	12			9
N234/1		Nut for hub studs		12	12	12	doz.		10
N101/11		Spring washer for ditto		12	12	12	doz.		8
P234/1		Brake-drum		2	2	2		1	5
P101/3		Track rod assembly		1	1	1		18	6
P101/9		Track rod tube		1	1	1		6	6
P101/136		Lock nut for ditto (R.H. thread)		1	1	1			4
P101/137		" " " (L.H. thread)		1	1	1			4
P101/140		Adjustable end for ball joint (R.H. thread)		1	1	1		5	6
P101/141		" " " (L.H. thread)		1	1	1		5	6
P101/144		Spring for ball joint		2	2	2			3
P101/142		Ball cup (inner)		2	2	2			10
P101/143		End cup for ball joint		2	2	2		1	0
P101/138		Steering ball		2	2	2		2	0
P101/139		Nut for ditto		2	2	2			4
P235		Draglink assembly		1	1	1		17	2
P235/1		Draglink tube		1	1	1		5	0
P102/102		Adjustable end for ditto (R.H. thread)		1	1	1		5	6
P101/141		" " " (L.H. thread)		1	1	1		5	6
P101/136		Lock nut for ditto (R.H. thread)		1	1	1			4
P101/137		" " " (L.H. thread)		1	1	1			4
P101/138		Steering ball		2	2	2		2	0
P101/142		Ball cup (inner)		2	2	2			10
P102/105		End cup (outer)		1	1	1		1	0
P102/106		Plug for ditto		1	1	1			3
P101/143		Ball cup plug (outer)		1	1	1		1	0
P101/144		Spring for ball joint		2	2	2			3
P236		Front spring O/S and N/S		2	2	2	1	5	0
P236/100		Front spring top leaf		2	2	2		4	2
P236/101		Front spring 2nd leaf		2	2	2		4	7
P236/102		Front spring 3rd leaf		2	2	2		7	0
P236/103		Front spring 4th leaf		2	2	2		3	9
P236/104		Front spring 5th leaf		2	2	2		3	8
P236/105		Front spring 6th leaf		2	2	2		3	6
P236/106		Front spring 7th leaf		2	2	2		3	2
1045		Front shock absorber bracket O/S (on springs)		1	1	1		4	2
1046		Ditto N/S (on springs)		1	1	1		4	2
1190		Front spring bottom plate		2	2	2		1	6
2422		Bolt for front spring securing		8	8	8			10
2309		Stiffening strip for front spring		4	4	4			8
1951		Front brake cable stop bracket		2	2	2			4
801		Front spring suspension pin		2	2	2		2	5
802		Tab washer for ditto		2	2	2			4
803		Dust excluder for front spring		2	2	2		1	0

REAR AXLE AND SPRINGS AND PROPELLER SHAFT

P238	Rear axle assembly less springs and wheels	1	1	1	23	0	0
MG494/1	Rear axle banjo with spring pads	1	1	1	2	8	6

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
P238/122	Oil retainer for axle banjo N/S	1	1	1	1	1	1
P238/123	" " " " " O/S	1	1	1	1	1	1
X105/11	Taper drain plug for axle casing	1	1	1			4
X105/1	Screw for front cover (1" long)	6	6	6	doz.	1	3
X105/2	" " " " (1 $\frac{3}{8}$ " long)	2	2	2	doz.	1	3
P238/128	Spring packing washer for ditto	8	8	8	doz.		5
P238/15	Rear axle front cover complete with differential assembly	1	1	1	12	0	0
P238/1	Rear axle front cover (studded) with differential bearing caps	1	1	1	2	3	0
P275/104	Stud for differential bearing caps (used only with aluminium front cover)	4	4	4			3
P238/119	Stud for differential bearing cap (for malleable iron front cover)	4	4	4			2
P101/139	Nut for ditto	4	4	4			4
P238/116	Stud for bevel pinion housing (used only with aluminium front cover)	4	4	4			2
X238/1	Stud for bevel pinion housing (for malleable iron front cover)	4	4	4			2
P105/129	Bevel pinion housing	1	1	1	16		4
X105/5	Spring ring for ditto	1	1	1			7
P105/137	Bevel pinion washer	1	1	1			5
X105/6	Bevel pinion roller bearing	1	1	1	18		6
P105/174	Bevel pinion bearing distance piece	1	1	1	1		0
P105/131	Bevel pinion thrust bearing	1	1	1	13		3
P105/103	Shims for bevel pinion (.005")	as required					3
P105/104	" " " " (.010")	as required					3
P105/105	" " " " (.020")	as required					3
P105/135	Cap for bevel pinion housing	1	1	1	7		9
P275/102	Packing piece for bevel pinion bearing housing	1	1	1	2		0
P105/127	Screw for ditto	2	2	2			3
X105/3	Nut for pinion housing stud	4	4	4	doz.	1	3
X105/4	Spring washer for ditto	4	4	4	doz.		8
P238/127	Universal joint flange	1	1	1	9		4
X105/12	Slotted nut for ditto	1	1	1			3
X105/13	Washer for ditto	1	1	1			3
P238/5	Differential assembly complete with crown wheel and pinion	1	1	1	11	11	6
P105/9	Differential case complete	1	1	1	1	6	0
MG470/102	Differential wheel	2	2	2			8
P105/121	Differential pinion	2	2	2			7
P105/122	Differential pinion pin	1	1	1			1
P105/123	Dowel for ditto	1	1	1			9
P238/12	Crown wheel and pinion (8/43 ratio)	1 pr.	1 pr.	1 pr.	pair 2	7	10
X470/1	Differential case bolts	6	6	6			9
P105/116	Castle nuts for ditto	6	6	6			3
P105/106	Differential bearing	2	2	2	14		3
P105/143	Differential bearing adjusting nut	2	2	2	1		9
P105/107	Lock washer for ditto	2	2	2			3
P105/163	Joint for front cover	1	1	1			4
X105/3	Nut for securing front cover	8	8	8	doz.	1	3
X105/4	Spring washer for ditto	8	8	8	doz.		8
P105/11	Rear axle rear cover	1	1	1	7		9
P105/163	Joint for ditto	1	1	1			4
X105/7	Set screw for ditto	8	8	8			3
X105/4	Spring washer for ditto	8	8	8	doz.		8
P105/117	Oil filler plug	1	1	1			1
X105/9	Fibre washer for ditto	1	1	1	doz.	1	0
MG470/106	Rear axle shaft	2	2	2			19
P238/104	Rear hub (L.H.)	1	1	1			14
P238/103	" " (R.H.)	1	1	1			14
P101/8	Brake anchor bracket	2	2	2			5
P101/132	Bush for brake cam and fulcrum pin	4	4	4			2
X105/8	Bolt for brake anchor bracket (top) (1 $\frac{1}{8}$ " long)	4	4	4			3
X234/2	Ditto (bottom) (1 $\frac{1}{8}$ " long)	4	4	4			3
X101/10	Nut for ditto	8	8	8	doz.	1	3
X101/11	Washer for ditto	4	4	4	doz.		8
P101/120	Brake cam	2	2	2			8
P101/121	Washer for ditto (inner)	2	2	2	doz.		9
P101/122	" " (outer)	2	2	2	doz.		9
P101/124	Brake cam lever	2	2	2			4
S1/8	Stauffer greaser for ditto	2	2	2			9
X101/4	Key for brake cam	2	2	2			3
X101/5	Bolt for brake cam lever	2	2	2			3

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
X101/1	Nut for ditto	2	2	2	doz.	1	3
X101/2	Spring washer for ditto	2	2	2	doz.		8
P101/123	Fulcrum pin for brake-shoe	2	2	2		2	6
P101/133	Slotted nut for ditto	2	2	2			3
X101/3	Washer for ditto	2	2	2	doz.		6
MG374/2	Brake-shoe assembled with lining	4	4	4		12	3
P234/4	Brake-shoe	4	4	4		7	6
MG374/100	Brake-shoe lining	4	4	4		3	0
MG374/101	Rivets for ditto	32	32	32	doz.	5	
574	Vibration damper weight	4	4	4		2	0
576	Clevis pin for ditto	8	8	8			3
575	Spring for ditto	8	8	8			3
X101/12	Washer for ditto	16	16	16	doz.	8	
P101/129	Brake-shoe spring	4	4	4			4
P238/8	Rear hub bearing housing with studs	2	2	2		11	6
P275/105	Joint for rear hub bearing housing	2	2	2			3
P238/105	Rear wheel studs	12	12	12			9
X234/1	Nuts for ditto	12	12	12	doz.	10	
X101/11	Spring washer for ditto	12	12	12	doz.	8	
P238/111	Oil retaining felt for rear hub						
	Ceased at Axle No. 72/1500	2	2	2		1	2
P238/114	Retaining ring for ditto						
	Ceased at Axle No. 72/1500	2	2	2			3
P238/124	Oil retaining felt for rear hub						
	Comm. at Axle No. 117/1	2	2	2			3
P238/125	Retaining ring for ditto						
	Comm. at Axle No. 117/1	2	2	2			3
P105/112	Rear hub ball bearing	2	2	2		16	0
P105/113	Locking washer for ditto	2	2	2			3
P105/158	Rear hub bearing nut (R.H.)	1	1	1		1	10
P105/159	" " " (L.H.)		1	1		1	10
P234/1	Brake-drum		2	2	1	5	5
1364	Spring pad and steady bracket	2	2	2		7	0
S1/5	Grease nipple for rear hub	2	2	2			3
P237	Rear springs complete O/S and N/S	2	2	2		18	0
P237/100	Rear spring top leaf	2	2	2		4	6
P237/101	Rear spring 2nd leaf	2	2	2		5	0
P237/102	Rear spring 3rd leaf	2	2	2		7	6
P237/103	Rear spring 4th leaf	2	2	2		4	3
P237/104	Rear spring 5th leaf	2	2	2		4	3
P237/105	Rear spring 6th leaf	2		2		3	11
P237/106	Rear spring 7th leaf	2		2		3	8
P237/107	Rear spring 8th leaf	2	2	2		3	4
P237/108	Rear spring 9th leaf	2	2	2		3	2
936	Rear shock absorber bracket on springs O/S	1	1	1		4	2
1738	" " " " " " N/S	1	1	1		4	2
1054	Rear spring top plate	2	2	2		2	4
812	Rear spring "U" clip	4	4	4			11
810	Radius washer for rear spring front suspension						
	pin	2	2	2			6
809	Outer washer for ditto	2	2	2			6
818	Dust excluder for rear spring	2	2	2		1	2
1927	Rear axle strap	2	2	2			8
816	Rubber block for ditto	2	2	2		1	0
882	Brake cable stop bracket (rear end)	2	2	2			4
A297	Propeller shaft	1	1	1	4	8	0
811	Propeller shaft flange bolts	12	12	12			4
S1/6	Greaser for propeller shaft	2	2	2			3
POWER UNIT AND INSTALLATION							
MG363	Power unit complete with gearbox and remote control	1	1	1	Price on application		
CYLINDER BLOCK							
MG363/9	Cylinder block (studded) with cover-plates	1	1	1	6	2	0
X110/38	Core disc	2	2	2			4
P110/103	Cylinder jacket cover-plate	2	2	2		1	1
P110/104	Joint for ditto	2	2	2		2	8
X110/4	Set screw for ditto	28	28	28			3
X110/5	Washer for ditto	28	28	28	doz.	4	
X363/36	Stud for cylinder head (4 $\frac{3}{8}$ " long)	7	7	7			5
X363/2	" " " (4 $\frac{1}{2}$ " long)	1	1	1			5
X363/4	Locating studs for ditto (4 $\frac{15}{16}$ " long)	1	1	1		1	6
X363/37	" " " (4 $\frac{9}{16}$ " long)	1	1	1		1	6

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Sabon	£	s.	d.
X110/93	Dowel for locating front bearing housing ...	1	1	1	doz.	9	
X110/6	Stud for cylinder head oil drain pipe (rear)	2	2	2		3	
949	Stud for oil base ...	8	8	8		9	
P110/106	Union cock in crankcase for oil pressure gauge pipe ...	1	1	1		2	3
BELL HOUSING AND REAR MAIN BEARING							
P239/9	Bell housing with rear main bearing ...	1	1	1	2	11	8
P110/110	Rear main bearing (bush) ...	1	1	1	10	6	
X110/13	Grub screw for ditto ...	1	1	1		2	
X110/2	Set screw for ditto (bell housing to block) ...	6	6	6		3	
X105/4	Spring washer for ditto ...	6	6	6	doz.	8	
P110/314	Joint for ditto ...	1	1	1		4	
P110/109	Starter pinion inspection plug ...	1	1	1	1	6	
FRONT MAIN BEARING HOUSING AND ENGINE NOSE PIECE							
P239/102	Front bearing housing ...	1	1	1	1	9	3
P239/107	Front main bearing (double row ball) ...	1	1	1	2	0	0
P110/317	Joint for front bearing housing ...	1	1	1		4	
X110/2	Set screw for ditto (housing to cylinder block) ...	6	6	6		3	
X105/4	Spring washer for ditto ...	6	6	6	doz.	8	
X105/14	Set screw for ditto (housing to cylinder block) ...	2	2	2		3	
X101/2	Spring washer for ditto ...	2	2	2	doz.	8	
P110/107	Retainer plate for front bearing ...	1	1	1		1	3
P110/134	Lock plate for ditto ...	2	2	2		2	3
X110/26	Set screw for ditto ...	4	4	4		3	
P239/8	Engine nose piece and front bearing housing cover ...	1	1	1	1	7	2
MG363/21	Ditto Comm. at Engine No. 2501	1	1	1	1	16	6
X110/11	Set screw for ditto (front cover to bearing housing) ...	4	4	4		3	
X110/34	Ditto Comm. at Engine No. 2501	4	4	4		3	
X105/4	Spring washer for ditto ...	4	4	4	doz.	8	
P110/273	Shim for front cover (.003") ...	as required				4	
P110/274	" " " " (.005") ...	as required				4	
P110/275	" " " " (.007") ...	as required				4	
MG363/207	" " " " (.015") ...	as required				5	
P239/115	Bolt for ditto (engine nose piece to front cover) ...	4	4	4		5	
X110/41	Nut for ditto ...	4	4	4		3	
828	Rubber bush for engine mounting (halves)	2	2	2		4	
CRANKSHAFT AND FLYWHEEL							
P110/29	Crankshaft ...	1	1	1	2	11	8
X110/29	Plug for crank pin ...	3	3	3		11	
X110/8	Crankshaft key (distributor and dynamo drive gear) ...	2	2	2		3	
P110/142	Crankshaft flange ...	1	1	1	1	0	4
P110/135	Nut for ditto ...	1	1	1		2	8
P110/136	Lock wire for ditto ...	1	1	1		3	
X110/24	Key for ditto ...	1	1	1		6	
P110/263	Thrust washer for crankshaft location (steel) ...	1	1	1		2	2
P110/266	Ditto (phosphor bronze) ...	1	1	1		2	5
P110/262	Oil pump spiral gear (driven) ...	1	1	1	10	10	
P110/261	Oil retaining flange ...	1	1	1		9	3
P110/264	Fan pulley distance piece ...	1	1	1		2	3
MG464/100	Thrust bearing sleeve Comm. at Engine No. 2501	1	1	1		13	6
X464/1	Crankshaft thrust bearing Comm. at Engine No. 2501	1	1	1		7	9
MG464/102	Thrust bearing sleeve Comm. at Engine No. 2501	1	1	1		14	6
P110/265	Starting dog nut ...	1	1	1		2	4
MG464/103	Ditto Comm. at Engine No. 2501	1	1	1		2	4
P239/108	Flywheel ...	1	1	1	1	17	9
P110/141	Bolt for ditto ...	4	4	4		1	0
X105/3	Nut for ditto ...	4	4	4	doz.	1	3
X105/4	Washer ...	4	4	4	doz.	8	

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	MG	DESCRIPTION	MG	No. Used			Price Each		
				2-seater	4-seater	Saloon	£	s.	d.
P110/440		Oil retainer for first motion shaft spigot bearing		1	1	1			4
X110/28		Spigot bearing for first motion shaft		1	1	1	8	9	
X287/21		Lock wire for ditto		1	1	1			3
CONNECTING RODS AND PISTONS									
P239/4		Connecting rod with cap and bolts							
		Ceased at Engine No. 1674		4	4	4	19	6	
MG363/20		Ditto ... Comm. at Engine No. 1675		4	4	4	1	5	0
MG363/205		Connecting rod bush (small end)							
		Comm. at Engine No. 1675		4	4	4	1	2	
P110/493		Connecting rod bolt		8	8	8	1	8	
X110/22		Nut for ditto		8	8	8			3
P110/127		Piston Ceased at Engine No. 1674		4	4	4	10	10	
P110/128		Compression ring							
		Ceased at Engine No. 1674		8	8	8	1	3	
P110/129		Scraper ring		4	4	4	1	4	
		Ceased at Engine No. 1674		4	4	4	1	9	
P239/141		Gudgeon pin		4	4	4	1	9	
		Ceased at Engine No. 1674		4	4	4	1	9	
P239/106		Set screw for ditto	Always quote size when ordering	4	4	4			4
		Ceased at Engine No. 1674		4	4	4			4
X181/2		Spring washer for ditto		4	4	4	doz.		8
		Ceased at Engine No. 1674		4	4	4	doz.		8
MG363/4		Piston complete with rings and gudgeons		4	4	4	1	0	0
		Comm. at Eng. No. 1675		4	4	4	1	0	0
MG363/211		Piston ring (compression)		8	8	8	1	3	
		Comm. at Engine No. 1675		8	8	8	1	3	
MG363/212		Ditto (scraper)		4	4	4	1	4	
		Comm. at Engine No. 1675		4	4	4	1	4	
MG363/202		Gudgeon pin with pads		4	4	4	2	4	
		Comm. at Engine No. 1675		4	4	4	2	4	
CYLINDER HEAD AND VALVE GEAR									
MG363/12		Cylinder head assembly less manifolds and sparking plugs		1	1	1	14	1	8
MG363/13		Cylinder head (studded) with valve guides		1	1	1	5	0	0
X110/38		Core disc for cylinder head		2	2	2			4
MG363/196		Valve guides		8	8	8	2	3	
X110/6		Stud for camshaft front bearing		2	2	2			3
X363/7		Stud for camshaft rear bearing		2	2	2			2
X363/9		Stud for induction manifold (1" long)		3	3	3	doz.	1	6
X363/6		" " " (2 3/4" long)		2	2	2			3
X363/8		Stud for exhaust manifold (1 3/8" long)		3	3	3	doz.	1	6
X287/5		" " " (1 1/16" long)		2	2	2	doz.	1	6
X363/6		Stud for water outlet pipe		3	3	3			3
X110/6		Stud for oil drain housing		2	2	2			3
X110/6		Stud for oil drain flange (front)		2	2	2			3
X110/45		Stud for cylinder head oil drain pipe (rear)		2	2	2			3
MG363/101		Nut for cylinder head stud		10	10	10			2
MG363/192		Inlet valve		4	4	4	3	0	
MG363/191		Exhaust valve		4	4	4	3	0	
1015		Valve spring (inner)		8	8	8			5
1016		" " (outer)		8	8	8			8
1017		Valve spring collar		8	8	8	1	0	
P110/184		Split cotters for valve (halves)		16	16	16	pair	1	0
992		Valve rocker		8	8	8	7	2	
997		Locking screw for ditto		8	8	8			2
998		Tab washer for ditto		8	8	8			4
MG363/106		Eccentric bush for valve rocker		8	8	8	3	4	
X363/11		Spring ring for ditto		8	8	8	doz.		9
MG363/15		Rocker-shaft O/S		1	1	1	3	9	
MG363/14		" N/S		1	1	1	3	9	
MG363/213		Rocker-shaft tie brackets		2	2	2	1	3	
MG363/109		Distance piece for rocker-shaft (1 1/16" long)		6	6	6			3
MG363/110		" " " (1" long)		2	2	2			3
MG363/111		" " " (1 1/16" long)		2	2	2			4
MG363/112		Belleville washer for ditto		8	8	8	doz.	1	0
996		Rear end support bracket for rocker-shaft		1	1	1	8	3	
MG363/115		Lock screw for ditto		2	2	2			2
MG363/105		Camshaft		1	1	1	1	3	10
X110/41		Slotted nut for ditto		1	1	1			3
X110/31		Washer for ditto		1	1	1	doz.		6
X101/4		Key for ditto		1	1	1			3

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	DESCRIPTION				Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
P264/1	Camshaft front bearing housing with cap ...	1	1	1	1	3	10
X110/49	Dowel for ditto ...	2	2	2	doz.		8
X110/46	Stud for ditto ...	2	2	2			3
X101/1	Nut for ditto ...	2	2	2	doz.	1	3
X101/2	Washer for ditto ...	2	2	2	doz.		8
P110/223	Camshaft front bearing bush (top) ...	2	2	2		1	0
P110/224	" " " (front bottom) ...	1	1	1		1	0
P110/225	" " " (rear bottom) ...	1	1	1		1	0
X101/1	Nut for securing front bearing housing ...	2	2	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	2	2	doz.		8
MG363/5	Camshaft rear bearing housing with cap ...	1	1	1		18	0
MG363/118	Plug for ditto ...	1	1	1	doz.	1	3
X110/48	Copper washer for ditto ...	1	1	1	doz.		3
X110/49	Dowel for ditto ...	2	2	2	doz.		8
X363/12	Stud for ditto ...	2	2	2			2
X101/1	Nut for ditto ...	2	2	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	2	2	doz.		8
P110/221	Camshaft rear bearing bush (bottom) ...	1	1	1		1	9
P110/222	" " " (top) ...	1	1	1		1	3
X101/1	Nut for securing front bearing housing ...	2	2	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	2	2	doz.		8
P110/7	Camshaft vertical drive bevel wheels ...	1 pr.	1 pr.	1 pr.	pair	1	16 5
P110/171	Thrust washer for camshaft ...	2	2	2			11
P110/172	Belleville washer for ditto ...	2	2	2			4
P110/202	Washer for camshaft ...	1	1	1		1	0
P110/210	Thrust washer for ditto (.172" thick) for vertical drive pinion ...	as required					7
P110/211	Ditto (.178" thick) for vertical drive pinion ...	as required					7
P110/194	Sleeve for vertical drive pinion ...	1	1	1		9	0
X110/44	Roller bearing for ditto ...	2	2	2		5	10
P110/43	Bearing retainer plate with felt ...	1	1	1		3	4
X110/98	Felt washer for ditto ...	1	1	1			3
P110/196	Oil thrower for camshaft drive driving pinion ...	1	1	1			7
P110/200	Oil drain housing for camshaft drive driving pinion ...	1	1	1		7	4
X101/1	Nut for ditto ...	2	2	2	doz.	1	3
X101/2	Washer for ditto ...	2	2	2	doz.		8
P110/204	Shims for vertical drive (.003" thick) ...	as required					3
P110/205	" " " (.005" thick) ...	as required					3
P110/206	" " " (.007" thick) ...	as required					3
P110/207	" " " (.010" thick) ...	as required					5
P110/208	" " " (.015" thick) ...	as required					5
P110/209	" " " (.020" thick) ...	as required					8
P110/197	Universal joint fork for vertical drive ...	1	1	1		4	9
X110/43	Key for ditto ...	1	1	1			3
P110/198	Nut for ditto ...	1	1	1			7
P110/199	Copper washer for ditto ...	1	1	1	doz.		8
MG363/197	Cylinder head gasket ...	1	1	1		4	8
P110/49	Strap for cylinder head cover fixing with nut and clip ...	2	2	2		2	8
X239/4	Copper packing washer for ditto ...	2	2	2	doz.		6
P239/118	Cylinder head cover ...	1	1	1		1	14 4
MG363/128	Plug for ditto ...	1	1	1			6
X363/16	Washer for plug ...	1	1	1	doz.	1	4
P110/26	Screw with head for securing cylinder head cover ...	2	2	2		3	0
P110/313	Joint for cylinder head cover ...	1	1	1		2	0

INDUCTION MANIFOLD, CARBURETTORS AND EXHAUST MANIFOLD

MG363/27	Induction manifold (studded) ...	1	1	1		1	5 10
X110/6	Stud for carburetter flange ...	4	4	4			3
MG363/130	Joint for induction manifold ...	1	1	1		2	0
X363/10	Nut for securing induction manifold (small) ...	3	3	3			2
X287/11	" " " (large) ...	2	2	2			4
X110/37	Washer for ditto ...	5	5	5	doz.		8
MG363/194	Plug for induction manifold ...	1	1	1		1	6
X363/35	Washer for ditto ...	1	1	1	doz.		10
MG363/195	Taper plug for balance plug (not used with suction windscreen wiper) ...	1	1	1			3
A433	Carburetter complete with links ...	1 pr.	1 pr.	1 pr.	pair	7	0 0
X363/18	Joint for carburetter ...	2	2	2			2
X363/15	Nut for securing carburetter ...	4	4	4	doz.	1	3
X105/4	Spring washer for ditto ...	4	4	4	doz.		8

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	MG	DESCRIPTION	MG	No. Used			Price Each		
				2-seater	4-seater	Saloon	£	s.	d.
P110/157		Cap for relief valve		1	1	1	2	6	
X110/95		Set screw for securing oil pump		3	3	3		3	
X101/2		Spring washer for ditto		3	3	3	doz.	8	
P239/5		Main oil feed pipe		1	1	1	3	8	
N239/2		Union for ditto... ..		1	1	1		10	
P239/119		Joint for ditto (lead)		1	1	1		5	
P110/173		Oil restrictor pin (cylinder head)		1	1	1	1	6	
X110/39		Set screw for securing oil feed pipe		1	1	1		3	
X110/40		Fibre washer for ditto		1	1	1	doz.	4	
P110/20		Cylinder head oil drain pipe (front)		1	1	1	10	5	
X287/20		Joint for ditto (top)		1	1	1		1	
X110/58		" " (bottom)		1	1	1	doz.	1	0
X101/1		Nut for ditto (top)		2	2	2	doz.	1	3
X101/2		Spring washer for ditto (top)		2	2	2	doz.	8	
X110/3		Set screw for ditto (bottom)... ..		2	2	2		3	
X101/2		Spring washer for ditto (bottom)		2	2	2	doz.	8	
MG363/16		Cylinder head oil drain pipe (rear)		1	1	1	10	10	
X110/58		Joint for ditto		2	2	2	doz.	1	0
X101/1		Nuts for securing ditto		4	4	4	doz.	1	3
X101/2		Spring washer for ditto		4	4	4	doz.	8	
P110/443		Banjo union for bell housing (main bearing oil feed)		1	1	1		1	0
P110/479		Lock plate for ditto		1	1	1		4	
X110/7		Washer for ditto		1	1	1	doz.	1	8
ELECTRICAL DETAILS									
A478		Starter motor		1	1	1	5	5	0
X110/10		Set screw for securing ditto		2	2	2		3	
X110/12		Bolt for ditto		1	1	1		3	
X101/10		Nut for ditto		1	1	1	doz.	1	3
X101/11		Spring washer for ditto		3	3	3		3	
P110/111		Starter packing piece		1	1	1		1	9
A577		Distributor ... Ceased at Engine No. 750 (manual)		1	1	1	1	5	6
A362		Ditto							
		Comm. at Engine No. 751 (automatic advance)		1	1	1	1	10	6
P110/288		Securing screw for ditto		1	1	1		3	
CLUTCH DETAILS									
P239/132		Clutch driving studs (in flywheel)		6	6	6		3	
P239/131		Clutch springs		6	6	6		5	
P239/13		Clutch pressure plate with lining and thrust buttons		1	1	1	15	3	
P239/125		Clutch lining		1	1	1	4	8	
X110/65		Rivets for ditto		6	6	6	doz.	4	
P110/472		Thrust buttons for ditto		3	3	3		4	
P239/11		Clutch centre plate assembly		1	1	1	11	10	
MG363/30		Clutch cover-plate (bushed) with lining		1	1	1	3	0	6
MG363/215		Bush for clutch operating pin		3	3	3		4	
P239/125		Lining for clutch cover		1	1	1	4	8	
X110/66		Rivets for ditto		6	6	6	doz.	4	
P110/324		Clutch operating pin		3	3	3		4	
P239/124		Clutch finger lever		3	3	3	3	6	
P110/334		Clutch lever pin Ceased at Engine No. 2500		3	3	3		4	
MG363/216		" " " Comm. at Engine No. 2501		3	3	3		4	
X110/61		Felt washers for clutch lever		6	6	6	doz.	1	2
X110/62		Brass washers for ditto		12	12	12	doz.	5	
P239/126		Clutch lever adjusting screw		3	3	3	doz.	2	0
X101/1		Lock nut for ditto		3	3	3	doz.	1	3
P239/130		Clutch lever spring retaining clip		3	3	3		3	
X239/9		Set screw for ditto		6	6	6		1	
X110/64		Spring washer for ditto		6	6	6	doz.	8	
X110/30		Set screw for securing clutch cover to flywheel		6	6	6		3	
X105/4		Spring washer for ditto		6	6	6	doz.	8	
P110/338		Clutch thrust bearing		1	1	1	13	0	
P110/500		Cover for ditto		1	1	1	1	0	
P110/481		Clutch operating sleeve		1	1	1		4	10
P110/339		Clutch operating shaft... ..		1	1	1	10	10	
P239/139		Clutch pedal		1	1	1	5	4	
P110/422		Cotter pin for ditto with nut and spring washer		1	1	1		5	
1144		Clutch pedal return spring		1	1	1		5	
1145		Anchor bracket for ditto		1	1	1		3	
1286		Clutch pedal stop stud		1	1	1		4	
1388		Nut for ditto		1	1	1		4	

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
GEARBOX AND DETAILS WITH REMOTE CONTROL							
MG363/3	Gearbox assembly complete, less clutch pedal withdrawal and inspection cover ...	1	1	1	21	0	0
MG363/29	Clutch pit (studded) ...	1	1	1	1	2	8
X363/22	Stud for securing gearbox to ditto ...	6	6	6	doz.	1	6
X110/11	Set screw for securing clutch pit to bell housing ...	3	3	3			3
X110/9	Bolts for ditto ...	5	5	5			4
X105/3	Nuts for ditto ...	5	5	5	doz.	1	3
X105/4	Spring washers for ditto ...	8	8	8	doz.		8
P110/348	Bush for clutch operating shaft O/S ...	1	1	1		3	5
P110/349	" " " " N/S ...	1	1	1		1	6
X110/70	Disc for ditto ...	1	1	1	doz.		8
X110/71	Locking screw for ditto ...	2	2	2			3
X101/2	Spring washer for ditto ...	2	2	2	doz.		8
2332	Clutch inspection cover ...	1	1	1		1	4
X110/60	Set screw for ditto ...	2	2	2			3
X287/17	Washer for ditto ...	2	2	2	doz.		8
MG363/18	Gearbox case (studded) ...	1	1	1	1	6	0
X110/93	Dowel for locating front end ...	2	2	2	doz.		9
X363/12	Stud for top cover ...	4	4	4			2
X363/19	Stud for rear cover (2 3/8" long) ...	1	1	1			3
X363/20	" " " " (1 5/8" long) ...	5	5	5			3
X363/21	" " " " (1 3/8" long) ...	1	1	1			3
X110/93	Dowel for rear cover ...	2	2	2	doz.		9
P110/109	Oil filler and drain plug ...	2	2	2		1	6
X110/67	Fibre washer for ditto ...	2	2	2	doz.		10
X105/3	Nut for securing gearbox case to clutch pit	6	6	6	doz.	1	3
X105/4	Spring washer for ditto ...	6	6	6	doz.		8
MG363/143	First motion shaft ...	1	1	1		1	3
X110/76	Shim for ditto (.003" thick) ...	as required					4
X110/77	" " " (.005" thick) ...	as required					4
X110/78	" " " (.007" thick) ...	as required					4
X239/8	" " " (.010" thick) ...	as required					4
P239/133	" " " (.015" thick) ...	as required					5
P110/366	Oil thrower for ditto (rear) ...	1	1	1			4
X110/85	Ball race for ditto ...	1	1	1		8	9
P110/365	Oil thrower for ditto (front) ...	1	1	1			4
MG363/137	Locking nut for ditto (combined oil return)	1	1	1		3	2
X110/74	Circlip for ditto ...	1	1	1			3
MG363/165	Retaining plate for cover securing bolts ...	1	1	1			5
X363/27	Bolts for first motion shaft cover ...	4	4	4			3
X101/1	Nut for ditto ...	4	4	4	doz.	1	3
X101/2	Spring washer for ditto ...	4	4	4	doz.		8
X110/75	Sealing washer for cover ...	1	1	1			6
MG363/164	Cover for first motion shaft ...	1	1	1		3	4
MG363/140	Mainshaft ...	1	1	1		13	4
X363/23	Roller bearing spigot ...	1	1	1		4	9
MG363/138	Distance washer for ditto ...	1	1	1		1	3
MG363/145	3rd and top speed sliding gear ...	1	1	1		16	10
MG363/146	1st and 2nd speed sliding gear ...	1	1	1		18	4
X110/86	Ball race (mainshaft rear) ...	1	1	1		11	6
MG363/179	Retaining plate for ditto ...	1	1	1			6
X112/1	Bolt for ditto ...	2	2	2			3
X105/3	Nut for ditto ...	2	2	2	doz.	1	3
X105/7	Set screw for ditto ...	1	1	1			3
X105/4	Spring washer for ditto ...	3	3	3	doz.		8
P110/410	Speedometer driving gear ...	1	1	1		4	2
P110/411	Speedometer driven gear ...	1	1	1		4	10
P110/389	Thrust button for ditto ...	1	1	1			1
P110/409	Bearing for ditto ...	1	1	1		8	9
X110/80	Joint for ditto ...	1	1	1			4
MG363/177	Rear cover (gearbox) ...	1	1	1		18	4
MG363/178	Plug for ditto ...	1	1	1			3
X105/3	Nuts for securing ditto ...	7	7	7	doz.	1	3
X105/4	Spring washers for ditto ...	7	7	7	doz.		8
MG363/139	Propeller shaft flange ...	1	1	1		9	4
X105/12	Nut for ditto ...	1	1	1			3
X105/13	Washer for ditto ...	1	1	1			3
MG363/141	Layshaft ...	1	1	1		5	0
X363/23	Roller bearing for layshaft ...	2	2	2		4	9
MG363/138	Distance washer for ditto ...	4	4	4		1	3
MG363/144	Constant mesh gear ...	1	1	1		14	8
MG363/152	Spring retaining ring for ditto ...	2	2	2	doz.	1	8

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.		DESCRIPTION		No. Used			Price Each		
				2-seater	4-seater	Saloon	£	s.	d.
MG363/147		3rd speed constant mesh gear		1	1	1	19	6	
MG363/148		Roller for ditto...		23	23	23		2	
MG363/149		Washer for rollers		2	2	2		3	
MG363/150		Spring retaining ring for ditto		1	1	1	doz.	1	4
MG363/151		Layshaft gear		1	1	1	1	8	2
P110/362		Locking screw for layshaft		1	1	1		2	
X101/2		Spring washer for ditto		1	1	1	doz.	8	
MG489/203		Reverse shaft		1	1	1		2	9
MG363/24		Reverse gear (bushed)...		1	1	1	13	2	
MG363/154		Bush for ditto		1	1	1		2	3
X101/10		Nut for reverse shaft		1	1	1	doz.	1	3
X363/24		Spring washer for ditto		1	1	1	doz.	8	
MG363/166		1st and 2nd change speed rod		1	1	1	3	10	
MG363/170		1st and 2nd change speed fork		1	1	1	6	0	
MG363/168		Distance piece for ditto (rear)		1	1	1		3	
MG363/169		" " " " (front)		1	1	1		4	
MG363/167		3rd and 4th gear change speed rod		1	1	1	3	9	
MG363/171		3rd and 4th gear change speed fork		1	1	1	6	0	
X110/84		Ball for change speed forks		2	2	2	doz.	1	6
X363/28		Spring for ditto		2	2	2		3	
MG489/212		Selector lever (reverse)		1	1	1	5	8	
MG363/156		Fulcrum pin for ditto		1	1	1		8	
X101/5		Nut for ditto		1	1	1	doz.	1	3
X101/11		Spring washer for ditto		1	1	1	doz.	8	
MG363/160		Socket for reverse locking plunger		1	1	1	2	0	
X363/25		Nut for ditto		1	1	1		2	
X363/26		Spring washer for ditto		1	1	1	doz.	8	
MG363/161		Plug for socket		1	1	1		3	
MG363/162		Reverse locking plunger		1	1	1		10	
MG363/163		Spring for ditto		1	1	1		11	
MG363/159		Selector shaft reverse		1	1	1	1	6	
MG363/157		Selector fork reverse		1	1	1	1	8	
MG363/158		Distance piece for ditto		1	1	1		3	
MG363/8		Change speed lock assembly		1	1	1	3	0	
GEAR LEVER REMOTE CONTROL DETAILS									
MG363/19		Gearbox remote control assembly complete		1	1	1	3	5	0
MG363/31		Change speed housing		1	1	1	1	19	2
X110/38		Core plug for ditto		2	2	2		4	
P287/133		Greaser (front)		1	1	1		5	
MG363/181		" (rear)		1	1	1		4	
P110/404		Locating peg for change speed lever		1	1	1	doz.	2	
MG363/183		Change speed gate		1	1	1	4	6	
MG363/198		Shim for ditto	as required				doz.	1	2
X105/14		Bolt for ditto		3	3	3		3	
X101/2		Spring washer for ditto		3	3	3	doz.	8	
MG489/186		Change speed lever		1	1	1	7	2	
MG408/114		Knob for ditto		1	1	1	2	0	
X363/30		Lock nut for ditto		1	1	1		2	
2747		Anti-rattle spring for ditto		1	1	1		5	
MG363/189		Shaft actuating lever		1	1	1	4	6	
X363/34		Set screw for ditto		1	1	1		3	
X101/2		Spring washer for ditto		1	1	1	doz.	8	
MG363/23		Change speed shaft		1	1	1	7	6	
MG489/213		Selector lever		1	1	1	5	4	
X101/4		Key for ditto		1	1	1		3	
X363/31		Nut for ditto		1	1	1		3	
X363/32		Washer for ditto		1	1	1	doz.	4	
MG363/182		Tray for change speed housing		1	1	1	1	6	
X110/82		Screw for ditto		2	2	2	doz.	7	
X101/1		Nut for securing remote control to gearbox		4	4	4	doz.	1	3
X101/2		Spring washer for ditto		4	4	4	doz.	8	
REAR ENGINE MOUNTING									
795		Rear engine bearer brackets		2	2	2	2	9	
1378		Rear engine support washer (thick)		2	2	2		9	
1377		Rear engine bearer distance piece		2	2	2		4	
1375		Fibre washer for engine mounting		2	2	2		2	
130		Washer for engine mounting (thin)		2	2	2	doz.	1	6
129		Bolt seats (rubber)		2	2	2		5	
BRAKE GEAR									
P239/140		Brake pedal		1	1	1	5	4	
1007		Brake pedal fulcrum pin		1	1	1		9	
1365		Brake pedal roller		23	23	23	set	1	9

Please Quote Chassis, Engine and Body Numbers when ordering Parts

12

1-7-6.

13

Part No.	DESCRIPTION			2-seater	4-seater	Saloon	Price Each		
							£	s.	d.
PETROL TANK AND PIPES									
MG422	Petrol tank with tap (less cap) (unpainted) ...			1	—	—	2	15	4
1115	Petrol tank (less cap) (unpainted) ...			—	1	—	2	2	8
1251	" " (less cap) (unpainted) ...			—	—	1	2	2	8
1911	Petrol tap ...			1	—	—		6	8
1903	Petrol tank cap ...			1	—	—	12	4	2
1464	" " " " " " ...			—	1	1	4	2	7
1410	Dipstick for petrol tank ...			—	1	—	2	7	7
1409	" " " " " " ...			—	—	1		2	7
S23/2	Rubber packing for tank (on body) (68" long) (cut into 3 lengths to suit) ...			1	—	—	foot 1	2	10
1402	Petrol tank strap ...			—	2	—			10
1859	Petrol pipe (tank to main) ...			1	—	—	2	3	0
1196	" " (tank to reserve) ...			—	1	1	2	3	0
1197	" " (tank to main) ...			—	1	1	2	6	0
S3/2	¾" gas cone to ¼" gas cone union adaptor ...			1	2	2			6
1198	Main petrol pipe ...			1	1	1	3	4	0
1199	Reserve petrol pipe ...			—	1	1	3	4	0
S3/2	¾" gas cone to ¼" gas cone union adaptor ...			1	—	—			6
1200	Petrol tap ...			—	1	1	6	1	0
1859	Petrol pipe, tap or main pipe to Petrolift Ceased 2-Seater at Chassis No. J3433			1	1	1	2	3	0
2774	Petrol pipe, main to petrol pump Comm. Chassis No. J3434			1	—	—		2	1
A242	Petrolift Ceased 2-Seater at Chassis No. J3433			1	1	1	2	10	0
A444	Petrol pump ... Comm. Chassis No. J3434			1	—	—	2	10	0
1860	Petrol pipe (Petrolift to carburetter) Ceased 2-Seater at Chassis No. J3433			1	1	1	3	0	0
2773	Ditto (petrol pump to carburetter) Comm. Chassis No. J3434			1	—	—		5	4
A481	Petrol pipe connection for ditto Comm. Chassis No. J3591			1	—	—		1	5
S2/19	Petrol pipe and Tecalemit clip (double-ended)			—	2	2			4
S2/23	Petrol pipe clip (double-ended) ...			—	1	1			7
S2/30	" " " (for 1 pipe) (⅞" dia. fixing hole) ...			1	2	2			4
S2/16	" " " (for 2 pipes) ...			—	2	2			3
S2/29	Petrol pipe and Tecalemit clip (single end)			3	—	—			4
S2/32	Petrol pipe clip (single) (⅜" dia. fixing hole)			3	—	—			4
S2/11	Ditto (single) (¼" dia. fixing hole) ...			2	—	—			3
1415	Distance piece for petrol pipe clip (rear) ...			1	1	1			2
ACCESSORIES AND SUNDRIES									
A294	Wheel (2.50W.B. x 19") (unpainted) ...			5	5	5	2	2	0
1123	Hub cap O/S ...			2	2	2		9	7
1756	" " N/S ...			2	2	2		9	7
1914	Instruction plate for foot brake adjustment			1	—	—			6
1219	Instruction plate for foot brake adjustment and petrol tap ...			—	1	1			10
P277/1	Shock absorbers (front) ...			—	1 pr.	1 pr.	pair 3	19	6
MG371/1	" " (front) ...			1 pr.	—	—	pair 5	16	0
A590	Front shock absorber less pins ...			1 pr.	1 pr.	1 pr.	pair 5	11	0
P277/100	Pin for ditto (top) ...			—	2	2		2	0
MG371/100	" " " (top) ...			2	—	—		2	0
P277/102	" " " (bottom) ...			2	2	2		2	0
P277/103	Castle nut for ditto ...			4	4	4			3
P277/3	Shock absorbers (rear) ...			1 pr.	1 pr.	1 pr.	pair 4	7	6
A591	Rear shock absorber less pins ...			1 pr.	1 pr.	1 pr.	pair 4	2	6
P277/102	Pin for ditto ...			2	2	2		2	0
P277/103	Castle nut for ditto ...			2	2	2			3
MG371/101	Rear shock absorber arm (bushed) ...			1	1	1		5	0
1229	Rear shock absorber tie bar ...			1	1	1		2	2
178	Front number-plate ...			1	1	1		2	4
1124	Rear number-plate ...			1	1	1		2	4
1456	Rear number-plate bracket ...			—	—	2		1	0
B200/136	Rear number-plate bar ...			—	1	—		3	0
A289	Licence holder ...			1	1	1		4	0
1480	Clip for starting handle ...			3	—	—			2
2955	Clip for tyre pump ...			2	—	—			4
2012	Strap for lifting jack ...			1	—	—		1	6
1946	Spare sparking plug carrier ...			1	1	1		5	0

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.		DESCRIPTION	MG			Price Each		
			2-seater	4-seater	Saloon	£	s.	d.
P359	Grouped lubricating system		1	1	1	2	0	2
P167/133	Pipe (1' 5" long) (steering box and front spring sliding trunnion)		1	1	1	1	6	
P278/102	" (1' 8½" long) (grouped nipples and front spring sliding trunnions)		2	2	2	2	0	
P359/100	" (2' 1½" long) (grouped nipples and front brake cables)		2	2	2	2	2	
P278/104	" (2' 11½" long) (grouped nipples and brake cross shaft)		2	2	2	2	9	
P359/101	" (4' 5" long) (grouped nipples and rear brake cables)		2	2	2	3	6	
P167/138	" (2' 7" long) (brake cross shaft and rear spring front shackles)		2	2	2	2	3	
P278/117	" (5' 9" long) (brake cross shaft and rear spring sliding trunnions)		2	2	2	4	3	
S1/4	Greasier nipple (front spring front shackles, steering knuckles, track rod and draglink ends)		10	10	10			8
P278/109	Adjustable feed plug (steering box, rear spring front shackles, front spring rear shackle N/S)		4	4	4	1	3	
P278/110	Ditto (front spring rear shackle O/S)		1	1	1	1	6	
P359/103	Open feed plug (brake cable stop brackets and rear spring rear shackles)		6	6	6	1	0	
P278/118	Adjustable feed plug (brake cross shaft)		2	2	2	1	9	
P113/110	Fibre washers (thick)		13	13	13	doz.	1	0
P113/111	" (thin)		38	38	38	doz.	6	6
P113/109	Clip for 1 pipe		4	4	4	doz.	6	7
P278/111	Clip for 2 pipes		2	2	2	doz.	1	7
P278/119	Support for 3 pipes		1	1	1		4	4
MG369/106	Support for 4 pipes		2	2	2		6	
P359/1	Zerk battery plate fitting (1-way) (grouped nipples)		4	4	4	1	3	
P359/2	Ditto (2-way) (grouped nipples)		2	2	2	1	5	
1220	Instruction plate for greasier nipples O/S		1	1	1	1	1	
1221	" " " " " N/S		1	1	1	1	1	
DASHBOARD AND FUME EXCLUDERS								
1121	Dashboard wall O/S		1	1	1	4	7	
1122	" " N/S		1	1	1	4	7	
130	Distance washer for ditto		2	2	2	doz.	1	6
1886	Dash panel		1	1	1	15	3	
1142	"		—	1	1	15	3	
978	Draught excluder rubber round dash panel (79" long)		1 lth.	1 lth.	1 lth.	3	8	
1869	Draught excluder block O/S		1	1	1	1	4	
1962	" " N/S		1	1	1	1	4	
1175	Clutch housing draught excluder plate		1	1	1	8	4	
978	Clutch housing draught excluder rubber (32" long)		1	1	1	1	6	
2003	Draught excluder for steering column (rubber)		1	1	1	3	7	
2070	Backing plate for ditto		1	1	1	7	7	
1176	Undertray ... Ceased Chassis No. J3580		1	—	—	9	1	
1965	Ditto Comm. on 2-Seater at Chassis No. J3581		1	1	1	10	2	
ELECTRICAL EQUIPMENT AND INSTRUMENTS								
A305	Instrument panel with ammeter	Ceased Chassis No. J3575	1	—	—	2	2	0
A485	Ditto (dome glass)	Comm. Chassis No. J3576	1	—	—	2	2	0
A246	Ditto		—	1	1	2	15	0
A634	Combined speedometer and revolution counter	Ceased Chassis No. J3575	1	—	—	6	16	0
A634/1	Cable for speedometer	" " "	1	—	—	15	0	
A491	Combined speedometer and revolution counter	Comm. Chassis No. J3576	1	—	—	6	13	0
2792	Mask for ditto (chrom. plated)	Comm. Chassis No. J3576	1	—	—	1	0	
A603	Speedometer		—	1	1	2	15	0
A603/1	Speedometer cable		—	1	1	13	0	
A459	Speedometer cable Comm. Chassis No. J3576		1	—	—	15	0	
A461	Speedometer reduction box	Comm. Chassis No. J3576	1	—	—	1	1	0

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each
					£ s. d.
2425	Headlamp mounting bracket O/S				
	Ceased Chassis No. J3330	1	—	—	6 0
2426	Ditto N/S ... Ceased Chassis No. J3330	1	—	—	6 0
1938	Headlamp tie bar (length to be cut to suit)	1	—	—	3 8
2444	Combined headlamp and wing stay bracket				
	O/S	1	—	—	16 8
2445	Ditto N/S	1	—	—	16 8
1940	Front wing rear stay O/S				
	Ceased Chassis No. J3437	1	—	—	8 6
1941	Ditto N/S ... Ceased Chassis No. J3437	1	—	—	8 6
1945	Bolt for front wing securing				
	Ceased Chassis No. J3437	4	—	—	10
318	Rubber packing for ditto				
	Ceased Chassis No. J3437	4	—	—	5
2803	Combined front wing stay and headlamp bracket O/S				
	Comm. Chassis No. J3591	1	—	—	16 0
2804	Ditto N/S ... Comm. Chassis No. J3591	1	—	—	16 0
2675	Rubber ferrule for front wing				
	Comm. Chassis No. J3438	2	—	—	1 1
1945	Bolt for front wing mounting				
	Comm. Chassis No. J3438	2	—	—	10
316	Rubber washer for ditto (internal) (domed)				
	Comm. Chassis No. J3438	2	—	—	4
1378	Distance washer for front wing bolt (steel)				
	Comm. Chassis No. J3591	2	—	—	9
2843	Distance washer for ditto (rubber) (internal, flat) ...				
	Comm. Chassis No. J3438	2	—	—	3
1064	Headlamp bracket O/S	—	1	1	4 0
1065	" " " N/S	—	1	1	4 0
1127	Tie bar for ditto	—	1	1	2 9
1094	Distance washer for headlamp bracket ...	—	4	4	doz. 1 4
1070	Rubber packing for ditto	—	2	2	8
1093	Front wing rear stay O/S	—	1	1	2 2
1099	" " " N/S	—	1	1	2 2
1899	Rear wing O/S (unpainted)				
	Ceased Chassis No. J3437	1	—	—	14 6
2060	Ditto N/S (unpainted)				
	Ceased Chassis No. J3437	1	—	—	14 6
2669	Ditto O/S (unpainted)				
	Comm. Chassis No. J3438	1	—	—	1 11 6
2670	Ditto N/S (unpainted)				
	Comm. Chassis No. J3438	1	—	—	1 11 6
2807	Rear wing tie bar O/S] Originally made [	1	—	—	6 11
2808	" " " N/S] in 1 piece [	1	—	—	6 11
1945	Bolt for rear wing mounting	2	—	—	10
318	Rubber moulding for ditto	2	—	—	5
316	Rubber washer for ditto				
	Comm. Chassis No. J3438	2	—	—	4
815	Rubber buffer between wing and body				
	Comm. Chassis No. J3438	2	—	—	3
1178	Rear wing O/S (unpainted)	—	1	1	1 5 10
1179	" " " N/S (unpainted)	—	1	1	1 5 10
2809	Running-board O/S Comm. Chassis No. J3438	1	—	—	1 1 0
2810	" " " N/S Comm. Chassis No. J3438	1	—	—	1 1 0
2590	Step channelling for ditto (17" long)				
	Comm. Chassis No. J3438	6	—	—	2 4
2591	Rubber for ditto (17" long)				
	Comm. Chassis No. J3438	6	—	—	1 2
3071	Rubber moulding between wing and running-board O/S ...				
	Comm. Chassis No. J3438	1	—	—	1 4
3072	Ditto N/S ... Comm. Chassis No. J3438	1	—	—	1 4
2030	Front fairing (unpainted)	1	—	—	16 0
MG372	Front fairing fixing clip with bolt and nut ...	1	—	—	6 8
1100	Front fairing (unpainted)	—	1	1	17 4
1912	Side fairing (unpainted) O/S	1	—	—	16 9
1913	" " " (unpainted) N/S	1	—	—	16 9
2053	" U " rubber for ditto (20" long)	1	—	—	5
S23/3	Rubber tape for ditto (36" long)	2	—	—	4
2052	Draught excluder plate for side fairing ...	2	—	—	9
2053	" U " rubber for ditto (10" long)	2	—	—	3
1484	Rubber bushes for ditto	4	—	—	3
1983	Side fairing fixing bracket O/S	1	—	—	1 9
1985	" " " N/S	1	—	—	1 9
1230	Side fairing O/S (unpainted)	—	1	1	8 7
1231	" " " N/S (unpainted)	—	1	1	8 7

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each		
					£	s.	d.
S23/3	Rubber tape for ditto (30" long) ...	—	2	2	foot		4
1485	Side fairing fixing bracket O/S ...	—	1	1			7
1486	" " " " N/S ...	—	1	1			7
1465	Front wing side fairing O/S ...	—	1	1		2	6
1466	" " " " N/S ...	—	1	1		2	6
1705	Rubber beading for ditto (8" long) ...	—	2	2			8
1894	Bonnet (unpainted) ...	1	—	—	2	5	0
1129	" (unpainted) ...	—	1	1	2	0	0
259	Bonnet rod lug (rear) ...	1	1	1			8
2062	Bonnet hinge rod bracket ...	1	1	1			6
A311	Bonnet fastener complete ...	4	—	—		3	4
A262	" " " " ...	—	4	4		4	2
1373	Bonnet fastener bracket (front) O/S ...	—	1	1		1	7
1374	" " " " (front) N/S ...	—	1	1		1	7
1550	" " " " (rear) O/S ...	—	1	1		1	8
1551	" " " " (rear) N/S ...	—	1	1		1	8
B225/146	Bonnet rest O/S ...	1	—	—		8	6
B225/147	" " N/S ...	1	—	—		8	6
B220/122	" " O/S ...	—	1	1		8	6
B220/123	" " N/S ...	—	1	1		8	6
S23/3	Tape for ditto (9' long) ...	1	1	1	foot		4
1931	Rain channel (under bonnet) ...	1	—	—		3	0
1932	Support bracket for ditto ...	1	—	—			3
419	Rubber washer for ditto ...	1	—	—			3
1633	Rain channel (under bonnet) ...	—	1	1		3	0
PROPELLER SHAFT SHROUD AND FITTINGS							
1856	Propeller shaft shroud ...	1	—	—	1	0	8
1957	" " " " ...	—	1	1	1	3	0
1223	Bottom plate for ditto ...	1	1	1		3	11
1438	Platform for ditto ...	2	2	2		1	4
979	Support bracket for ditto (rear) ...	1	1	1		2	7
1001	" U " clip for ditto ...	1	1	1			4
1211	Support bracket for ditto (front) ...	1	1	1		3	0
1212	" U " clip for ditto ...	1	1	1			6
1174	Footwell ...	—	1	1		9	10
1436	Angle plate for ditto (front) ...	—	2	2			4
1437	" " " " (rear) ...	—	2	2			4
BODY MOUNTING BRACKETS							
1002	Body bracket (rear) (on cross tube) ...	2	2	2			8
979	Support for ditto ...	2	2	2	2	7	
1001	" U " clip for ditto ...	2	2	2			4
2931	Body bracket (front) O/S (on cross tube) ...	1	1	1			5
2932	" " (front) N/S (on cross tube) ...	1	1	1			5
1211	Support for ditto ...	2	2	2	3	0	
1212	" U " clip for ditto ...	2	2	2			6
1587	Body bracket (front) ...	—	2	2		10	
1929	" " (rear) ...	2	2	2	1	2	
1930	Backing plate for ditto ...	2	2	2			6
1408	Plates for body mounting (rear) (with bolts) ...	—	4	4			7
1897	Body to dash tie bar ...	2	—	—		5	4
SPARE WHEEL CARRIER DETAILS							
MG424	Spare wheel carrier ...	1	—	—	2	15	0
MG497/102	M.G. medallion for ditto ...	1	—	—		5	0
1968	Thumb nut ...	1	—	—		5	4
1916	Distance tube for ditto ...	1	—	—			3
1915	Top fixing bracket for spare wheel carrier (on body) ...	1	—	—		5	4
1896	Bottom fixing bracket for spare wheel carrier (on frame) ...	2	—	—		2	9
361	Dome nut (C.P.) for securing carrier to body ...	2	—	—			6
1904	Rubber packing between petrol tank and spare wheel carrier (26" long) ...	2	—	—			10
P309	Spare wheel centre assembly ...	1	—	—		7	0
1972	Rubber buffer for ditto ...	1	—	—		1	4
B220/110	Spare wheel block ...	—	1	—		11	0
1193	Spare wheel hub ...	—	1	—		13	0
1194	Spare wheel lock nut and sleeve ...	—	1	—		14	0
P316	Spare wheel carrier assembly (single wheel) ...	—	—	1	2	7	4
1620	Spare wheel carrier bracket ...	—	—	1		2	6
1322	Spare wheel carrier distance tube ...	—	—	1			8
1619	Spare wheel carrier support channel (single wheel) ...	—	—	1		10	10

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each
					£ s. d.
1616	Spare wheel carrier wing nut	—	—	1	5 4
1615	Spare wheel carrier tie bar	—	—	1	8 6
1384	Spare wheel carrier trough	—	—	1	3 8
1617	Spare wheel carrier tyre clip	—	—	1	8 6
1386	Spare wheel top support tie rod	—	—	1	4 9
1389	Securing bracket for ditto (on body) N/S ...	—	—	1	2 1
1391	Nut for spare wheel top support tie rod ...	—	—	2	4
1392	Spare wheel carrier trough support bracket	—	—	1	1 7
1395	Spare wheel carrier special washer for tie bar	—	—	1	3
1479	Spare wheel carrier trough clip	—	—	1	8 6
1455	Spare wheel carrier rubber bush (on body)	—	—	1	6
MG465	Spare wheel centre assembly	—	—	1	7 0
MG372/102	M.G. medallion for spare wheel centre assembly	—	—	1	1 0
1621	Spare wheel carrier support channel (two wheels)	—	—	1	12 6
1390	Spare wheel securing bracket for top support tie rod O/S	—	—	1	2 1
BODY DETAILS (2-SEATER)					
13225	Body complete	1	—	—	Price on application
DOORS, LOCKS AND HINGES					
B128/176	Door hinge O/S (top)	4	—	—	3 0
B225/140	" " O/S (bottom)	1	—	—	3 0
B128/174	" " N/S (top)	1	—	—	3 0
B225/138	" " N/S (bottom)	1	—	—	3 0
B225/143	Door lock O/S (Mulliner)	1	—	—	9 6
B225/144	" " N/S (Mulliner)	1	—	—	9 6
B225/101	" " O/S (Carbodies)	1	—	—	9 6
B225/142	" " N/S (Carbodies)	1	—	—	9 6
B225/125	Door lock catch plate (Mulliner)	2	—	—	3 6
B225/108	" " " " (Carbodies)	2	—	—	3 6
B225/121	Door handle (Mulliner)	2	—	—	5 0
B225/119	" " O/S (Carbodies)	1	—	—	5 0
B225/120	" " N/S (Carbodies)	1	—	—	5 0
B225/148	Door check strap (7")	2	—	—	2 0
B220/194	Side curtain sockets	4	—	—	1 4
SEATS AND FITTINGS					
B225/133	Rear squab complete less tonneau cover ...	1	—	—	2 17 0
B128/181	Squab adjusting screw and knob (top) ...	2	—	—	1 6
B220/177	Squab adjusting plate (top)	2	—	—	1 0
B225/176	Squab adjusting peg (bottom)	2	—	—	3 4
B225/177	Squab adjusting bottom rack	2	—	—	8
B225/171	Seat cushion O/S	1	—	—	1 7 0
B225/172	" " N/S	1	—	—	1 7 0
B225/115	Air bag for seat cushion	2	—	—	15 0
B225/103	Tonneau cover	1	—	—	1 12 0
FLOORBOARDS AND CARPETS					
B225/162	Floorboards O/S	1	—	—	1 3 0
B225/163	" " N/S	1	—	—	1 3 0
B225/136	Carpet (propeller shaft shroud cover) ...	1	—	—	13 4
B225/118	" (front) (with mat)	1	—	—	2 2 0
2707	Leather cover for speedometer reduction gear	1	—	—	5 4
	Comm. Chassis No. J3576	1	—	—	9 0
B220/155	Passenger foot rest with rubber mat ...	1	—	—	2 0
B220/169	Rubber mat for ditto and carpet	2	—	—	
FACIA PANEL AND WINDSCREEN DETAILS					
B225/141	Facia panel (drilled)	1	—	—	1 5 0
B225/1	Windscreen complete (1933, drilled for suction wiper)	1	—	—	7 2 6
B225/2	Windscreen frame complete less glass ...	1	—	—	4 15 0
B225/173	Windscreen frame (bare)	1	—	—	2 10 0
B225/116	Windscreen side support O/S	1	—	—	1 0 0
B225/117	" " N/S	1	—	—	1 0 0
B225/10	Windscreen complete (1933, with strengthened supports)	1	—	—	7 2 6
B225/11	Windscreen frame complete less glass ...	1	—	—	4 15 0
B225/174	Windscreen frame (bare)	1	—	—	2 10 0

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each
					£ s. d.
B225/12	Windscreen complete (1934, electric wiper with flat for exterior mirror)	1	—	—	7 2 6
B225/3	Windscreen frame complete less glass	1	—	—	4 15 0
B225/175	Windscreen frame (bare)	1	—	—	2 10 0
B225/158	Windscreen side support O/S (top)	1	—	—	15 0
B225/156	" " " N/S (top)	1	—	—	15 0
B225/159	" " " O/S (bottom)	1	—	—	15 0
B225/169	" " " O/S (bottom) (with flat for exterior mirror)	1	—	—	15 0
B225/157	Ditto N/S (bottom)	1	—	—	15 0
B220/160	Windscreen ratchet (used only with B225/1 and B225/10)	2	—	—	7 6
B225/181	Windscreen ratchet (used with B225/12)	2	—	—	7 6
B220/161	Spring for ditto	2	—	—	6
B220/162	Adjusting fly screw	2	—	—	6 0
B225/100	Windscreen glass	1	—	—	2 7 6
B225/123	Windscreen rubber surround	1	—	—	4 9
HOOD AND SIDE CURTAINS					
B225/113	Hood frame	1	—	—	2 0 0
B225/160	Hood frame fulcrum bracket (on body)	2	—	—	3 6
B225/112	Hood canopy (for suction wiper)	1	—	—	2 6 0
B225/168	" " (for electric wiper)	1	—	—	2 6 0
B225/113	Side curtain O/S (complete)	1	—	—	1 1 0
B225/114	" " N/S (complete)	1	—	—	1 1 0
B220/157	Side curtain feet	4	—	—	1 0
B225/127	Curtain flap O/S	1	—	—	7 6
B225/130	" " N/S	1	—	—	7 6
BODY DETAILS (4-SEATER)					
B221	Body complete	—	1	—	Price on application
DOORS, LOCKS AND HINGES					
B220/145	Door hinge O/S	—	2	—	2 6
B220/146	" " N/S	—	2	—	2 6
B220/129	Door lock O/S	—	1	—	3 3
B220/130	" " N/S	—	1	—	3 3
B220/120	Door handle O/S	—	1	—	5 0
B220/121	" " N/S	—	1	—	5 0
B220/178	Door check strap	—	2	—	2 0
B220/194	Side curtain sockets	—	4	—	1 4
SEATS AND FITTINGS					
B220/100	Bucket seat O/S	—	1	—	3 0 0
B220/150	" " N/S	—	1	—	3 0 0
B220/101	Cushion for ditto less air bag	—	2	—	1 5 0
B220/147	Air bag for ditto	—	2	—	15 0
B220/112	Seat adjusting plate	—	4	—	1 0
B220/113	Wing stud for ditto	—	4	—	1 6
B220/103	Rear seat squab	—	1	—	1 5 0
B220/140	Rear seat pan	—	1	—	1 15 0
B220/102	Rear seat cushion less air bags	—	1	—	3 0 0
B220/148	Air bag for ditto	—	2	—	15 0
FLOORBOARDS AND CARPETS					
B221/101	Floorboard (large) O/S	—	1	—	7 0
B221/102	" (large) N/S	—	1	—	7 0
B220/118	" (small) O/S	—	1	—	5 0
B220/119	" (small) N/S	—	1	—	5 0
B220/104	Front carpet O/S	—	1	—	9 0
B220/105	" " N/S	—	1	—	9 0
B221/100	Centre carpet	—	1	—	7 0
B220/107	Foot well carpet	—	1	—	7 0
B220/108	Heel board carpet	—	1	—	6 0
B220/155	Passenger foot slope with rubber mat	—	1	—	9 0
B220/109	Rubber mat	—	2	—	2 0
FACIA PANEL AND WINDSCREEN					
B220/143	Facia panel	—	1	—	2 0 0
B220/1	Windscreen complete with glass	—	1	—	8 13 9
B220/2	Windscreen frame complete less glass	—	1	—	6 15 0
B220/142	Windscreen frame	—	1	—	3 10 0

Please Quote Chassis, Engine and Body Numbers in all Correspondence

		No. Used			Price Each		
Part No.	DESCRIPTION	2-seater	4-seater	Saloon	£	s.	d.
B220/158	Windscreen side support (top) O/S ...	—	1	—	15	0	0
B220/179	" " " (top) N/S ...	—	1	—	15	0	0
B220/159	" " " (bottom) O/S ...	—	1	—	15	0	0
B220/180	" " " (bottom) N/S ...	—	1	—	15	0	0
B220/141	Windscreen glass ...	—	1	—	1	18	9
B220/160	Windscreen ratchet ...	—	2	—	7	6	0
B220/161	Windscreen ratchet spring ...	—	2	—			6
B220/162	Windscreen adjusting fly screw ...	—	2	—	6	0	0
HOOD AND SIDESCREENS							
B221/118	Hood frame complete ...	—	1	—	2	8	0
B221/126	Hood frame securing bracket on body ...	—	2	—	2	3	0
B221/105	Hood canopy ...	—	1	—	2	10	0
B220/138	Hood to screen attachment bracket ...	—	2	—	4	6	0
B220/172	Wing screw for ditto ...	—	2	—	2	6	0
B220/137	Hood straps ...	—	2	—	2	0	0
B221/120	Staples for ditto ...	—	2	—	1	0	0
B220/134	Hood rest (rear) O/S ...	—	1	—	7	0	0
B220/135	" " (rear) N/S ...	—	1	—	7	0	0
B221/106	Hood envelope ...	—	1	—	15	0	0
B221/103	Side curtain (front) O/S (complete)...	—	1	—	1	1	0
B221/104	" " (front) N/S (complete)...	—	1	—	1	1	0
B220/127	Rear side curtain O/S ...	—	1	—	11	0	0
B220/128	" " " N/S ...	—	1	—	11	0	0
B128/120	Boot lid lock ...	—	1	—	2	0	0
B128/113	Key for ditto ...	—	1	—	1	0	0
B128/121	Escutcheon for ditto ...	—	1	—	1	6	0
BODY DETAILS (SALOON)							
B222	Body complete ...	—	—	1	Price on application		
DOORS, LOCKS AND HINGES							
B222/121	Door hinge O/S ...	—	—	2	6	0	0
B222/122	" " N/S ...	—	—	2	6	0	0
B222/146	Door lock O/S ...	—	—	1	15	6	0
B222/147	" " N/S ...	—	—	1	15	6	0
B220/120	Door handle O/S ...	—	—	1	5	0	0
B222/1	" " N/S (with lock and key) ...	—	—	1	15	0	0
B222/108	Door check strap ...	—	—	2	2	0	0
B220/124	Door rubber buffer ...	—	—	2	1	0	0
SEATS AND CUSHIONS							
B222/100	Bucket seat O/S ...	—	—	1	3	0	0
B222/110	" " N/S ...	—	—	1	3	0	0
B220/101	Cushion for ditto with air bag ...	—	—	2	1	5	0
B220/147	Air bag for ditto ...	—	—	2	15	0	0
B220/112	Seat adjusting plate ...	—	—	4	1	0	0
B220/113	Wing stud for ditto ...	—	—	4	1	6	0
B222/101	Rear seat squab ...	—	—	1	1	5	0
B220/140	Rear seat pan ...	—	—	1	1	15	0
B220/102	Rear seat cushion ...	—	—	1	3	0	0
B220/148	Air bag for ditto ...	—	—	2	15	0	0
FLOORBOARDS AND CARPETS							
B222/102	Floorboard (large) O/S ...	—	—	1	7	0	0
B222/103	" (large) N/S ...	—	—	1	7	0	0
B220/118	" (small) O/S ...	—	—	1	5	0	0
B220/119	" (small) N/S ...	—	—	1	5	0	0
B220/104	Front carpet O/S ...	—	—	1	9	0	0
B220/105	" " N/S ...	—	—	1	9	0	0
B221/100	Centre carpet ...	—	—	1	7	0	0
B220/107	Foot well carpet ...	—	—	1	7	0	0
B220/108	Heel board carpet ...	—	—	1	6	0	0
B220/155	Passenger foot slope with rubber mat ...	—	—	1	9	0	0
B220/109	Rubber mat ...	—	—	2	2	0	0
FACIA PANEL, WINDSCREEN AND DOOR GLASSES							
B222/118	Facia panel (drilled) ...	—	—	1	2	10	0
B222/7	Windscreen complete with glass ...	—	—	1	8	16	3
B222/112	Windscreen frame less glass ...	—	—	1	6	15	0
B222/111	Windscreen glass ...	—	—	1	2	1	3

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	MG	DESCRIPTION	MG	No. Used			Price Each		
				2-seater	4-seater	Saloon	£	s.	d.
B222/123		Door glass (front) (sliding type) ...		---	---	2	1	4	10
B222/115		" " (rear) ...		---	---	2	1	3	5
B222/117		Rear light glass ...		---	---	1	1	6	7
B222/4		Rear window blind (complete) ...		---	---	1	1	5	0
SLIDING ROOF DETAILS									
B222/107		Sliding roof channel (interior) ...		---	---	2	10	0	
B222/152		" " " (exterior) O/S ...		---	---	1	5	0	
B222/154		" " " (exterior) N/S ...		---	---	1	5	0	
B222/5		Sliding roof lock (complete) ...		---	---	2	10	0	
B222/106		Sliding roof handle ...		---	---	1	1	0	
B222/6		Roof-lamp (complete) ...		---	---	1	8	0	
LUGGAGE CARRIER DETAILS									
P307		Luggage carrier assembly ...		---	---	1	1	12	0
1418		Slide fitting in flap for support arm N/S ...		---	---	1	3	6	
1419		Ditto O/S ...		---	---	1	3	6	
1420		Luggage carrier support arm ...		---	---	2	5	6	
1421		Wing nut for ditto ...		---	---	2	1	8	
1422		Grab screw for ditto ...		---	---	2		3	
1424		Support clip on flap for arm ...		---	---	2		3	
1426		Hinge on body N/S ...		---	---	1	1	6	
1431		Hinge on flap N/S ...		---	---	1	1	3	
1427		Hinge on body O/S ...		---	---	1	1	6	
1432		Hinge on flap O/S ...		---	---	1	1	3	
1430		Swivel pin bracket for hinge ...		---	---	2	1	10	
1423		Bottom fixing block for support arm ...		---	---	2	3	11	
1425		Body fixing bracket for ditto ...		---	---	2		4	
1439		Stud for ditto ...		---	---	4		3	
B128/120		Lock for luggage carrier panel ...		---	---	2	2	0	
B128/121		Escutcheon for ditto ...		---	---	2	1	6	
B128/113		Key for ditto ...		---	---	1	1	0	
TOOL KIT									
B220/139		Toolbox ...		---	1	---	15	0	
B220/139		Toolbox ...		---	---	1	15	0	
P330/100		Tool roll ...		1	1	1	4	0	
P330/101		Screwdriver (10") ...		1	1	1	1	6	
P330/103		Adjustable spanner ...		1	1	1	2	8	
P330/104		Pliers (6" pair) ...		1	1	1	1	0	
2867		Tappet spanner with .006" feeler gauge ...		1	1	1	1	0	
P330/113		Spanner ($\frac{1}{4} \times \frac{3}{16}$ ") (double-ended) ...		1	1	1		6	
P330/114		" ($\frac{3}{8} \times \frac{5}{16}$ ") (double-ended) ...		1	1	1		10	
P330/115		" ($\frac{1}{2} \times \frac{7}{16}$ ") (double-ended) ...		1	1	1	1	3	
1733		Contact breaker spanner ...		1	1	1		6	
1734		Grease gun ...		1	1	1	10	6	
1735		Tyre pump ...		1	1	1	7	0	
1736		Jack (with handle) ...		1	1	1	1	1	0
1401		Starting handle ...		1	1	1	3	8	
P330/117		Hammer for Rudge hubs ...		1	1	1	6	6	
1182		Special engine spanner ...		1	1	1	1	6	
A288		Grease gun ...		1	1	1	6	0	
1892		Plug spanner ...		1	1	1	1	3	
1959		Spanner ($\frac{1}{8}$ " Whit.) ...		1	1	1		10	
2801		Box spanner ($\frac{1}{4}$ " Whit.) ...		1	1	1		11	
2802		" ($\frac{7}{16}$ " Whit.) ...		1	1	1	1	3	
2860		Tommy bar for ditto ...		1	1	1		2	

PRINTED IN GREAT BRITAIN BY
THE MORRIS-OXFORD PRESS LTD.
COWLEY : OXFORD : ENGLAND
27514—1/35/750

Telephone : 251 (4 lines)

Telegrams : "EMGEE"

THE CAR
COMPANY LTD
ABINGDON-ON-THAMES

Governing Director LORD NUFFIELD
Managing Director CECIL KIMBER, M.I.A.E.