

PRICE 2/6

THE SPARE PARTS LIST FOR

THE



MAGNETTE

(KN Type)

DECEMBER, 1934

IMPORTANT

When ordering replacements it is of the greatest assistance to our Service Department if the part required is given its correct reference number and description, and the chassis and engine numbers should be quoted in all correspondence as well as on the order itself, as delay and misinterpretation of orders are thus avoided.

We would also draw your attention to the fact that you will get quicker service if you place all your orders with our Distributors in your territory, who are holding very adequate stocks of M.G. Spares.

The name and address of the nearest Distributors is given in Instruction Manual supplied with the car, and we feel sure that all your requirements will receive every consideration and attention.

May we request you therefore to get into touch with our Distributors for all your future orders ?

We cannot stress too highly the *danger* of fitting non-genuine M.G. parts.

Unfortunately cases have come to our notice where accidents have actually been caused by this practice, and we strongly advise all M.G. owners to insist and see that for all repairs and replacements only genuine M.G. parts are fitted.

M.G. parts are specially designed and manufactured to withstand the stresses imposed by a high-speed sports car, and we would warn all owners that the fitting of non-genuine parts renders the guarantee *null and void*.

The Company only fit the highest grade and best known proprietary fittings, but we give no guarantee whatsoever in respect of tyres, lamps, electrical equipment, speedometers, clocks, or any other proprietary fittings of any type supplied with the car or otherwise, as such proprietary fittings are usually covered by a guarantee issued by their respective manufacturers.

All questions involving the replacement or repair of any such proprietary fittings should therefore be taken up direct with the manufacturers concerned, and not with The M.G. Car Company Ltd.

G.K.—G.T.



CHASSIS NUMBER.....

ENGINE NUMBER.....

BODY NUMBER.....

REGISTRATION NO.....

NAME

ADDRESS

DATE.....

AGENT

**PLEASE FILL IN AND QUOTE REFERENCES IN
CORRESPONDENCE AND WHEN ORDERING
PARTS.**

INDEX

	<i>Sheet</i>
Accelerator Gear	13
Accessories	15
Axle (Front)	1—3
Axle (Rear)	3—4
Body and Details (Saloon)	18—20
Bonnet	17
Brake Gear	13
Chassis Frame and Details	1
Controls	13
Dashboard and Fume Excluders	16
Electrical Equipment	16
Exhaust System and Silencer	14
Fairings	17
Instruments	16
Petrol Tank and Pipes	14—15
Power Unit and Installation	4—12
Bell Housing and Rear Main Bearing	5
Carburettors	7
Clutch Details	10
Connecting Rods and Pistons	6
Crankshaft Intermediate Main Bearings	5
Cylinder Block	4—5
Cylinder Head	6—7
Dynamo and Vertical Drive	8
Electrical Details	10
Engine Nosepiece and Front Main Bearing	5
Flywheel	5
Gearbox and Remote Control	10—12
Induction Manifold and Exhaust Manifold	7
Lubrication Details	8—10
Water Pump and Details	8
Propeller Shaft Shroud, Fittings	17
Radiator and Connections	14
Shock Absorbers	15
Spare Wheel Carrier and Fittings	17
Springs (Front)	3
Springs (Rear)	4
Steering Gear	13—14
Sundries	15
Tool Kit	20
Wings, Front and Rear	17

Do not forget to quote Chassis, Engine and Body Numbers in all correspondence.

**CHASSIS FRAME AND DETAILS**

MG559	Chassis frame assembly , comprising 2 side members, 5 cross tube assemblies, 2 front and 2 rear dumb-irons, 2 front sliding trunnion brackets, 2 rear spring suspension pins, 1 set of cruciform bracing, 2 rear cross braces, 1 foot well, 1 battery carrier, 1 pair of rear shock absorber brackets, 2 front wing stay brackets			1	15	17	6
P332/1	Front cross tube assembly	...	...	1	1	0	0
MG559/1	Engine bearer cross tube assembly	...	...	1	3	15	10
1811	Cap for front engine mounting	...	...	1		2	9
1810	Special bolt for ditto	...	...	2			10
P332/3	Third cross tube	...	...	1	2	9	0
P332/4	Rear spring front cross tube	...	...	1	2	10	0
1783	Rear spring front suspension pin	...	...	2		6	2
1844	Plug for ditto	...	...	2			2
P332/5	Rear cross tube assembly	...	...	1	6	17	6
1794	Rear spring sliding trunnion roller	...	...	4		2	9
820	Washer for ditto	...	...	2			6
873	Distance piece for rear cross tube	...	...	2			11
1793	Cap for rear cross tube	...	...	2		7	9
MG559/100	Side member O/S (drilled)	...	...	1	1	19	0
MG559/101	" " N/S (drilled)	...	...	1	1	19	0
1763	Front dumb-iron O/S	...	...	1		11	8
1764	" " N/S	...	...	1		11	8
625	Taper washer for ditto	...	...	2			4
1768	Bracket for front spring sliding trunnion O/S	...	...	1		9	0
1769	" " " " " N/S	...	...	1		9	0
1771	Front spring sliding trunnion roller	...	...	4		2	9
1770	Cover for ditto	...	...	2		6	4
1779	Combined cross tube end bracket and brake cross shaft support	...	...	2		10	2
1780	Bracket for rear spring front cross tube	...	...	2		2	9
2612	Front wing stay bracket	...	...	2			6
MG559/102	Foot well	...	...	1		19	0
1833	Battery carrier	...	...	1		10	2
MG559/103	Rear shock absorber bracket	...	...	2		3	9
1789	Rear cross brace O/S	...	...	1	1	1	10
1790	" " N/S	...	...	1	1	1	10
2404	Chassis frame reinforcement (front) O/S	...	...	1	1	1	3
2405	" " " (front) N/S	...	...	1	1	1	3
MG559/104	" " " (rear)	...	...	2	1	1	10
2408	" " " (centre)	...	...	2		2	3
804	Rubber buffer and plate for front axle stop	...	...	2		1	7
805	Backing plate for ditto	...	...	2			4
815	Rear axle striking pad	...	...	2			3
817	Set screw for ditto	...	...	2			2
874	Combined greaser and set screw for rear spring rear cross tube	...	...	2			10

FRONT AXLE AND SPRINGS

MG554	Front axle assembly less springs and wheels			1	13	7	6
MG362/2	Axle beam with bush for track rod centre lever	...	...	1	3	9	4
MG362/118	Bush for track rod centre lever	...	...	2		2	0
MG554/1	Steering knuckle (bushed) O/S	...	...	1	1	4	8
MG554/2	" " (bushed) N/S	...	...	1	1	4	8
MG362/105	" Bush for ditto (top)	...	...	2		2	11
MG362/107	" " (bottom)	...	...	2		2	9
P101/115	Washer for steering knuckle (wheel bearings)	...	...	2	doz.		9
P101/113	Slotted nut for steering knuckle O/S	...	...	1		1	0
P101/114	" " " N/S	...	...	1		1	0
MG362/101	Steering knuckle king pin	...	...	2		1	10
MG362/102	Cotter pin for ditto	...	...	2			6
X101/1	Nut for ditto	...	...	2	doz.	1	3
X101/2	Spring washer for ditto	...	...	2	doz.		8
MG362/108	Thrust washer for king pin	...	...	2			5
MG362/106	Disc for steering knuckle top bush	...	...	2	doz.	1	0
MG362/129	Steering arm O/S	...	...	1		8	6
MG362/130	" " N/S	...	...	1		8	6
MG554/3	Brake anchor bracket assembly O/S	...	...	1	2	2	4
MG554/4	" " " " " N/S	...	...	1	2	2	4
MG362/161	" Bush for brake cam	...	...	2		1	7
MG362/132	Brake cable stop bracket	...	...	2		4	9
MG362/128	Oil thrower for anchor bracket	...	...	2		1	4
MG362/125	Bolt for brake anchor bracket (1 5/8" long)	...	...	4		1	0
MG362/126	" " " " " (1 3/8" long)	...	...	4		1	0

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	MG	DESCRIPTION	MG	No. Used		Price Each		
				Saloon		£	s.	d.
MG362/127		Bolt for brake anchor bracket (1½" long) ...		4		1	0	
X101/10		Nut for ditto ...		12	doz.	1	3	
X101/11		Spring washer for ditto ...		12	doz.		8	
MG362/147		Brake cam ...		2		4	9	
MG362/148		Brake cam lever O/S ...		1		2	9	
MG362/149		" " " N/S ...		1		2	9	
X101/4		Key for ditto (Woodruff) ...		2			3	
X101/5		Bolt for ditto ...		2			3	
X101/1		Nut for ditto ...		2	doz.	1	3	
X101/2		Spring washer for ditto ...		2	doz.		8	
MG554/7		Brake-shoe with lining ...		4		16	10	
MG362/156		Brake-shoe lining ...		4		3	0	
MG362/184		Rivets for ditto ...		36	doz.		5	
MG362/160		Damper weight for brake-shoe ...		4		2	6	
MG362/158		Clevis pin for damper weight ...		8			3	
MG362/159		Spring for ditto ...		8			3	
X362/3		Washer for ditto ...		16	doz.		2	
MG554/111		Fulcrum pin for brake-shoe ...		4		2	4	
X105/13		Washer for ditto... ...		4			3	
X105/12		Nut for ditto (external) ...		4			3	
MG554/108		Bridge piece for fulcrum pin ...		2		1	5	
MG554/113		Lock screw for ditto ...		4			7	
MG554/112		Lock plate for ditto ...		2			4	
MG362/155		Axis pin for brake-shoe ...		4		1	3	
MG362/154		Roller for brake-shoe ...		4			6	
X363/32		Washer for ditto ...		4	doz.		5	
MG362/157		Brake-shoe spring... ...		2			3	
MG554/5		Front hub (studded) O/S ...		1		1	0	0
MG554/6		" " (studded) N/S ...		1		1	0	0
MG554/106		Studs for hub ...		12			10	
X362/1		Nuts for hub studs ...		12	doz.	1	0	
X493/5		Spring washers for ditto... ...		12	doz.		8	
MG554/109		Distance washer for steering knuckle ...		2		1	6	
MG494/104		Oil retainer for front hub ...		2		3	0	
P151/195		Hub bearing (inner) ...		2		12	0	
MG362/109		Distance tube between bearings ...		2		1	2	
P101/117		Hub bearing (outer) ...		2		10	9	
MG554/107		Brake-drum ...		2		1	10	0
MG362/143		Track rod centre lever ...		1		7	2	
MG362/144		Pin for centre lever ...		1		4	7	
MG362/145		Thrust washer for ditto ...		1			9	
X348/17		Key for ditto (Woodruff) ...		1			2	
X362/2		Slotted nut for ditto ...		1			3	
X110/30		Set screw for centre lever ...		1			3	
X105/3		Nut for ditto ...		1	doz.	1	3	
MG362/5		Track rod assembly (short) ...		1		14	6	
MG362/6		" " " (long) ...		1		16	0	
MG362/133		" Track rod tube (short) ...		1		13	10	
MG362/134		" " " (long) ...		1		15	3	
P101/136		Lock nut for ditto (R.H. thread) ...		2			4	
P101/137		" " " " (L.H. thread) ...		2			4	
MG362/137		Adjustable end for track rod (R.H.) ...		2		2	9	
MG362/139		Ball seat (inner) ...		2		2	9	
MG362/138		" " (outer) ...		2		2	9	
MG362/140		Spring washer for ditto ...		2			2	
MG362/141		Adjustable screw for ditto ...		2			9	
MG362/142		Adjustable end for track rod (L.H.) ...		2			10	
P101/142		Ball cup ...		2			10	
P101/144		Spring for ball joint ...		2			3	
P101/143		End cup for ball joint ...		2		1	0	
P101/138		Steering ball ...		4		2	0	
P101/139		Nut for ditto ...		4			4	
MG597		Draglink assembly ...		1		17	2	
MG597/100		Draglink tube ...		1		5	0	
P101/136		Lock nut for ditto (R.H. thread) ...		1			4	
P101/137		" " " " (L.H. thread) ...		1			4	
MG362/142		Adjustable end (L.H. thread) ...		1		3	0	
MG367/101		" " (R.H. thread) ...		1		3	0	
P101/142		Ball cup ...		2			10	
P101/143		End plug for ball joint (R.H.) ...		1		1	0	
P102/106		" " " " (L.H.) ...		1			3	

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	MG	DESCRIPTION	MG	No. Used	Price Each		
					Saloon	£	s. d.
P101/144		Spring for ball joint		1			3
P102/105		Cup for ball joint		1		1	0
P101/138		Steering ball		2		2	0
P101/139		Nut for ditto		2			4
X367/1		Washer for draglink end		2		doz.	6
MG392 Front spring O/S and N/S							
MG392/100		Front spring top rebound leaf		2		16	8
MG392/101		Front spring second rebound leaf		2		3	5
MG392/102		Front spring main leaf		2		3	10
MG392/103		Front spring second leaf		2		5	4
MG392/104		Front spring third leaf		2		3	2
MG392/105		Front spring fourth leaf... ..		2		2	7
1776		Front shock absorber bracket on spring O/S		2		2	3
1782		" " " " " " N/S		1		2	9
1777		Front spring bottom plate		1		2	9
3154		Taper plates for front axle		2		3	8
2068		Front spring bolts		2		1	4
2302		Stiffening strip for front spring		8			8
1772		Dust excluder for front spring		4			4
1765		Front spring suspension pin		2		1	1
802		Tab washer for ditto		2		2	6
				2			4

REAR AXLE ASSEMBLY, SPRINGS AND PROPELLER SHAFT

MG555		Rear axle assembly less springs and wheels		1		31	0	0
MG364/4		Rear axle casing with ends		1		4	3	9
X463/1		Set screw for rear axle front cover		10				2
X364/2		Packing washer for set screw		10		doz.		3
X364/3		Drain plug for axle casing		1				5
MG555/1		Rear axle front cover complete with differential assembly		1		10	15	0
MG555/4		Rear axle front cover (studded) with differential bearing caps		1		1	19	6
MG463/106		Bolt for differential bearing cap		4			1	0
X364/8		Dowel bush for ditto		4				2
X463/2		Stud for bevel pinion housing		6				2
MG555/103		Bevel pinion housing		1		7		2
MG364/163		Thrust washer for bevel pinion		1				6
MG555/5		Bevel pinion roller bearings		1 pair	pair 1	2		0
MG555/104		Distance tube between bearings		1				6
X555/2		Thrust bearing for bevel pinion		1		17		9
MG364/172		Shims for bevel pinion housing (.003" thick)... ..		as reqd.				4
MG364/173		" " " " (.005" thick)... ..		as reqd.				5
MG364/174		" " " " (.010" thick)... ..		as reqd.				5
MG364/175		" " " " (.020" thick)... ..		as reqd.				6
MG555/105		Cap for bevel pinion housing		1		5	10	
P105/127		Countersunk screw for ditto		2				3
X105/3		Nut for bevel pinion housing stud		6		doz.	1	3
X105/4		Spring washer for ditto		6		doz.		8
MG364/165		Universal joint flange for propeller shaft		1			8	0
X364/5		Nut for pinion shaft		1				3
X364/6		Washer for ditto		1		doz.		9
MG494/101		Combined oil filler plug and dipstick adaptor		1			3	0
MG494/106		Spring retainer for oil level dipstick		1				2
X364/7		Set screw for ditto		2		doz.		5
MG364/1		Dipstick		1			1	6
MG555/2		Differential complete with crown wheel and pinion		1		6	0	0
MG555/6		Differential case complete		1		1	3	8
MG364/178		Differential wheel... ..		2			7	6
X364/10		Differential pinion		4			5	2
X555/3		Differential spider... ..		1			6	1
X364/11		Differential case bolts		8				6
MG364/181		Nuts for ditto		8				2
X364/12		Lock washers for ditto		8				1
MG555/7		Crown wheel and pinion (9/52 ratio)		1 pair		3	3	0
X364/13		Differential case bearing... ..		2		10	10	
P105/158		Adjusting nut for ditto		2			1	10
P105/113		Locking washer for ditto		2				3
MG364/166		Joint for rear axle front cover... ..		1		doz.		9
X101/10		Nut for securing front cover		10		doz.	1	3
X101/11		Spring washer for ditto		10		doz.		8
MG364/171		Rear axle rear cover		1			2	6
MG364/166		Joint for rear cover		1		doz.		9
X364/9		Set screw for securing rear cover		10				2

Please Quote Chassis, Engine and Body Numbers when ordering Parts



Saloon

£ s. d.

X101/11	Spring washer for rear cover set screws	10	doz.	8
MG364/111	Rear axle shaft	2	1	5 0
MG364/106	Rear hub O/S	1	15	0
MG364/107	" " N/S	1	15	0
MG554/3	Brake anchor bracket assembly O/S	1	2	2 4
MG554/4	" " " " N/S	1	2	2 4
MG362/161	Bush for brake cam	2	1	7
MG362/132	Brake cable stop bracket	2	4	9
MG362/128	Oil thrower for brake anchor bracket...	2	1	4
MG362/126	Bolts for brake anchor bracket (1 $\frac{3}{8}$ " long)	4	1	0
MG362/127	" " " " (1 $\frac{1}{8}$ " long)	8	1	0
X101/10	Nut for ditto	12	doz.	1 3
X101/11	Spring washer for ditto	12	doz.	8
MG554/111	Brake-shoe fulcrum pin	4	2	4
X105/12	Nut for securing ditto to anchor bracket	4	3	
X105/13	Washer for ditto	4	3	
MG362/147	Brake cam...	2	4	9
MG362/148	Brake cam lever O/S	1	2	9
MG362/149	" " " " N/S	1	2	9
X101/4	Key for ditto (Woodruff)	2	3	
X101/5	Bolt for ditto	2	3	
X101/1	Nut for ditto	2	doz.	1 3
X101/2	Spring washer for ditto	2	doz.	8
MG554/7	Brake-shoe with lining	4	16	10
MG362/156	Lining for brake-shoe	4	3	0
MG362/184	Rivets for ditto	36	doz.	5
MG362/160	Damper weight for brake-shoe	4	2	6
MG362/158	Clevis pin for ditto	8	3	
MG362/159	Spring for damper weight	8	3	
X362/3	Washer for ditto	16	doz.	2
MG554/108	Bridge piece for fulcrum pin	2	1	5
MG554/113	Lock screw for ditto	4	7	
MG554/112	Lock plate for ditto	2	4	
MG362/155	Axis pin for brake-shoe	4	1	3
MG362/154	Roller for ditto	4	6	
X363/32	Washer for ditto	4	doz.	5
MG362/157	Brake-shoe spring	2	3	
X555/4	Rear hub oil retainer	2	4	5
MG555/3	Rear hub bearing housing with studs	2	13	6
MG555/101	Rear hub studs	12	10	
X101/10	Nut for hub studs	12	doz.	1 3
X493/5	Spring washer for ditto	12	doz.	8
X364/15	Rear hub bearing...	2	1	10 3
P105/158	Adjusting nut for ditto (R.H. thread)	1	1	10
P105/159	" " " " (L.H. thread)	1	1	10
P105/113	Locking washer for ditto	2	3	
MG554/107	Brake-drum	2	1	10 0
MG393	Rear springs O/S and N/S	2	18	0
MG393/100	Rear spring top rebound leaf	2	4	2
MG393/101	Rear spring second rebound leaf	2	4	8
MG393/102	Rear spring main leaf	2	7	0
MG393/103	Rear spring second leaf	2	4	5
MG393/104	Rear spring third leaf	2	4	0
MG393/105	Rear spring fourth leaf	2	3	5
MG393/106	Rear spring fifth leaf	2	2	9
3104	Rear shock absorber bracket O/S	1	4	10
3105	" " " " N/S	1	4	10
1797	Rear spring top plate	2	7	0
2303	Stiffening strip for rear spring	4	1	0
1805	Rear spring bolts...	8	1	8
1801	Dust excluder for rear spring	2	1	2
1785	Washer for rear spring suspension	2	doz.	1 4
1784	Radius washer for ditto	2	doz.	1 4
3170	Rear axle strap	2	1	10
3177	Rubber pad for ditto	2	8	
A691	Propeller shaft	1	5	3 6
811	Bolts for propeller shaft flange...	12	4	

POWER UNIT AND INSTALLATION

MG572	Power unit complete with gearbox and remote control	1	Price on application	
-------	---	---	----------------------	--

CYLINDER BLOCK

MG489/1	Cylinder block (studded) with cover-plates	1	10	12 6
X110/38	Core disc for cylinder block	2	4	

Please Quote Chassis, Engine and Body Numbers in all Correspondence



MG348/102	Cover-plate (front and rear) for cylinder jacket	...	2		1	0
MG348/1	Cover-plate (intermediate) for cylinder jacket	...	1		6	1
X363/19	Stud for water inlet pipe ($2\frac{3}{4}$ " long)	...	1			3
X287/5	" " " " ($1\frac{3}{16}$ " long)	...	1	doz.	1	6
MG348/297	Joint for cylinder jacket cover-plate	...	3			4
X110/4	Set screw for cylinder jacket cover-plate	...	18			3
X110/5	Washer for ditto	...	18	doz.		4
P287/107	Drain cock...	...	1		1	9
X287/4	Washer for ditto (fibre)	...	1	doz.		4
X348/2	Stud for cylinder head ($4\frac{9}{16}$ " long)	...	1		1	9
X348/3	" " " " ($4\frac{5}{16}$ " long)	...	1		1	9
X348/4	" " " " ($5\frac{1}{16}$ " long)	...	1			5
X348/5	" " " " ($4\frac{13}{16}$ " long)	...	7			5
X348/6	" " " " ($4\frac{15}{16}$ " long)	...	8			5
X110/93	Locating dowel for front bearing housing	...	1	doz.		9
X348/26	Stud for oil drain pipes (centre and rear)	...	4	doz.	1	0
X489/6	Stud for oil base ($4\frac{5}{8}$ " long)	...	6			4
X489/7	" " " " ($4\frac{1}{4}$ " long)	...	8			4
X489/9	Stud for oil filter case ($2\frac{1}{2}$ " long)	...	4			2
X348/8	" " " " ($1\frac{1}{16}$ " long)	...	2	doz.	1	0

BELL HOUSING AND REAR MAIN BEARING

MG489/2	Bell housing with rear main bearing	...	1		2	1	6
MG348/178	Rear main bearing (bush)	...	1		11		9
X110/13	Grub screw for rear main bearing	...	1				2
MG348/100	Bolt (bell housing to cylinder block)	...	9				8
X105/4	Washer (spring) for ditto	...	6	doz.			8
X239/4	" (copper) for ditto	...	3	doz.			6
MG489/115	Joint for bell housing	...	1				2

FRONT MAIN BEARING HOUSING AND ENGINE NOSE PIECE

MG489/3	Front bearing housing with front main bearing	...	1		3	0	6
MG420/101	Front main bearing (bush)	...	1		14		8
MG348/179	Grub screw for front main bearing	...	1				10
MG348/253	Joint for front bearing housing (.006" thick)	...	as reqd.				3
MG489/205	" " " " (.010" thick)	...	as reqd.				4
X110/11	Set screw (housing to cylinder block)	...	7				3
X105/4	Washer for ditto (spring)	...	7	doz.			8
MG348/29	Engine nose piece and front bearing housing cover	...	1		1	17	2
X363/13	Bolt for ditto	...	4				3
X105/4	Washer for ditto (spring)	...	4	doz.			8
X110/11	Set screw for ditto (securing)	...	4				3
X105/4	Washer for ditto (spring)	...	4	doz.			8
MG348/251	Joint for front bearing housing cover	...	1	doz.	1		0
828	Bush for engine mounting (rubber)	...	2 halves				4

CRANKSHAFT AND INTERMEDIATE MAIN BEARINGS AND FLYWHEEL

MG489/34	Crankshaft with plugs	...	1		8	11	3
MG348/143	Plug for crank pin (short alum.)	...	as reqd.				6
MG348/144	" " " " (long alum.)	...	as reqd.				7
MG489/210	" " " " (steel)	...	as reqd.				6
X110/23	Key for crankshaft (distributor drive gear)	...	2				3
X348/17	" " " " (dynamo drive gear)	...	1				2
MG489/116	Crankshaft flange	...	1		1	1	0
MG489/202	Nut for ditto	...	1			1	9
X110/24	Key for ditto	...	1				6
MG348/181	Thrust washer (rear) for crankshaft	...	1			1	6
MG348/273	" " (front) for crankshaft	...	1			1	6
MG348/272	Thrust ring for ditto	...	1			1	6
X348/14	Grub screw for ditto	...	1	doz.			9
MG489/117	Spiral gear for crankshaft	...	1		11		1
MG348/128	Fan pulley for crankshaft	...	1			5	3
P110/265	Nut (starting dog) for crankshaft	...	1			2	4
MG348/28	Intermediate main bearing rear (top and bottom halves)	...	1		2	2	10
X287/7	Bolt ($1\frac{3}{16}$ " long) for ditto	...	2				4
X105/3	Nut for ditto	...	2	doz.	1		3
X105/4	Washer (spring) for ditto	...	2	doz.			8
MG348/27	Intermediate main bearing front (top and bottom halves)	...	1		1	17	9
X287/7	Bolt ($1\frac{3}{16}$ " long) for ditto	...	2				4
X105/3	Nut for ditto	...	2	doz.	1		3

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
X105/4	Washer (spring) for front main bearing bolts ...	2	doz.	8	
P287/115	Bolt for bearing housing ($6\frac{1}{8}$ " long) (front and rear inter.) ...	4		1	5
MG348/300	Lock plate for ditto ...	4			3
MG489/118	Flywheel ...	1		1	9 6
MG348/148	Bolt for flywheel ...	8			7
X363/31	Nut for ditto ...	8			3
MG489/119	Spigot bearing housing for first motion shaft ...	1		7	0
X110/28	Ball bearing for ditto ...	1		8	9
CONNECTING RODS AND PISTONS					
MG348/30	Connecting rod (bushed) with cap and bolts ...	6		1	4 10
MG363/205	Bush (small end) for connecting rod ...	6		1	2
MG384/121	Bolt for connecting rod ...	12			10
984	Nut for ditto ...	12			3
MG363/4	Piston complete with rings and gudgeon } Always	6		1	0 0
MG363/211	Piston ring (compression) ... } quote size	12		1	3
MG363/212	" " (scraper) ... } when	6		1	4
MG363/202	Gudgeon pin with pads ... } ordering.	6		2	4
CYLINDER HEAD AND DETAILS					
MG489/5	Cylinder head assembly complete less manifolds and sparking plugs ...	1		22	10 0
MG489/6	Cylinder head (studded) with valve guides ...	1		7	8 9
MG489/120	Valve guides ...	12		1	2
X110/100	Stud for cylinder head cover ...	6			2
X110/6	Stud for securing camshaft front bearing housing ...	2			3
X348/21	Stud ($3\frac{1}{8}$ " long) for camshaft intermediate and rear bearing housing ...	3			2
X110/6	Stud (1" long) for ditto ...	6			3
X110/54	Stud (1" long) for securing induction manifold ...	2			3
X489/1	Stud ($2\frac{3}{8}$ " long) for securing induction manifold ...	2			2
X489/2	Stud ($2\frac{1}{8}$ " long) for securing induction manifold ...	3			2
X420/4	Stud for exhaust manifold ...	8			2
X110/20	Stud for water outlet pipe ...	6			3
X110/6	Stud for oil drain housing ...	4			3
X468/10	Stud for cylinder head front flange ...	2			3
X110/38	Core disc ...	3			4
X489/3	Plug for oil gallery ...	1			3
X348/37	Washer for ditto ...	1	doz.	1	0
X101/10	Nut for cylinder head stud ...	18	doz.	1	3
MG489/121	Inlet valve ...	6		3	0
MG489/122	Exhaust valve ...	6		3	0
1016	Valve spring (outer) ...	12			8
1015	" " (inner) ...	12			5
MG489/123	Collar for valve spring ...	12			8
P110/184	Split cotters for valves (halves) ...	24	pair	1	0
992	Valve rocker ...	12		7	2
997	Locking screw for valve rocker ...	12			2
MG363/106	Eccentric bush for valve rocker ...	12		3	4
X363/11	Spring ring for valve rocker ...	12	doz.		9
MG348/24	Valve rocker-shaft N/S ...	1		4	2
MG348/23	" " O/S ...	1		4	2
X110/47	Locking screw for ditto ...	6			3
X110/48	Washer (copper) for ditto ...	6	doz.		3
MG348/182	Distance tube ($1\frac{1}{2}$ " long) for rocker-shaft ...	4			5
MG489/124	" " ($1\frac{3}{8}$ " long) for ditto ...	4			4
MG489/125	" " ($\frac{1}{16}$ " long) for ditto ...	4			4
P110/179	" " ($\frac{3}{8}$ " long) for ditto ...	6			4
MG348/185	Belleville washers for ditto ...	12	doz.		9
X287/14	Plain washers for ditto ...	2	doz.		6
MG348/186	Steady brackets for rocker-shaft ...	2		1	9
MG348/119	Rear end support bracket for rocker-shaft ...	1		12	10
P287/145	Plug for ditto ...	2			3
X110/48	Washer for plug (copper) ...	2	doz.		3
MG489/114	Camshaft ...	1		2	3 2
X363/31	Nut (slotted) for camshaft ...	1			3
X348/25	Washer for ditto ...	1	doz.		6
2362	Tachometer drive adaptor ...	1		2	10
MG348/19	Camshaft front bearing housing with cap ...	1		19	4
X110/49	Dowel for cap ...	2	doz.		8
X348/26	Stud for cap ...	2	doz.	1	0
X101/1	Nut for ditto ...	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	doz.		8
P287/145	Plug for cap ...	1			3

Please Quote Chassis, Engine and Body Numbers in all Correspondence



MG348/175	White metal (top) for camshaft front bearing	...	2		1	0
MG348/176	White metal (front bottom) for ditto	...	1		1	0
MG348/177	White metal (rear bottom) for ditto	...	1		1	0
X101/1	Nut for securing camshaft front bearing housing	...	2	doz.	1	3
X101/2	Spring washer for ditto	...	2	doz.		8
MG348/20	Camshaft intermediate and rear bearing housing with cap	...	3		14	6
X110/49	Dowel for ditto	...	6	doz.		8
X348/26	Stud for cap	...	3	doz.	1	0
X101/1	Nut for ditto	...	3	doz.	1	3
X101/2	Spring washer for ditto	...	3	doz.		8
P287/145	Plug for cap	...	3			3
MG348/173	White metal bottom half for camshaft intermediate and rear bearing	...	3		1	6
MG348/174	White metal top half for ditto	...	3		1	6
X101/1	Nut for securing camshaft intermediate and rear bearing	...	9	doz.	1	3
X101/2	Spring washer for ditto	...	3	doz.		8
MG489/7	Bevel wheels (camshaft)	...	1 pair		1	7
X101/4	Key for camshaft	...	1			3
MG348/171	Thrust washer for camshaft	...	2		10	
MG348/172	Belleville washer for camshaft	...	2			7
P110/202	Washer for camshaft	...	1		1	0
MG348/296	Thrust washer (.112" thick) for vertical drive pinion	as reqd.			1	0
MG489/209	" (.122" thick) for vertical drive pinion	as reqd.			1	0
P110/194	Sleeve for ditto	...	1		9	0
X110/44	Roller bearing for ditto	...	2		5	10
P110/43	Retainer plate with felt for ditto	...	1		3	4
X110/90	Felt washer for bearing retainer plate	...	1			3
MG489/127	Oil thrower for camshaft drive driving pinion	...	1			4
MG348/121	Oil drain housing for camshaft drive driving pinion	...	1		6	2
X101/1	Nut for securing oil drain housing	...	4	doz.	1	3
X101/2	Spring washer for ditto	...	4	doz.		8
P110/204	Shim (.003") for vertical drive	...	as reqd.			3
P110/205	" (.005") for vertical drive	...	as reqd.			3
P110/206	" (.007") for vertical drive	...	as reqd.			3
P110/207	" (.010") for vertical drive	...	as reqd.			5
P110/208	" (.015") for vertical drive	...	as reqd.			5
P110/209	" (.020") for vertical drive	...	as reqd.			8
MG489/128	Universal joint fork for vertical drive	...	1		4	5
X110/43	Key for ditto	...	1			3
P110/198	Nut for ditto	...	1			7
P110/199	Washer for ditto	...	1	doz.		8
MG489/8	Cylinder head gasket	...	1		6	8
MG489/9	Cylinder head cover assembly	...	1		2	9
MG489/112	Cylinder head cover (bare)	...	1		2	0
MG489/109	Oil filler lid for ditto	...	1		4	2
MG489/132	Washer for ditto (sealing)	...	1			6
MG489/133	Eye bolt for cylinder head cover	...	1		3	2
MG489/134	Clamp for cover	...	1		2	10
X489/4	Joint pin for oil filler lid	...	2	doz.	1	0
X101/12	Washer for ditto	...	2	doz.		8
MG489/135	Bolt for oil filler cover clamp	...	1		2	0
X489/5	Joint pin for ditto	...	1			2
X287/17	Washer for ditto	...	1	doz.		4
MG489/136	Nut for oil filler clamp	...	1		1	0
MG489/33	Strainer for oil filler	...	1		1	4
MG348/279	Joint for cylinder head cover	...	1		2	9
MG348/16	Nut for securing cylinder head cover	...	6		1	7

INDUCTION MANIFOLD, CARBURETTERS AND EXHAUST MANIFOLD

MG489/10	Induction manifold (studded)	...	1		1	6	6
X468/4	Stud for securing carburetters	...	4	doz.	1	0	
MG468/110	Balance plug for induction manifold	...	1			7	
X468/2	Fibre washer for ditto	...	1	doz.			5
MG489/138	Joint for induction manifold	...	1		1	2	
X105/3	Nut (securing) for induction manifold	...	5	doz.	1	3	
X468/3	Lock nut (securing) for induction manifold	...	4	doz.		6	
X105/4	Washer (spring) for ditto	...	7	doz.		8	
A469	Carburetter complete with links	...	1 pair	pair	10	0	0
MG420/114	Joint for carburetter	...	2			3	
X468/3	Lock nut (securing) for carburetter	...	4	doz.		6	
MG348/126	Exhaust manifold (front)	...	1		1	2	6
MG348/127	" (rear)	...	1		1	2	6

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
MG489/139	Joint for exhaust manifold	2			8
X287/11	Nut for securing exhaust manifold	8			4
X110/37	Washer for ditto	8		doz.	8
MG348/120	Water outlet pipe... ..	1		1	3
MG348/262	Joint for ditto	3			2
X101/1	Nut for securing water outlet pipe	6		doz.	1 3
X101/2	Spring washer for ditto	6		doz.	8

DYNAMO AND VERTICAL DRIVE

X468/5	Washer for dynamo spindle	1			2
MG468/7	Universal joint fork with oil thrower for dynamo	1		6	6
P110/4	Dynamo coupling disc	1			5 6
P110/282	Packing washer for dynamo coupling (.010")	as reqd.	doz.	1	4
P110/283	" " " " (.020")	as reqd.	doz.	1	4
P110/284	" " " " (.030")	as reqd.	doz.	1	4
P110/285	" " " " (.040")	as reqd.	doz.	1	4
P110/286	" " " " (.050")	as reqd.	doz.	1	4
P110/277	Bolt for dynamo coupling	4			6
X101/1	Nut for ditto	4		doz.	1 3
X101/2	Washer for dynamo coupling (spring)... ..	4		doz.	8
MG489/204	Shim for dynamo bottom bevel wheel	as reqd.			7
P110/257	Shim for dynamo base (.003")	as reqd.			4
P110/258	" " " " (.005")	as reqd.			4
P110/259	" " " " (.007")	as reqd.			5
P110/260	" " " " (.015")	as reqd.			7
MG348/276	Shim for crankshaft bevel wheel (.003")	as reqd.			3
MG348/277	" " " " (.005")	as reqd.			3
MG348/278	" " " " (.007")	as reqd.			3
X105/14	Set screw (securing) for dynamo	4			3
X101/2	Washer (spring) for ditto	4		doz.	8
A484	Dynamo complete	1		10	0 0
MG468/8	Dynamo bottom bevel and crankshaft bevel wheels	1 pair	pair	1	13 2
MG468/114	Tab washer for bottom bevel wheel	1		doz.	1 2

WATER PUMP DETAILS

MG489/11	Water pump assembly	1		2	7 10
MG348/35	Water pump body (studded)... ..	1		16	1
X110/101	Stud for water pump cover (1 1/8" long)	4		doz.	1 0
X348/18	" " " " (2" long)... ..	2		doz.	1 0
MG348/109	Cover for water pump	1		6	8
MG348/255	Joint for ditto	1			2
X101/1	Nut for securing water pump cover	6		doz.	1 3
X101/2	Washer (spring) for ditto	6		doz.	8
MG489/140	Adaptor for water pump	1		8	3
1309	Felt retainer for ditto	1		10	0
1310	Felt washer for ditto	1			2
MG348/152	Spindle for water pump... ..	1		11	4
MG348/153	Slip washer for water pump spindle	1		1	8
MG489/141	Pinion for water pump	1		7	0
X110/43	Key for ditto	1			3
MG348/151	Rotor for water pump	1		4	2
1318	Securing bolt for ditto	1			2
1319	Tab washer for ditto	1			2
1315	Bush for water pump spindle	1		1	2
1317	Gland nut for water pump spindle	1		2	7
1316	Packing for ditto... ..	1		1	0
X420/6	Spring for ditto	1			3

X348/12	Bolt for securing water pump body	2			2
X105/4	Washer (spring) for ditto	2		doz.	8
MG348/2	Water inlet pipe	1		10	10
X105/3	Nut for securing water inlet pipe	2		doz.	1 3
X105/4	Washer (spring) for ditto	2		doz.	8
MG348/299	Hose for water inlet pipe	1			6
A399	Clip for ditto	2			1 0
P287/187	Joint for water inlet pipe	1		1	3

LUBRICATING SYSTEM

MG489/12	Oil breather	1		2	1
MG489/107	Oilbase	1		4	17 0
MG489/146	Joint for ditto	1			3 6

Please Quote Chassis, Engine and Body Numbers in all Correspondence



X101/1	Nut for securing oilbase...	...	14	doz.	1	3
X101/2	Spring washer for ditto ...	...	14	doz.		8
X110/3	Set screw for securing oilbase ...	...	4			3
MG348/197	Drain plug for oilbase ...	...	1		2	0
X348/16	Washer for ditto ...	...	1	doz.		9
MG489/35	Dipstick with knob ...	...	1		1	10
MG489/108	Adaptor for dipstick ...	...	1		3	0
X489/8	Joint for dipstick adaptor ...	...	1	doz.		6
X110/6	Stud for securing dipstick adaptor ...	...	2			3
X101/1	Nut for ditto ...	...	2	doz.	1	3
X101/2	Washer (spring) for ditto ...	...	2	doz.		8
MG489/14	Oil strainer assembly ...	...	1		10	10
P287/159	Fibre washer for oil strainer ...	...	1	doz.		0
MG489/15	Oil suction pipe (sump to pump) ...	...	1		3	10
X348/33	Washer for union ...	...	1	doz.		8
MG348/213	Union for pump ...	...	1		1	3
MG489/16	Oil pump assembly ...	...	1		1	9
MG489/110	Oil pump body ...	...	1		13	4
MG489/111	Cover for oil pump ...	...	1		5	10
MG489/153	Joint for cover ...	...	1	doz.		8
P239/109	Oil relief valve ...	...	1			7
MG348/165	Cap nut for ditto...	...	1		2	3
X363/16	Washer for ditto ...	...	1	doz.	1	4
P110/158	Spring for relief valve ...	...	1			4
MG489/154	Spindle and gear combined for oil pump ...	...	1		6	8
MG348/160	Oil pump gear (driven) ...	...	1		10	10
MG348/161	Spindle for ditto ...	...	1			5
MG489/152	Joint for oil pump body ...	...	1	doz.		8
X420/1	Set screw (1½" long) (oil pump securing) ...	...	2			7
X420/2	" " (2½" long) (oil pump securing) ...	...	2			9
X420/3	" " (2½" long) (oil pump securing) ...	...	1			9
X101/2	Spring washer for ditto ...	...	5	doz.		8
MG489/17	Main oil feed pipe (pump to filter) ...	...	1		2	1
X348/32	Union for filter and pump ...	...	2			6
X348/57	Washer for ditto (on filter) ...	...	1			2
X489/19	" " (on pump) ...	...	1	doz.		5
MG489/18	Oil filter assembly ...	...	1		1	16
MG489/19	Oil filter case (studded) ...	...	1		14	6
X348/34	Studs for securing oil filter cap ...	...	4	doz.	1	0
MG468/122	Cap for oil filter ...	...	1		4	8
MG468/123	Joint for oil filter cap ...	...	1			9
X105/3	Nut for oil filter cap ...	...	4	doz.	1	3
X105/4	Spring washer for ditto ...	...	4	doz.		8
A730	Tecalemit oil filter element ...	...	1		8	9
X348/36	Spring for element location ...	...	1	doz.	1	2
MG348/221	Socket for element ...	...	1			9
MG348/219	Oil relief valve body ...	...	1		3	6
MG348/301	Ball (oil relief valve) ...	...	1	doz.	1	3
X348/35	Spring for oil relief valve ...	...	1	doz.	1	0
MG348/220	Plug for oil relief valve ...	...	1			3
MG348/222	Plate for ditto ...	...	1	doz.	2	3
P110/106	Oil gauge tap ...	...	1		2	3
X348/39	Washer for ditto ...	...	1			1
MG489/156	Joint for oil filter case ...	...	1	doz.		8
X105/3	Nut for securing oil filter case ...	...	6	doz.	1	3
X105/4	Spring washer for ditto ...	...	6	doz.		8
MG489/20	Front bearing and cylinder head oil feed pipe ...	...	1		4	5
MG489/160	Joint for flange ...	...	1			2
X110/39	Set screw for securing flange ...	...	1			3
X110/40	Washer for ditto (fibre) ...	...	1	doz.		4
X362/3	" " (steel) ...	...	1	doz.		2
X348/29	Union for oil filter ...	...	1			4
X348/37	Washer for ditto ...	...	1	doz.	1	0
X348/29	Union for front bearing oil feed pipe...	...	1			4
X348/15	Washer for ditto ...	...	1	doz.	1	0
P287/144	Restrictor pin for cylinder head oil feed pipe ...	...	1		1	0
MG489/21	Main oil feed pipe (bearings) ...	...	1		3	10
MG489/161	Joint for ditto ...	...	3			2
X105/14	Set screw for ditto ...	...	6			3
X101/2	Washer for ditto (spring) ...	...	6	doz.		8
MG489/22	Cylinder head oil drain pipe (front) ...	...	1		5	10
X489/10	Joint for ditto (top) ...	...	1			2
X489/11	" " (bottom)...	...	1			2
X468/11	Bolt for flange ...	...	2			3
X101/1	Nut for ditto ...	...	2	doz.	1	3

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
X101/2	Spring washer for front oil drain pipe securing nut ...	2	doz.	8	
X105/14	Set screw for front oil drain pipe (bottom) ...	2		2	
X101/2	Spring washer for ditto ...	2	doz.	8	
MG489/23	Cylinder head oil drain pipe (rear) ...	1		4	7
X489/12	Joint (bottom) for ditto ...	1		2	
X489/13	" (top) for ditto ...	1	doz.	1	0
X489/21	Set screw for flange ...	1		2	
X239/4	Washer for ditto ...	1	doz.	6	
X101/1	Nuts for securing studs ...	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	doz.	8	
MG489/24	Cylinder head oil drain pipe (centre) ...	1		3	10
X101/1	Nuts for securing ditto ...	2	doz.	1	3
X101/2	Spring washer for ditto ...	2	doz.	8	
X489/13	Top joint for ditto ...	1	doz.	1	0
X489/12	Bottom joint for ditto ...	1		2	
X489/21	Set screw for ditto ...	1		2	
X239/4	Washer for ditto ...	1	doz.	6	
ENGINE ELECTRICAL DETAILS					
A375	Starter (4-brush) complete with solenoid ...	1		6	2 0
X489/20	Set screw for securing starter ...	1			3
X110/12	Bolt for securing starter ...	2			3
X101/10	Nut for ditto ...	2	doz.	1	3
X101/11	Spring washer for ditto ...	3	doz.	8	
A466	Distributor ...	1		2	17 6
X287/13	Securing set screw for distributor ...	1			2
X101/2	Spring washer for ditto ...	1	doz.	8	
MG489/168	Distributor adaptor ...	1		6	1
MG489/169	Oil pump and distributor drive gear ...	1		9	4
X110/3	Set screw for securing distributor adaptor ...	1			3
X101/2	Spring washer for ditto ...	1	doz.	8	
CLUTCH DETAILS					
MG491/2	Clutch cover complete ...	1		19	6
MG491/112	Fulcrum pad for clutch cover ...	4			4
MG491/113	Rivets for ditto ...	8	doz.	6	
MG491/107	Fulcrum bracket for operating disc spring ...	4		8	
MG491/113	Rivets for ditto ...	8	doz.	6	
MG477/114	Clutch spring ...	12		4	
MG491/121	Clutch pressure plate ...	1		18	9
MG477/104	Clutch driving bolt ...	4		1	1
MG477/105	Nut for ditto ...	4			2
MG477/106	Spring for ditto ...	4			2
MG491/100	Clutch operating pin ...	4		1	3
MG491/101	Lever (clutch withdrawal) ...	4		4	3
MG491/122	Fulcrum pin for ditto ...	4		8	
MG491/120	Washer for ditto ...	8			1
MG491/102	Adjusting screw for lever ...	4			6
MG491/118	Nut for ditto ...	4			1
MG491/3	Clutch plate complete (driven) ...	1		1	6 6
MG491/4	Clutch operating disc ring complete ...	1		6	1
MG491/104	Lining for ditto ...	1			1 10
X491/1	Rivets for ditto ...	4	doz.	6	
MG491/105	Retaining spring for clutch operating disc ring ...	4			2
MG491/106	Fulcrum pin for ditto ...	4		1	2
MG491/108	Withdrawal race ...	1		14	3
MG491/109	Sleeve for ditto ...	1		5	4
S1/7	Greaser for ditto ...	1			3
MG491/110	Clutch pedal ...	1		5	10
P110/422	Cotter pin for ditto ...	1			5
1034	Clutch operating shaft ...	1		10	10
X491/2	Bolt for securing clutch ...	8			6
X110/41	Nut for ditto ...	8			3
2569	Clutch pedal stop stud ...	1			3
1287	Adjustable stop for clutch pedal ...	1			8
1144	Return spring for clutch pedal ...	1			5
1248	Anchor bracket for ditto ...	1			4
GEARBOX DETAILS					
MG489/25	Gearbox assembly complete less clutch pedal, withdrawal and inspection cover and engine bearer tube ...	1		21	0 0
MG489/26	Clutch housing (studded) ...	1		2	1 6
X363/22	Stud for gearbox case ...	6	doz.	1	6
MG489/200	Dowel for ditto ...	2			2
P110/348	Bush for clutch withdrawal shaft O/S ...	1		3	5

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
P110/349	Bush for clutch withdrawal shaft N/S	1		1	6
X110/70	Disc for ditto	1	doz.	8	
X110/71	Set screw for bushes	2		3	
X101/2	Washer for ditto	2	doz.	8	
2332	Clutch inspection cover	1		1	4
MG489/27	Engine bearer tube (rear) assembly	1		1	0 6
MG489/170	Engine bearer tube	1		8	0
MG489/195	Collar for ditto	2		1	4
MG489/196	Bush for ditto (rubber)	2		5	10
2918	Rear engine bearer and brake pedal bracket	1		9	10
958	Rear engine bearer bracket N/S	1		7	0
959	Location screw for ditto	1		1	3
X110/9	Bolt (clutch pit to bell housing) ($1\frac{3}{16}$ " long)	6		4	
X110/11	" (clutch pit to bell housing) ($\frac{7}{8}$ " long)	2		3	
X105/3	Nut for ditto	6	doz.	1	3
X105/4	Washer for ditto	8	doz.	8	
MG489/28	Gearbox case (studded)	1		1	3 0
X363/12	Stud for top cover	4		2	
X363/19	Stud for rear end cover ($2\frac{3}{8}$ " long)	1		3	
X363/20	" " " " " ($1\frac{3}{8}$ " long)	5		3	
X363/21	" " " " " ($1\frac{3}{8}$ " long)	1		3	
MG489/200	Dowel for ditto	2		2	
P110/109	Filler plug and drain	2		1	6
X110/64	Washer for ditto (fibre)	2	doz.	3	
X105/3	Nut for securing gearbox to clutch housing	6	doz.	1	3
X105/4	Washer for ditto (spring)	6	doz.	8	
MG489/172	First motion shaft	1		1	7 2
P110/366	Oil thrower for ditto (rear)	1		4	
X110/85	Ball race for ditto	1		8	9
P110/365	Oil thrower for ditto (front)	1		4	
MG363/137	Locking nut for ditto (combined oil return)	1		3	2
X110/74	Circlip for ditto	1		3	
MG363/165	Retaining plate (for cover securing bolts)	1		5	
X363/27	Bolts for cover	4		3	
X101/1	Nuts for ditto	4	doz.	1	3
X101/2	Washer for ditto	4	doz.	8	
X110/75	Sealing washer for cover	1		6	
MG363/164	Cover for first motion shaft	1		3	4
MG363/140	Mainshaft	1		13	4
X363/23	Roller bearing spigot	1		4	9
MG363/138	Distance washer for ditto	1		1	3
MG489/173	Third and top speed sliding gear	1		15	3
MG489/29	First and second speed sliding gear assembly	1		1	9 6
MG489/176	Bolt for ditto	4		5	
X105/3	Nut for ditto	4	doz.	1	3
X110/86	Ball race, mainshaft (rear)	1		11	6
MG363/179	Retaining plate for ditto	1		6	
X112/1	Bolts for ditto	2		3	
X105/3	Nuts for ditto	2	doz.	1	3
X105/7	Set screw for ditto	1		3	
X105/4	Spring washer for ditto	3	doz.	8	
MG489/177	Gear (driving) (speedometer)	1		3	10
MG489/178	" (driven) (speedometer)	1		4	5
P110/389	Thrust button for ditto	1		1	0
P110/409	Bearing for ditto	1		8	9
X110/80	Joint for ditto	1		4	
MG363/177	Rear cover	1		18	4
X105/3	Nuts for securing ditto	7	doz.	1	3
X105/4	Spring washers for ditto	7	doz.	8	
MG363/139	Propeller shaft flange	1		9	4
X105/12	Nut for ditto	1		3	
X105/13	Washer for ditto	1		3	
MG363/141	Layshaft	1		5	0
X363/23	Roller bearing	2		4	9
MG363/138	Distance washer for ditto	4		1	3
MG489/179	Constant mesh gear	1		14	3
MG363/152	Spring retaining ring for ditto	2	doz.	1	8

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
MG489/180	Third speed constant mesh gear	1		17	6
MG363/148	Rollers for ditto ...	23			2
MG363/149	Washers for ditto...	2			3
MG363/150	Spring retaining ring for ditto...	1	doz.	1	4
MG489/181	First and second layshaft gear...	1		1	8 2
P110/362	Locking screw for layshaft	1			2
X101/2	Washer for ditto ...	1	doz.		8
X489/17	Oil retaining washer for layshaft	1			2
MG489/197	Washer for ditto ...	1			2
X489/18	Set screw for securing ditto	1	doz.	1	0
MG489/198	Tab washer for set screw	1	doz.	1	0
MG489/203	Reverse shaft	1			2 9
MG363/24	Reverse gear (sliding) (bushed)	1		12	10
MG363/154	Bush for reverse gear	1			2 3
X101/10	Nut for reverse shaft	1	doz.	1	3
X363/24	Washer for ditto ...	1	doz.		8
MG489/188	Selector shaft (first and second)	1		3	7
MG489/189	Selector fork (first and second)	1		5	0
MG412/120	Selector shaft distance piece for ditto (rear) ...	1			4
MG489/190	" " " " " (front)...	1			8
MG489/191	Selector shaft (third and fourth)	1		3	2
MG489/192	Selector fork (third and fourth)	1		3	2
X110/84	Balls for selector fork	2	doz.	1	6
X363/28	Spring for ditto	2			3
MG489/212	Selecting lever (reverse)	1		5	8
MG363/156	Selecting lever fulcrum pin for ditto	1			8
X101/10	Nut for ditto	1	doz.	1	3
X101/11	Washer for ditto	1	doz.		8
MG363/160	Socket reverse locking plunger...	1		2	0
X363/25	Nut for ditto...	1			2
X363/26	Washer for ditto	1	doz.		8
MG363/161	Plug for socket	1			3
MG363/162	Plunger (reverse) (locking)	1			10
MG363/163	Spring for ditto	1			11
MG363/159	Selector shaft reverse	1		1	6
MG363/157	Selector fork reverse	1		1	8
MG363/158	Distance piece for ditto...	1			3
MG363/178	Selector shaft locking screw	1			3
MG363/8	Interlock assembly (change speed)	1		3	0
GEARBOX REMOTE CONTROL DETAILS					
MG489/30	Remote control assembly (gearbox)...	1		2	10 0
MG489/31	Housing (change speed) assembly	1		1	3 6
X110/38	Disc for ditto	2			4
P110/404	Locating peg for lever	1	doz.		2
MG489/32	Gate assembly for change speed	1		6	1
MG489/184	Stop (reverse)	1		1	6
X412/4	Hinge pin for ditto	1			2
X489/15	Washer for ditto	1	doz.		3
MG489/211	Spring for stop	2			3
X489/16	Screw for ditto	1	doz.		6
MG363/198	Shims for change speed gate	as reqd.	doz.	1	2
X110/39	Bolts for fixing gate	3			3
X101/2	Washers for ditto...	3	doz.		8
MG489/186	Lever (change speed)	1		7	2
MG489/187	Knob for ditto	1		1	5
X363/30	Lock nut for ditto	1			2
2747	Spring (anti-rattle) for lever	1			5
MG363/189	Lever (shaft actuating)	1		4	6
X363/34	Set screw for ditto	1			3
X101/2	Washer for ditto	1	doz.		8
MG363/23	Shaft (change speed)	1		7	6
MG489/213	Lever (selector)	1		5	4
X101/4	Key for ditto	1			3
X363/31	Nut for selector lever	1			3
X363/32	Washer for ditto	1	doz.		4
MG363/182	Tray for housing	1		1	6
X110/82	Screw for ditto	2	doz.		7
X101/1	Nuts for securing remote control to gearbox	4	doz.	1	3
X101/2	Spring washer for ditto	4	doz.		8

Please Quote Chassis, Engine and Body Numbers in all Correspondence

**BRAKE GEAR**

2009	Brake pedal	1		5	10
1007	Fulcrum pin for pedal	1			9
1365	Rollers for ditto	23	set	1	9
P245	Brake push rod	1		5	7
933	Clevis pin for ditto	2			6
269	Brake pedal return spring	1			3
270	Anchor bracket for ditto	1			7
P336	Brake cross shaft assembly	1		2	8 4
842	Roller bearing retainer for brake cross shaft N/S	1			2 6
841	Roller for ditto	32	set	2	6
844	Blanking disc for brake cross shaft	1			3
860	Foot brake adjusting rod	1		1	6
858	Clevis pin for ditto	1			4
846	Nut for adjusting rod	1		2	9
849	Knob for hand brake lever	1		1	3
853	Screw for knob	1			4
852	Spring for hand brake pawl	1			4
854	Hand brake pawl rod	1			8
856	Hand brake pawl screw	2			8
855	Hand brake pawl stud	1			4
857	Hand brake lever ratchet pawl	1		2	2
845	Hand brake adjusting rod	1		2	11
851	Clevis pin for hand brake lever rod	1			4
846	Hand brake adjusting nut	1		2	9
838	Bush for brake cross shaft	1		1	6
922	Trunnion for brake cross shaft	2			8
1071	Fibre washer for ditto	2			4
1791	Steady bracket for brake cross shaft	1		10	1
877	Hand brake ratchet	1		4	2
878	Hand brake lever stop	1		2	2
2933	Rubber buffer for ditto	1	doz.	1	8
1051	Hand brake lever return spring	1			3
2767	Return spring for brake cross shaft	1	doz.	1	4
2764	Clip for ditto	1			5
270	Anchor bracket for ditto	1			7
P337	Front brake cable assembly	2		1	0 2
P338	Rear brake cable assembly	2		1	0 2
1806	Concertina type rubber for brake cables	4			9
P109/100	Clevis pin for brake cables	4			3
S2/20	Clip for rear brake cables (on springs)	2			3
1963	Rubber ferrule for ditto	2		2	0

CONTROLS

MG577	Accelerator cross shaft assembly	1		1	2 6
1969	Jet control return spring (on cross shaft)	1			4
2322	Accelerator pedal stop	1			6
265	Accelerator return spring	1			4
1248	Anchor bracket for ditto	1			2
P122	Ball jointed coupling for throttle control	1		1	4
2950	Slow-running rod	1		1	3
2952	Knob for ditto	1			6
3047	Rubber bush for ditto	1			2
2953	Instruction plate for slow running and mixture control	1			6
132	Spring for slow-running rod	1			7
1110	Bracket for ditto	1		1	0
2951	Jet control rod	1		1	3
2952	Knob for ditto	1			6
3047	Bush for ditto	1			2
1111	Anti-rattle spring for ditto	1	doz.	1	4
2328	Jet control connecting rod	1			2
1111	Anti-rattle spring for ditto	1	doz.	1	4
181	Yoke end for rod	1			6
2934	Clevis pin for ditto	1	doz.	1	0

STEERING GEAR

MG512	Steering gear unit less wheel	1		6	15 0
MG512/4	Inner column with top end and cam assembled	1		1	15 0
MG512/5	Inner column	1			15 10
MG443/103	Steering cam	1		18	5
MG429/124	Rubber ring for inner column	1			3
MG443/100	Steering box	1		14	4
MG429/105	Ball cup for cam	2		2	7
MG429/104	Ball cage for ditto with balls	2		3	0

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	MG	DESCRIPTION	MG	No. Used	Price Each		
					Saloon	£	s. d.
MG429/103		Rocker-shaft		1		13	0
MG429/102		Peg for ditto		1		4	8
MG512/100		Oversize peg for ditto		1		7	0
MG429/106		Side cover		1		4	0
MG429/107		Shim for ditto (.0024")		as reqd.		4	
MG429/108		" " " (.005")		as reqd.		4	
MG429/109		" " " (.010")		as reqd.		5	
MG429/110		Joint for ditto		1		2	
MG429/111		Bolt for ditto		3			3
MG429/112		Drop arm		1		10	8
MG429/113		Washer for ditto		1			6
MG429/114		Pinch bolt for drop arm		1			3
MG512/107		Outer column		1	1	3	0
MG512/108		Flange for ditto		1		4	0
MG429/119		Shim for end cover (.0024")		as reqd.		4	
MG429/120		" " " (.005")		as reqd.		4	
MG429/121		" " " (.010")		as reqd.		5	
MG512/102		Joint for end cover		1		2	
MG512/103		Bolt for ditto		2			3
MG429/127		Retaining ring for steering column top bush		1			4
MG429/126		Bush for steering column top (felt)		1		10	
MG512/104		Key for steering wheel		1		10	
A727		Steering wheel		1	2	2	0
1919		Steering column clamp		1		2	2
2064		Steering column support bracket		1		2	9

RADIATOR AND CONNECTIONS

MG558	Radiator complete	1	14	0	0
MG475/1	Radiator case with medallion	1	6	17	6
P214/105	M.G. medallion for radiator case	1		5	0
P341/102	Radiator stoneguard	1	1	3	6
MG444/102	Headlamp mounting lug... ..	2		2	5
2626	Rubber moulding for headlamp mounting lug	2			4
MG444/103	Tie bar for ditto	1	1		6
MG444/104	Studs for securing cylinder head to radiator bracket	6			2
MG444/106	Bonnet hinge rod bracket	1			8
P214/109	Radiator stay rod lug	2			8
P282/100	Radiator drain tap	1	1		9
P214/103	Fibre washer for ditto	1			2
S23/3	Bonnet rest rubber (6' long)	1	1		2
P214/100	Radiator filler cap	1	12		0
P214/101	Rubber ring for ditto	1			7
1066	Radiator mounting washer (fibre)	3			3
130	" " " (steel)	2	doz.	1	6
2713	Cylinder head to radiator bracket	1	4		3
1980	Radiator stay rod	2			9
1069	Fork end for ditto	4			6
1068	Radiator stay rod eye bolt (through dash panel)	2			4
1977	Water hose connection (top)	1	1	11	
A332	Clip for ditto	2			9
1979	Water hose connection (bottom)	1	1		6
A110	Clip for ditto	2			10

EXHAUST SYSTEM

1991	Front exhaust pipe	1	17		2
1993	Exhaust pipe gasket	2			5
A371	Silencer	1	1	3	0
1868	Silencer clip	2			6
1865	Bracket for silencer clip... ..	2			8
831	Fume excluder clip	2			8
3173	Exhaust pipe (rear)	1	12		10
1992	Clip for exhaust pipe (rear)	1			2

PETROL TANK AND PIPES

MG581	Petrol tank	1	2	18	0
MG581/100	Main feed pipe adaptor with copper tube attachment	1		1	10
MG581/101	Reserve feed pipe adaptor with gauze attachment	1		2	9
P214/103	Fibre washer for ditto	2			2
1464	Cap for petrol tank	1	4		2
1196	Petrol pipe (tank to main pipe)	1		2	3
1197	" " (tank to reserve pipe)	1		2	6
S3/2	1/4" gas cone to cone connector	2			6
2014	Petrol pipe (main pipe)	2	3		11
S3/2	1/4" gas cone to cone connector	2			6
1859	Petrol pipe (main pipe to petrol tap)... ..	2	2		3

Please Quote Chassis, Engine and Body Numbers in all Correspondence



		Saloon	£	s.	d.
MG476	Petrol tap with remote control	1	12	0	
MG476/2	Petrol tap (less remote control)	1	7	8	
MG476/100	Knob for control rod	1	2	6	
MG476/101	Fixing plate on facia panel	1	1	10	
3063	Bracket for petrol tap remote control (on facia)	1	11		
MG476/102	Petrol tap control rod	1	8		
MG476/103	Actuating washer for control rod	1	1	0	
1112	Rubber buffer for control rod	2	3		
2320	Securing bracket for petrol tap on dash panel	1	3		
2865	Petrol pipe (tap to pump)	1	1	0	
A444	Petrol pump	1	2	10	0
A568	Petrol pipe (pump to rear carburetter)	1	4	2	
A614	" " (between carburetters)	1	4	9	
1415	Distance piece for rear petrol pipe clip	1	2		
S2/19	Petrol pipe and Tecalemit clip... ..	3	4		
S2/23	Petrol pipe clip (double, centre fixing)	1	7		
S2/9	" " " (double, end fixing)	2	4		
ACCESSORIES AND SUNDRIES					
A333	Wheels (19"×2.50" well-base) (unpainted)	5	2	2	0
1123	Hub cap O/S	2	9	7	
1756	" " N/S	2	9	7	
A289	Licence holder	1	4	0	
178	Front number-plate	1	2	4	
1124	Rear number-plate	1	2	4	
1914	Instruction plate for foot brake adjuster	1	6		
MG541	Front shock absorbers	1 pair	2	5	0
A650	Shock absorber (less arms and pins)	2	1	18	0
MG402/100	Shock absorber arm (bushed)	2	5	0	
MG402/102	Bolt for ditto with nut and spring washer	2	2	0	
MG541/100	Shock absorber mounting pin with nut	2	2	0	
MG402/103	Shock absorber mounting stud... ..	2	2	0	
2777	Mounting plate for front shock absorber O/S	1	2	0	
2778	" " " " " " " N/S	1	2	0	
MG560	Rear shock absorbers	1 pair	1	16	6
A697	Rear shock absorber (less arms and pins)	2	1	10	6
MG560/3	Shock absorber arm (bushed) with connecting link and mounting pin O/S	1	16	3	
MG560/4	Shock absorber arm (bushed) with connecting link and mounting pin N/S	1	16	3	
MG560/105	Cotter pin for securing arm	2	8		
3002	Spare sparking plug carrier	1	5	0	
MG369	Tecalemit grouped lubricating system	1	2	6	10
MG369/100	Pipe for ditto (1' 8" long) front spring rear shackle O/S to steering box	1	1	9	
MG369/101	" " " (2' 8 $\frac{3}{4}$ " long) nipples on dash to brake cables (front)	2	2	4	
MG369/102	" " " (2' 5" long) nipples on dash to front spring rear shackles	2	2	1	
P278/104	" " " (2' 11 $\frac{1}{2}$ " long) nipples on dash to brake cross shaft	2	2	9	
MG369/103	" " " (5' 5 $\frac{1}{2}$ " long) nipples on dash to rear brake cables	2	4	2	
MG369/104	" " " (3' 10" long) brake cross shaft to rear spring front shackles	2	3	0	
MG369/105	" " " (7' 1" long) brake cross shaft to rear spring rear shackles	2	5	9	
P278/109	Adjustable feed plug for steering box, rear spring front shackles and front spring rear shackle N/S	4	1	3	
P278/110	Adjustable feed plug for front spring rear shackle O/S	1	1	6	
P359/103	Open feed plug for brake cable stop bracket and rear spring rear shackles	6	1	0	
P278/118	Adjustable feed plug for brake cross shaft	2	1	9	
S1/6	Greaser nipple for propeller shaft	2	4		
S1/7	Greaser nipple for rear hubs and accelerator cross shaft	3	3		
S1/1	Greaser nipple for steering knuckles, track rod and draglink	10	8		
S1/4	Greaser nipple for front spring front shackle and track rod centre lever	3	8		
P113/110	Fibre washers (thick)	13	doz.	1	0
P113/111	" " (thin)	38	doz.	6	
P113/109	Clip for 1 pipe	4	doz.	6	
P278/111	Clip for 2 pipes	6	doz.	1	6
P278/119	Support for 3 pipes	2	4		
MG369/106	Support for 4 pipes	2	2		

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
P278/113	Bolt with nut for clips	14	doz.	2	2
P278/1	Feed plug on dash walls (1-way)	4		1	6
P278/2	" " " " (2-way)	2		1	9
1220	Instruction plate for greaser nipples on dash wall O/S	1		1	1
1221	" " " " " " " " N/S	1		1	1
DASHBOARD AND FUME EXCLUDERS					
1996	Dashboard wall O/S	1		4	0
1997	" " " " N/S	1		4	0
3106	Dash panel... ..	1	1	3	6
2980	Rubber seal dash panel to body (7' long)	1		5	6
2924	Carpet fixing plate	1		2	0
2926	Clutch housing seal (Sorbo) (2' 6" long)	1		2	9
2003	Draught excluder for steering column	1		3	7
2070	Backing plate for ditto	1			7
3252	Aluminium draught excluder block O/S	1		1	10
3253	" " " " N/S	1		1	10
2306	Under tray... ..	1		15	0
ELECTRICAL EQUIPMENT AND INSTRUMENTS					
A685	Instrument panel... ..	1		4	10
A686	Revolution counter (5") with m.p.h. in top gear	1		6	13
2792	Octagonal mask for ditto	1		1	0
A420	Revolution counter cable	1		15	0
2428	Rubber bush for ditto	1			4
A687	Oil pressure gauge	1	1	1	0
2341	Octagonal mask for ditto	1			6
1192	Pipe line for oil pressure gauge with unions... ..	1		3	6
335	Fibre washers for ditto	2			1
3066	Rubber bush for ditto	1			5
A646	Oil thermometer	1	1	5	0
X489/23	Washer for ditto (fibre)	1			1
2341	Octagonal mask for oil thermometer	1			6
A688	Petrol gauge	1	3	10	0
2341	Octagonal mask for ditto	1			6
A642	Clock	1	2	2	0
2341	Octagonal mask for ditto	1			6
A710	Mileometer... ..	1	2	10	0
A721	Mileometer cable... ..	1		15	0
A544	Mileometer angle drive box	1		10	6
A689	Secondary panel with 4 switches	1	1	1	0
A690	St. Christopher badge	1		1	11
A555	Dashlamp	2		5	0
A719	Combined horn and dipper switch arm	1	1	17	6
S27/2	Rubber bush for cable	1			3
A352	Batteries (6-volt)	2	2	16	6
A249	Cut-out and junction box	1	1	5	0
A364	Auxiliary junction box	1		3	0
A499	Ignition coil	1	1	10	0
A426	Ignition high-tension leads	1 set		9	6
2587	Wiring cover	1		1	8
A327	Harnessed cables	1 set	3	15	0
413	Rubber bush for ditto (through under tray)	1			6
2429	Rubber bush for panel cable harness	1			4
2449	Rubber bush for battery cables	2			4
A351	Headlamps... ..	1 pair	pair	9	7
2712	Nut for securing ditto	2		1	9
A500	Sidelamps with rubber packings	1 pair	pair	1	7
A405	Stop and tail-lamp	1		16	6
A493	Stop lamp switch... ..	1		2	6
S2/21	Clip for ditto on brake push rod	1			8
A563	Fog lamp	1	1	13	6
A699	Direction indicator with cable	2		15	6
A550	Horn (12-volt)	1	2	15	0
3054	Special bolt for securing ditto	1			6
A720	Windscreen wiper motor	1	2	2	0
A344	Windscreen wiper blade assembly	1		14	10
1484	Rubber bush for windscreen wiper cable	1			7
A389	Driving mirror with bracket	1		13	6
S2/1	Wiring clip (single) ($\frac{3}{8}$ " dia.)	1			3
S2/2	" " (single) ($\frac{3}{8}$ " dia.)	8			3
S2/3	" " (single) ($\frac{1}{4}$ " dia.)	8			3
S2/5	" " (single) ($\frac{11}{16}$ " dia.)	5			4
S2/6	" " (single) (1" dia.)	3			5
S2/12	Binding clip	22			4
S2/4	Wiring clip (single) ($\frac{11}{16}$ " dia.)	2			4

**BONNET, WINGS AND FAIRINGS**

1825	Front wing O/S (unpainted)	...	...	1	2 18 6
1826	" " N/S (unpainted)	...	...	1	2 18 6
2991	Front wing support stay	...	...	2	9 4
S17/4	Silentbloc for ditto	...	...	2	3 4
2992	Top bracket for wing stay	...	...	2	1 0
2853	Headlamp bracket O/S	...	...	1	13 1
2854	" " N/S	...	...	1	13 1
2585	Rubber packing for ditto (interior)	...	...	2	3
2586	" " " (external)	...	...	2	7
2751	Bolt for headlamp bracket	...	...	2	9
2563	Rubber packing for sidelamps	...	...	2	3
1828	Rear wing O/S (unpainted)	...	...	1	1 8 8
1829	" " N/S (unpainted)	...	...	1	1 8 8
1986	Running-board O/S	...	...	1	16 9
2065	" " N/S	...	...	1	16 9
2898	Stiffening strip for ditto	...	...	4	1
2590	Step channelling for running-boards (36 $\frac{1}{2}$ " long)	...	...	2	4 8
2590	" " (25" long)	...	...	2	3 3
2591	Rubber for ditto (36 $\frac{1}{2}$ " long)	...	...	2	2 4
2591	" " (25" long)	...	...	2	1 8
3071	Rubber moulding between wing and running-board O/S	...	...	1	1 4
3072	" " " " " N/S	...	...	1	1 4
2020	Front fairing (unpainted)	...	...	1	17 4
P214/105	M.G. medallion for ditto	...	...	1	5 0
S23/1	Rubber strip (on side members) (18" long)	...	...	2	5
S23/1	" " (between radiator and fairing) (30" long)	...	...	1	9
380	Plain washers for front fairing (C. plated)	...	...	4	4
361	Dome nuts for front fairing (C. plated)	...	...	4	6
3052	Bracket for horn and foglamp	...	...	2	5 4
2586	Rubber packing for ditto	...	...	2	6
3174	Badge bar	...	...	1	4 2
MG582	Bonnet (unpainted)	...	...	1	3 3 0
MG582/100	Bonnet top O/S	...	...	1	19 3
MG582/101	" " N/S	...	...	1	19 3
MG582/102	Bonnet top hinge rod	...	...	1	1 7
MG582/103	Bonnet side O/S	...	...	1	1 4 10
MG582/104	" " N/S	...	...	1	1 4 10
MG582/105	Bonnet side hinge rod	...	...	2	1 7
259	Bonnet rod lug	...	...	1	8
2062	Bonnet rod lug bracket	...	...	1	6
380	C.P. washers for bonnet boards	...	...	4	4
2321	Bracket for bonnet rest	...	...	2	6
MG516	Bonnet fastener complete	...	...	2 pair	5 0
A584	Bonnet fastener less handle	...	...	2 pair	2 6
MG516/100	Handle for bonnet fastener	...	...	2 pair	2 6
B223/152	Bonnet board O/S	...	...	1	1 5 0
B223/153	" " N/S	...	...	1	1 5 0
B223/100	Aluminium rear bonnet rest O/S	...	...	1	7 0
B223/101	" " " " N/S	...	...	1	7 0
S23/3	Rubber strip for ditto (9")	...	...	1	1 10
3250	Fillet for bonnet board O/S	...	...	1	2 0
3251	" " " " N/S	...	...	1	2 0

PROPELLER SHAFT SHROUD AND FOOT WELLS

3131	Propeller shaft shroud	...	...	1	18 0
1841	Platform for propeller shaft shroud (front)	...	...	1	11
1814	Support block for ditto	...	...	1	1 10
1815	" U " clip for ditto	...	...	1	5
3129	Foot well O/S	...	...	1	15 0
3130	" " N/S	...	...	1	15 0
3175	Filler strip for foot well O/S	...	...	1	2 3
3176	" " " " N/S	...	...	1	2 3

SPARE WHEEL CARRIER DETAILS

2522	Spare wheel trough	...	...	1	7 9
2528	Support bracket for spare wheel trough O/S	...	...	1	1 8
2529	" " " " N/S	...	...	1	3 10
1950	Spare wheel hub	...	...	1	14 7
1982	Spare wheel lock nut	...	...	1	16 0

BODY MOUNTING DETAILS

1812	Front body bracket	...	...	2	11
2004	Body bracket on 3rd cross tube	...	...	2	5 0

Part No	MG	DESCRIPTION	MG	No. Used	Price Each		
					Saloon	£	s. d.
1813		Rear body bracket		2		2	1
1814		Support block for ditto (aluminium)		2		1	10
1815		" U " clip for ditto		2			5
1408		Rear mounting plates for body		4			7

BODY DETAILS

B259	Body (complete)						Price on application
------	-----------------	--------	--	--	--	--	----------------------

DOOR LOCKS AND HINGES

B259/2	Front door (upholstered) less fittings and glass O/S	...	1	19	10	0
B223/162	Front door hinge (top) O/S	...	1	11	6	
B223/163	" " (bottom) O/S...	...	1	2	0	
B223/118	Hinge pins	...	2		6	
B223/144	Front door lock complete with safety locking lever O/S	...	1	9	6	
B223/168	Door lock bolt locating plate with bush	...	2	8	10	
B223/155	Side cover-plate for ditto (top) (on door)	...	1	1	0	
B223/172	Door lock striking plate...	...	2	2	0	
B223/124	Door handle (outside) O/S	...	1	5	0	
B223/120	" " (inside) O/S	...	1	4	0	
B223/173	Remote control fitting for ditto O/S	...	1	7	0	
B223/115	Door check strap	...	1	2	0	
B223/139	Door glass (fixed) O/S (front)	...	1	15	0	
B223/138	" " (sliding) O/S (front)	...	1	16	7	
B223/175	Window pull (front) O/S	...	1	4	2	
A582	Anti-rattle fitting for glass	...	1	4	0	
B237/126	Door pull	...	1	4	0	
B259/3	Front door (upholstered) less fittings and glass N/S	...	1	19	10	0
B223/164	Front door hinge (top) N/S	...	1	11	6	
B223/165	" " (bottom) N/S	...	1	2	0	
B223/118	Hinge pins...	...	2		6	
B223/166	Front door lock complete N/S	...	1	9	6	
B223/168	Door lock bolt locating plate with bush	...	2	8	10	
B223/155	Cover-plate for ditto (top) on door	...	1	1	0	
B223/172	Door lock striking plate...	...	2	2	0	
B223/14	Door handle (outside) N/S (with key)	...	1	15	0	
B223/199	Keys for ditto (pattern or lock to be supplied with order)	...	2	2	0	
B223/119	Door handle (inside) N/S (front)	...	1	4	0	
B223/174	Remote control fitting for ditto	...	1	6	0	
B223/115	Door check strap...	...	1	2	0	
B223/139	Door glass (fixed) N/S (front)	...	1	15	0	
B223/138	" " (sliding) N/S (front)	...	1	16	7	
B223/176	Window pull (front) N/S	...	1	4	2	
A582	Anti-rattle fitting for glass	...	1	4	0	
B237/126	Door pull	...	1	4	0	
B259/4	Rear door (upholstered) less fittings and glass O/S	...	1	17	10	0
B223/117	Rear door hinge (top) O/S	...	1	2	2	
B223/160	" " (bottom) O/S...	...	1	1	8	
B223/198	Hinge pins for ditto	...	2		6	
B223/179	Rear door lock complete O/S	...	1	9	6	
B223/168	Rear door lock bolt locating plate with bush	...	2	8	10	
B223/155	Cover-plate for ditto (top)	...	1	1	0	
B223/172	Door lock striking plate...	...	2	2	0	
B223/122	Rear door handle (inside) O/S	...	1	4	0	
B223/115	Door check strap (7")	...	1	2	0	
B223/137	Rear door glass (fixed) O/S	...	1	9	8	
B223/136	" " (sliding) O/S	...	1	9	11	
A582	Anti-rattle fitting for ditto	...	1	4	0	
B223/177	Window pull (rear) O/S	...	1	4	10	
B259/5	Rear door (upholstered) less fittings and glass N/S	...	1	17	10	0
B223/116	Rear door hinge (top) N/S	...	1	2	2	
B223/161	" " (bottom) N/S	...	1	1	8	
B223/198	Hinge pins	...	2		6	
B223/180	Rear door lock complete N/S	...	1	9	6	
B223/168	Rear door lock bolt locating plate with bush	...	2	8	10	
B223/155	Cover-plate for ditto (top)	...	1	1	0	
B223/172	Door lock striking plate	...	2	2	0	
B223/121	Door handle (inside) N/S (rear)	...	1	4	0	
B223/115	Door check strap	...	1	2	0	
B223/137	Rear door glass (fixed) N/S	...	1	9	8	
B223/136	" " (sliding) N/S	...	1	9	11	
A582	Anti-rattle fitting for ditto	...	1	4	0	
B223/178	Rear window pull N/S	...	1	4	10	

Please Quote Chassis, Engine and Body Numbers in all Correspondence

Part No.



DESCRIPTION



No. Used

Price Each

Saloon

£ s. d.

SEATS AND FITTINGS

B259/6	Front seat complete with slides O/S	...	...	1	7	10	0
B259/101	Front seat tubular frame with seat pan support bracket less slides O/S	...	...	1	5	10	0
B224/200	Seat adjusting slide on floorboard	...	...	1	3	4	
2540	Distance washer for ditto	...	...	3		2	
B223/181	Cross tube for frame with channel slide O/S	...	...	1	2	3	
B224/197	Plunger for ditto	...	...	1		9	
B224/198	Spring for ditto	...	...	1		5	
B224/167	Knurled thumb screw for ditto	...	...	1	1	2	
B223/183	Spring hand lever for adjusting seat	...	...	1	3	9	
B224/163	Front seat slide (rear) on floorboard	...	...	2	8	0	
B259/104	Front seat pan O/S	...	...	1	1	12	0
B259/103	Airbag for front seat	...	...	1	14	0	
B259/7	Front seat complete with slides N/S	...	...	1	7	10	0
B259/102	Front seat tubular frame with seat pan support bracket less slides N/S	...	...	1	5	10	0
B224/200	Seat adjusting slide on floorboard	...	...	1	3	4	
2540	Distance washer for ditto	...	...	3		2	
B223/182	Cross tube for frame with channel slide N/S	...	...	1	2	3	
B224/197	Plunger for ditto	...	...	1		9	
B224/198	Spring for ditto	...	...	1		5	
B224/167	Knurled thumb screw for ditto	...	...	1	1	2	
B223/183	Spring hand lever for adjusting seat	...	...	1	3	9	
B224/163	Front seat slide (rear) on floorboard	...	...	2	8	0	
B259/105	Front seat pan N/S	...	...	1	1	12	0
B259/103	Airbag for front seat	...	...	1	14	0	
2523	Seat to floorboard fixing plate (top)	...	...	2	1	2	
2524	" " " " (bottom)	...	...	2	1	2	
B259/106	Rear seat pan	...	...	1	2	10	0
B223/186	Locating bracket for ditto	...	...	2	1	6	
B223/187	Knurled thumb screw for ditto	...	...	2	1	6	
B259/107	Airbag for rear seat cushion	...	...	2	14	6	
B259/108	Airbag for rear seat back rest	...	...	2	15	0	
B259/109	Upholstery for rear seat...	...	...	1	16	0	0
B259/110	Staples for securing ditto	...	...	2			4

FACIA PANEL

B259/8	Facia panel (drilled) with beading and pockets	...	...	1	3	5	0
B259/112	Pockets for facia panel	...	...	2	4	0	
B259/113	C.P. beading round pockets	...	...	2	lengths	3	0
B259/114	C.P. beading along bottom of panel	...	...	1	length	3	0

FLOORBOARDS AND CARPETS

B259/115	Floorboard (front) O/S	...	...	1	10	0	
B259/116	" (front) N/S	...	...	1	10	0	
B259/117	" (centre) O/S	...	...	1	7	0	
B259/118	" (centre) N/S	...	...	1	7	0	
B259/119	" (in bottom of inner foot well) O/S	...	...	1	5	0	
B259/120	" (in bottom of inner foot well) N/S	...	...	1	5	0	
B259/121	" (between inner and outer foot well) O/S	...	...	1	5	0	
B259/122	" (between inner and outer foot well) N/S	...	...	1	5	0	
B259/123	" (on outside of outer foot well) O/S	...	...	1	4	6	
B259/124	" (on outside of outer foot well) N/S	...	...	1	4	6	
B259/125	Rearmost floorboard O/S	...	...	1	5	0	
B259/126	" " N/S	...	...	1	5	0	
B259/127	Passenger foot slope	...	...	1	5	0	
2886	Bracket for foot slope	...	...	1		3	
B259/141	Scuttle carpet N/S	...	...	1	1	6	
B259/128	Carpet (gearbox)	...	...	1	2	0	0
B223/156	Rubber mat for ditto and passenger foot slope	...	...	2	2	0	
B259/129	Cover for propeller shaft shroud	...	...	1	1	15	0
B259/130	Centre carpet O/S	...	...	1	13	0	
B259/131	" " N/S	...	...	1	13	0	
B259/132	Footwell carpet O/S	...	...	1	13	0	
B259/133	" " N/S	...	...	1	13	0	
B259/134	Rear carpet O/S	...	...	1	7	0	
B259/135	" " N/S	...	...	1	7	0	
B259/140	Scuttle carpet O/S	...	...	1	1	6	

Please Quote Chassis, Engine and Body Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used	Price Each		
			Saloon	£	s. d.
WINDSCREEN SLIDING ROOF AND LUGGAGE LID					
B223/2	Windscreen complete with glass	1	8	2	6
B223/1	Windscreen frame complete	1	5	15	0
B223/135	Windscreen glass	1	2	5	8
B223/192	Windscreen rubber surround	1	4	6	
A573	Windscreen winder complete	1	1	13	0
S35/1	Corrugated rubber tube for windscreen winder chain (13" long)	1	1	0	
2896	Support bracket for ditto	1		9	
2897	Fixing strip for ditto	1		3	
B223/140	Rear light glass	1	16	10	
A737	Interior light complete with switch combined	1	6	6	
B239/156	Adjusting clamp bracket for sliding roof	2	1	6	
B239/157	Slides for ditto	2		5	
B239/158	Leather washers for ditto	4		1	
B239/159	Cup washers for ditto	2		3	
B239/160	Knurled thumb screw for ditto	2		8	
B223/127	Centre pull handle for sliding roof	1	1	7	
B259/136	Runner for sliding roof (inside)	2		4	0
B259/137	" " " " (outside)	2		2	8
B223/13	Luggage lid panel complete	1	8	15	0
B223/195	Support for luggage lid panel O/S	1		8	0
B223/196	" " " " N/S	1		8	0
B224/153	Luggage lid lock	2		3	0
B224/154	Key for ditto	1		1	0
B224/151	Escutcheon plate for ditto	2		1	4
B224/155	Staples for luggage lid	8		1	0
B223/197	Luggage lid hinge	2		9	0
B259/1	Toolbox (bulkhead section) complete	1	1	19	0
B259/100	Motif for rear of body	1		5	6
TOOL ROLL					
P330/100	Tool roll	1	4	0	
P330/101	Screwdriver (10")	1	1	6	
P330/103	Adjustable spanner	1	2	8	
P330/104	Pliers (6" pair)	1	1	0	
P330/113	Spanner ($\frac{1}{4} \times \frac{3}{16}$ " double-ended)	1		6	
P330/114	" ($\frac{3}{8} \times \frac{5}{16}$ " double-ended)	1		10	
P330/115	" ($\frac{1}{2} \times \frac{7}{16}$ " double-ended)	1	1	3	
1733	Contact breaker spanner with .015" feeler gauge	1		6	
1734	Grease gun (for group system)	1	10	6	
1735	Tyre pump	1	7	0	
P330/117	Hammer for Rudge hubs	1	6	6	
A288	Grease gun (for propeller shaft)	1	6	0	
2368	Cylinder head spanner	1	2	6	
2372	Plug spanner	1	2	9	
1959	Spanner ($\frac{1}{8}$ " Whit. single-ended)	1		10	
1736	Jack with handle (Shelley double-lift type)	1	1	1	0
2742	Sump drain plug spanner	1		1	3
2801	Box spanner ($\frac{1}{4}$ " Whit.)	1		11	
2802	" " ($\frac{7}{16}$ " Whit.)	1	1	3	
3070	" " ($\frac{9}{16}$ " Whit.) (for rear axle oil filler)	1	1	3	
2860	Tommy bar for Part Nos. 2801/2 and 3070	1		2	
2867	Tappet spanner with .006" feeler gauge	1	1	0	
2008	Starting handle	1		5	6
2955	Clip for ditto	1		4	

Telephone : 251 (4 lines)

Telegrams : " EMGEE "



Governing Director - - - - - LORD NUFFIELD
Managing Director - - - CECIL KIMBER, M.I.A.E.