

**THE SPARE PARTS
LIST FOR**

THE



MAGNA

(L Type)

THE M.G. MAGNA "L" TYPE

1933 MODELS

When ordering replacements it is of the greatest assistance to our Service Department if the part required is given its correct reference number and description, and the chassis and engine numbers should be quoted in all correspondence as well as on the order itself, as delay and misinterpretation of orders are thus avoided.

We would also draw your attention to the fact that you will get quicker service if you place all your orders with our Distributors in your territory, who are holding very adequate stocks of M.G. Spares.

The name and address of the nearest Distributors is given in Instruction Manual supplied with the car, and we feel sure that all your requirements will receive every consideration and attention.

May we request you therefore to get into touch with our Distributors for all your future orders ?

We cannot stress too highly the *danger* of fitting non-genuine M.G. parts.

Unfortunately cases have come to our notice where accidents have actually been caused by this practice, and we strongly advise all M.G. owners to insist and see that for all repairs and replacements only genuine M.G. parts are fitted.

M.G. parts are specially designed and manufactured to withstand the stresses imposed by a high-speed sports car, and we would warn all owners that the fitting of non-genuine parts renders the guarantee *null* and *void*.

The Company only fit the highest grade and best known proprietary fittings, but we give no guarantee whatsoever in respect of tyres, lamps, electrical equipment, speedometers, clocks, or any other proprietary fittings of any type supplied with the car or otherwise, as such proprietary fittings are usually covered by a guarantee issued by their respective manufacturers.

All questions involving the replacement or repair of any such proprietary fittings should therefore be taken up direct with the manufacturers concerned, and not with The M.G. Car Company Ltd.

Every possible precaution has been taken to ensure accuracy of this list. The right is, however, reserved to vary the list of spare parts and prices without notice.

A P R I L
1 9 3 4
G.K. — G.T.

THE  CAR
COMPANY LTD
ABINGDON-ON-THAMES

Part No.



DESCRIPTION



2-seater

4-seater

Saloon

Price Each

£ s. d.

CHASSIS FRAME AND DETAILS

MG430	Chassis frame assembly	...	...	...	1			12 4 6
MG413	" " "	...	...	...		1	1	12 18 6
2661	Side member O/S	...	...	...	1			1 8 2
2392	" " O/S	...	...	...		1	1	1 8 2
2662	" " N/S	...	...	...	1			1 8 2
2419	" " N/S	...	...	...		1	1	1 8 2
623	Front dumb-iron O/S	...	...	...	1	1	1	5 10
624	" " N/S	...	...	...	1	1	1	5 10
625	Front dumb-iron taper washer	...	...	...	2	2	2	4
626	Front sliding trunnion bracket O/S	...	...	...	1	1	1	10 1
627	" " N/S	...	...	...	1	1	1	10 1
632	Front sliding trunnion bracket cover	...	...	...	2	2	2	1 7
633	Front sliding trunnion roller	...	...	...	4	4	4	3 8
P232/1	Front cross tube assembly	...	...	...	1	1	1	7 6
MG413/2	Engine bearer cross tube assembly	...	...	...	1	1	1	1 8 2
1811	Front engine mounting cap	...	...	...	1	1	1	2 9
1810	Front engine mounting cap bolt (special)	...	...	...	2	2	2	10
MG413/3	Third cross tube assembly	...	...	...	1	1	1	16 0
921	Combined cross tube end bracket and brake cross shaft support	...	...	...	2	2	2	4 10
P232/4	Rear spring front cross tube assembly	...	...	...	1	1	1	1 3 0
640	End bracket for cross tube	...	...	...	2	2	2	2 6
MG413/5	Rear spring rear cross tube assembly	...	...	...	1	1	1	2 5 0
819	Rear spring rear cross tube sliding trunnion roller	...	...	...	4	4	4	3 8
820	Rear spring rear cross tube sliding trunnion washer	...	...	...	2	2	2	6
872	Rear spring rear cross tube cap	...	...	...	2	2	2	4 9
873	Rear spring rear cross tube distance piece	...	...	...	2	2	2	11
2403	End bracket for cross tube	...	...	...	2	2	2	2 9
MG413/6	Rear cross tube assembly	...	...	...		1	1	17 4
804	Front axle rubber buffer and plate	...	...	...	2	2	2	1 7
805	Front axle rubber buffer and plate backing plate	...	...	...	2	2	2	4
815	Rear axle striking pad	...	...	...	2	2	2	3
817	Rear axle striking pad set screw	...	...	...	2	2	2	doz. 2 0
806	Rear spring suspension pin	...	...	...	2	2	2	5 4
874	Combined greaser and set screw	...	...	...	2	2	2	10
1606	Brake pedal and engine bearer bracket	...	...	...	1	1	1	7 3
958	Engine bearer bracket	...	...	...	1	1	1	6 9
959	Engine bearer bracket location screw	...	...	...	1	1	1	doz. 1 3
1002	Body bracket	...	...	...	2			8
2527	" " "	...	...	...		2	2	1 5
979	Body bracket support	...	...	...	2	2	2	2 7
2525	Body bracket O/S	...	...	...	1	1	1	7
2526	" " N/S	...	...	...	1	1	1	7
1211	Body bracket support	...	...	...	2	2	2	3 0
1001	Body bracket "U" clip (short)	...	...	...	2	2	2	4
1212	" " " " (long)	...	...	...	2	2	2	6
1587	Body bracket front	...	...	...		2	2	10
2343	Battery carrier	...	...	...	1	1	1	7 8
1229	Shock absorber tie bar	...	...	...	1	1	1	2 2
2588	Combined wing stay and shock absorber bracket O/S	...	...	...	1	1	1	10 2
2589	Ditto N/S	...	...	...	1	1	1	10 2

FRONT AXLE ASSEMBLY AND SPRINGS

MG469	Front axle assembly (12" brakes) less springs and wheels	...	...	...	1	1	1	13 10 10
P234/100	Front axle beam	...	...	...	1	1	1	2 6 6
P101/101	Front axle swivel pin	...	...	...	2	2	2	6 6
MG374/1	Front axle swivel pin cotter	...	...	...	2	2	2	2 3
X101/1	Front axle swivel pin cotter nut	...	...	...	2	2	2	doz. 1 3
X101/2	Front axle swivel pin cotter spring washer (1/4")	...	...	...	2	2	2	doz. 8
P101/104	Front axle swivel pin thrust washer	...	...	...	2	2	2	1 3
P101/10	Front axle steering knuckle (swivel) O/S (bushed)	...	...	...	1	1	1	1 7 8
P101/11	" " " " N/S (bushed)	...	...	...	1	1	1	1 7 8
P101/107	Front axle steering knuckle bush (top)	...	...	...	2	2	2	2 8
P101/149	" " " " (bottom)	...	...	...	2	2	2	2 6
X101/6	Front axle steering knuckle bush disc (top)	...	...	...	2	2	2	doz. 1 0
P101/113	Front axle steering knuckle slotted nut (R.H.)	...	...	...	1	1	1	1 0
P101/114	" " " " (L.H.)	...	...	...	1	1	1	1 0
P101/115	Front axle steering knuckle washer	...	...	...	2	2	2	doz. 9
P234/5	Front hub O/S (Rudge Whitworth) (studded)	...	...	...	1	1	1	14 6
P234/6	" " N/S (Rudge Whitworth) (studded)	...	...	...	1	1	1	14 6
P101/109	Front hub distance washer for inner bearing	...	...	...	2	2	2	1 0
P101/110	Front hub distance piece for bearing	...	...	...	2	2	2	1 0

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
P234/103	Front hub stud	12	12	12			9
P101/116	Front hub bearing (large)	2	2	2	10		6
P101/117	" " (small)	2	2	2	10		9
P101/118	Front hub felt washer	2	2	2			3
MG365/1	Brake-drum	2	2	2	1	0	10
P101/112	Brake-drum countersunk screw	4	4	4			3
MG365/4	Brake-shoe (lined)	4	4	4	13		7
MG365/105	Brake-shoe lining	4	4	4	3		0
MG365/112	Brake-shoe lining rivet	36	36	36	doz.		5
MG362/157	Brake-shoe spring	2	2	2			3
MG365/113	Brake-shoe fulcrum pin	4	4	4			11
X365/1	Brake-shoe fulcrum pin nut ($\frac{1}{2}$ " B.S.F.)	4	4	4			2
X365/2	Brake-shoe fulcrum pin washer ($\frac{1}{2}$ " ...)	4	4	4	doz.		8
574	Brake-shoe damper weight	4	4	4	2		0
576	Brake-shoe damper weight clevis pin	8	8	8			3
575	Brake-shoe damper weight spring	8	8	8			3
X101/12	Brake-shoe damper weight washer ($\frac{3}{8}$ " ...)	16	16	16	doz.		8
MG365/3	Brake-shoe anchor bracket assembly N/S	1	1	1	1	4	10
MG365/2	" " " " O/S	1	1	1	1	4	10
X234/2	Brake-shoe anchor bracket bolt (short) ($\frac{3}{8}$ " B.S.F. $\times 1\frac{1}{8}$ " ...)	4	4	4			3
X365/4	Brake-shoe anchor bracket bolt ($\frac{3}{8}$ " B.S.F. $\times 2\frac{1}{4}$ " ...)	2	2	2			6
X469/1	" " " " (long)	2	2	2			3
X101/10	Brake-shoe anchor bracket bolt nut ($\frac{3}{8}$ " B.S.F.)	8	8	8	doz.	1	3
X101/11	Brake-shoe anchor bracket bolt nut washer	8	8	8	doz.		8
MG365/107	Brake cam N/S	1	1	1			3
MG365/109	" " O/S	1	1	1			3
MG365/103	Brake cam lever N/S	1	1	1			3
MG365/104	" " " " O/S	1	1	1			3
MG365/118	Brake cam bush	2	2	2			1
X101/4	Brake cam key (Woodruff No. 3)	2	2	2			6
P101/3	Track rod assembly	1	1	1	18		6
P101/9	Track rod tube with plugs	1	1	1			6
MG469/100	Track rod lever N/S	1	1	1			7
MG469/101	" " " " O/S (steering arm)	1	1	1			7
P101/140	Track rod adjustable end for ball joints (R.H. thread)	1	1	1	5		6
P101/141	Ditto (L.H. thread)	1	1	1	5		6
P101/136	Track rod lock nut (R.H.)	1	1	1			4
P101/137	" " " " (L.H.)	1	1	1			4
P101/138	Track rod and draglink steering ball	2	2	2	2		0
P101/139	Track rod and draglink steering ball nut	2	2	2			4
P101/142	Steering ball cup	2	2	2			10
P101/143	End cup for ball joint on track rod	2	2	2	1		0
2731	Front axle packing	2	2	2			1
P235	Draglink assembly	1	1	1	17		2
P235/1	Draglink tube	1	1	1	5		0
P102/102	Adjustable end for ball joint (R.H. thread)	1	1	1	5		6
P101/141	" " " " (L.H. thread)	1	1	1	5		6
P101/138	Draglink and track rod steering ball	2	2	2	2		0
P101/136	Draglink and track rod steering ball lock nut (R.H.)	1	1	1			4
P101/137	Ditto (L.H.)	1	1	1			4
P101/142	Ball cup	2	2	2			10
P101/143	Ball joint end cup	1	1	1	1		0
P101/144	Ball joint spring	2	2	2			3
P102/105	Ball joint cup	1	1	1	1		0
P102/106	Ball joint end plug	1	1	1			3
P313	Front spring O/S (less shocker brackets)	1	1	1	1	0	0
	" " " " N/S (less shocker brackets)	1	1	1	1	0	0
P313/100	Front spring top leaf	2	2	2	4		10
P313/101	Front spring 2nd leaf	2	2	2	4		5
P236/102	Front spring 3rd or main leaf	2	2	2	6		3
P313/102	Front spring 4th leaf	2	2	2	4		0
P313/103	Front spring 5th leaf	2	2	2	3		9
P313/104	Front spring 6th leaf	2	2	2	3		7
P313/105	Front spring 7th leaf	2	2	2	3		5
P313/106	Front spring 8th leaf	2	2	2	3		2
1552	Front shock absorber bracket O/S	1	1	1	4		2
1553	" " " " N/S	1	1	1	4		2
1190	Front spring bottom plate	2	2	2	1		6
2422	Front spring plate bolt	8	8	8			10
801	Front spring suspension pin	2	2	2	2		5
802	Front spring suspension pin tab washer	2	2	2			4
803	Front spring dust excluder	2	2	2	1		0

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each		
					£	s.	d.
2309	Front spring stiffening strip	4	4	4			8
2324	Grub screw for back plate	2	2	2	doz.	1	3
REAR AXLE ASSEMBLY, PROPELLER SHAFT AND SPRINGS							
MG470	Rear axle assembly (8/43 ratio) (less springs and wheels)	1	1	1		21	4 0
MG366/3	Rear axle casing with spring pad	1	1	1		3	1 4
MG470/3	Rear axle front cover complete	1	1	1		2	7 6
X105/1	Rear axle front cover set screw ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{2}$ ") ...	6	6	6	doz.	1	3
X105/2	" " " " " ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{2}$ ") ...	2	2	2	doz.	1	3
X105/3	Rear axle front cover set screw nuts	8	8	8	doz.	1	3
X105/4	Rear axle front cover set screw spring washer ($\frac{5}{16}$ ") ...	16	16	16	doz.		8
X105/7	Rear axle rear cover screw ($\frac{5}{16}$ " B.S.F. $\times \frac{3}{4}$ ") ...	8	8	8			3
P105/163	Rear axle front and rear cover joints	2	2	2			4
P238/128	Rear axle front and rear cover spring packing washer	8	8	8	doz.		5
P105/157	Rear axle dowel	8	8	8			3
P105/117	Rear axle oil filler plug	1	1	1		1	2
X105/9	Rear axle oil filler plug washer	1	1	1	doz.	1	0
X105/111	Rear axle taper drain plug (axle banjo) ($\frac{1}{4}$ " gas) ...	1	1	1			4
X105/12	Rear axle spider slotted nut ($\frac{1}{2}$ " B.S.F.)	1	1	1			3
X105/13	Rear axle spider slotted nut washer ($\frac{1}{2}$ ")	1	1	1			3
P105/111	Rear axle drive shaft	2	2	2		19	6
P238/5	Differential assembly	1	1	1		11	11 6
P105/9	Differential case complete (L.H. & R.H.)	1	1	1		1	6 0
X470/1	Differential case bolt	6	6	6			9
P105/116	Differential case bolt castle nut	6	6	6			3
P105/106	Differential bearing	2	2	2		14	3
P101/139	Differential bearing cap castle nut	4	4	4			3
X105/4	Differential bearing cap castle nut spring washer ($\frac{5}{16}$ ")	4	4	4	doz.		8
P238/119	Differential bearing cap stud	4	4	4			2
MG470/102	Differential wheel	2	2	2		8	6
P105/121	Differential pinion	2	2	2		7	4
P105/123	Differential pinion dowel	1	1	1	doz.		9
P105/107	Differential bearing lock washer	2	2	2			3
P105/143	Differential bearing nut	2	2	2		1	9
P105/122	Differential pinion pin	1	1	1		1	0
P105/127	Differential pinion housing cap screw	2	2	2			3
P238/12	{ Crown wheel (8/43 ratio) } Not supplied separately	1	1	1	}	2	7 10
X261/1	{ Bevel pinion bearing (Hoffman) }	1	1	1			
X105/6	Bevel pinion roller bearing (R. & M. MRJ25) ...	1	1	1		15	0
P105/137	Bevel pinion washer	1	1	1			5
P105/174	Bevel pinion bearing distance piece	1	1	1		1	0
P105/129	Bevel pinion housing	1	1	1		16	4
X105/5	Bevel pinion housing spring ring	1	1	1			7
P275/102	Bevel pinion housing packing piece	1	1	1		2	0
P105/135	Bevel pinion housing cap	1	1	1		7	9
X105/3	Bevel pinion housing stud nut ($\frac{5}{16}$ ")	4	4	4	doz.	1	3
X238/1	Bevel pinion housing stud ($\frac{5}{16}$ " B.S.F. $\times 2\frac{1}{2}$ ") ...	4	4	4			2
P105/103	Bevel pinion shim (.005")	As required					3
P105/104	" " " (.010")	As required					3
P105/105	" " " (.020")	As required					3
MG365/1	Brake-drum	2	2	2		1	0 10
MG470/105	Brake-drum countersunk screw	4	4	4			2
MG365/4	Brake-shoe (lined)	4	4	4		13	7
MG365/105	Brake-shoe lining	4	4	4		3	0
MG365/112	Brake-shoe lining rivet	36	36	36	doz.		5
MG365/113	Brake-shoe fulcrum pin	4	4	4			11
X365/1	Brake-shoe fulcrum pin nut ($\frac{1}{2}$ " B.S.F.)	4	4	4			2
X365/2	Brake-shoe fulcrum pin washer ($\frac{1}{2}$ ")	4	4	4	doz.		8
X365/3	Brake-shoe fulcrum pin bracket rivet ($\frac{5}{16}$ " $\times \frac{3}{4}$ ") ...	8	8	8	doz.		4
MG362/157	Brake-shoe return spring	2	2	2			3
MG366/2	Brake-shoe anchor bracket assembly N/S	1	1	1		1	4 10
MG366/1	" " " " " O/S	1	1	1		1	4 10
X105/8	Brake-shoe anchor bracket bolt (top) ($\frac{3}{8}$ " B.S.F. $\times \frac{1}{16}$ ")	4	4	4			3
X234/2	Ditto (bottom) ($\frac{3}{8}$ " B.S.F. $\times \frac{1}{16}$ ")	4	4	4			3
X101/10	Brake-shoe anchor bracket bolt nut ($\frac{3}{8}$ " B.S.F.) ...	8	8	8	doz.	1	3
574	Brake-shoe damper weights	4	4	4		2	0
576	Brake-shoe damper weight clevis pin	8	8	8			3
575	Brake-shoe damper weight spring	8	8	8			3

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
X101/12	Brake-shoe damper weight washer ($\frac{3}{16}$ ")	16	16	16	doz.	8	
MG365/107	Brake cam N/S ...	1	1	1		3	0
MG365/109	" " O/S ...	1	1	1		3	0
X101/4	Brake cam key (Woodruff No. 3)	2	2	2		3	0
MG365/103	Brake cam lever N/S ...	1	1	1		3	0
MG365/104	" " O/S ...	1	1	1		3	0
X101/5	Brake cam bolt ($\frac{1}{4}$ " B.S.F. $\times 1\frac{5}{16}$ ")	2	2	2		3	3
X101/1	Brake cam bolt nut ($\frac{1}{4}$ " B.S.F.)	2	2	2	doz.	1	3
X101/2	Brake cam bolt spring washer ($\frac{1}{4}$ ")	2	2	2	doz.	8	
MG365/118	Brake cam bracket bush ...	2	2	2		1	6
X365/3	Brake cam bracket rivet ($\frac{5}{16}$ " dia. $\times \frac{1}{4}$ ")	8	8	8	doz.	4	
P238/104	Rear hub N/S (Rudge-Whitworth)	1	1	1		14	6
P238/103	" " O/S (Rudge-Whitworth)	1	1	1		14	6
P238/105	Rear hub stud (Rudge-Whitworth wheels)	12	12	12		9	
X234/1	Rear hub stud nut ($\frac{3}{8}$ " B.S.F.)	12	12	12	doz.	10	
X101/11	Rear hub stud nut washer ...	12	12	12	doz.	8	
P275/103	Rear hub ball bearing ...	2	2	2		1	4
P105/113	Rear hub ball bearing locking washer	2	2	2		3	
P105/158	Rear hub bearing nut (R.H.) ...	1	1	1		1	10
P105/159	" " " " (L.H.) ...	1	1	1		1	10
P238/114	Rear hub felt retaining ring ...	2	2	2		3	
P238/111	Rear hub oil retaining ring felt ...	2	2	2		1	2
P238/115	Rear hub oil retaining ring peg ...	4	4	4	doz.	1	0
P238/6	Rear hub housing assembly with studs	2	2	2		11	6
P275/105	Rear hub bearing joint ...	2	2	2		3	
A372	Propeller shaft (Hardy Spicer)	1	1	1		2	4
811	Propeller shaft flange bolt ...	12	12	12		4	
P238/100	Propeller shaft universal joint flange	1	1	1		9	4
P237	Rear spring assembly O/S (less shocker brackets)	1				18	0
	" " " " N/S (less shocker brackets)	1				18	0
MG455	" " " " O/S (less shocker brackets)		1	1		1	0
	" " " " N/S (less shocker brackets)		1	1		1	0
P237/100	Rear spring top leaf ...	2				4	6
P237/101	Rear spring 2nd leaf ...	2				5	0
P237/102	Rear spring 3rd leaf ...	2				7	6
P237/103	Rear spring 4th leaf ...	2				4	3
P237/104	Rear spring 5th leaf ...	2				4	3
P237/105	Rear spring 6th leaf ...	2				3	11
P237/106	Rear spring 7th leaf ...	2				3	8
P237/107	Rear spring 8th leaf ...	2				3	4
P237/108	Rear spring 9th leaf ...	2				3	2
936	Rear shock absorber bracket O/S	1	1	1		4	2
1738	" " " " N/S	1	1	1		4	2
1054	Rear spring top plate ...	2	2	2		2	4
MG455/100	Rear spring rebound leaf ...		2	2		5	4
MG455/101	" " " " ...		2	2		4	10
MG455/102	Rear spring main leaf ...		2	2		7	4
MG455/103	Rear spring 1st leaf ...		2	2		4	5
MG455/104	Rear spring 2nd leaf ...		2	2		4	3
MG455/105	Rear spring 3rd leaf ...		2	2		4	0
MG455/106	Rear spring 4th leaf ...		2	2		3	7
MG455/107	Rear spring 5th leaf ...		2	2		3	5
MG455/108	Rear spring 6th leaf ...		2	2		3	2
809	Rear spring front suspension pin washer ...	2	2	2		6	
810	Rear spring front suspension pin radius washer	2	2	2		6	
812	Rear spring "U" clip ...	4	4	4		11	
818	Rear spring dust excluder ...	2	2	2		1	2
1364	Rear spring pad and steady bracket...	2	2	2		7	0
1927	Rear axle strap ...	2	2	2		8	
816	Rear axle strap rubber block...	2	2	2		1	0
2324	Grub screw for back plate ...	2	2	2	doz.	1	3
S1/8	Stauffer grease cup ($\frac{5}{16}$ " B.S.F.)	2	2	2		9	

POWER UNIT AND INSTALLATION

MG420	Power unit complete with gearbox ...	1	1	1	Price on application		
-------	--------------------------------------	---	---	---	----------------------	--	--

CRANKCASE AND CYLINDERS

MG348/14	Cylinder block (studded) ...	1	1	1	11	5	0
MG348/102	Cylinder jacket cover-plate ...	2	2	2		1	0
MG348/1	Cylinder jacket cover-plate (intermediate) (complete)	1	1	1		6	1
MG348/297	Cylinder jacket cover-plate gasket ...	3	3	3		4	
X363/19	Cylinder jacket cover stud ($\frac{5}{16}$ " B.S.F. $\times 2\frac{1}{4}$ ")	1	1	1	doz.	2	0
X287/5	" " " " ($\frac{5}{16}$ " B.S.F. $\times 1\frac{3}{16}$ ")	1	1	1	doz.	1	6

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each		
					£	s.	d.
X105/3	Cylinder jacket cover nut ($\frac{5}{16}$ " B.S.F.)	2	2	2	doz.	1	3
X105/4	Cylinder jacket cover washer	2	2	2	doz.		8
X110/4	Cylinder water jacket set screw ($\frac{1}{4}$ " B.S.F. $\times \frac{7}{16}$ ")	18	18	18			3
X110/5	Cylinder water jacket washer ($\frac{1}{4}$ ")	18	18	18	doz.	4	
P287/101	Cylinder block core plug ($\frac{3}{8}$ " Whit. $\times \frac{3}{4}$ " long)	2	2	2			8
P287/107	Cylinder block drain cock	1	1	1		1	9
X287/4	Cylinder block drain cock washer	1	1	1	doz.	4	
MG420/113	Magneto facing cover-plate	1	1	1		1	4
X363/22	Magneto facing cover-plate stud ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{4}$ ")	4	4	4	doz.	1	6
X105/3	Magneto facing cover-plate nut ($\frac{5}{16}$ ")	4	4	4	doz.	1	3
MG420/104	Magneto facing cover-plate gasket	1	1	1			3
X105/4	Magneto facing cover-plate washer ($\frac{5}{16}$ ")	4	4	4	doz.		8
CYLINDER HEAD ASSEMBLY							
MG420/11	Cylinder head assembly	1	1	1		24	10 0
MG420/8	Cylinder head (studded)	1	1	1		7	17 6
MG348/34	Cylinder head gasket	1	1	1			5 0
X348/2	Cylinder head stud ($\frac{3}{8}$ " B.S.F. $\times 4\frac{3}{16}$ ")	1	1	1			1 9
X348/3	" " " ($\frac{3}{8}$ " B.S.F. $\times 4\frac{3}{16}$ ")	1	1	1			1 9
X348/4	" " " ($\frac{3}{8}$ " B.S.F. $\times 5\frac{1}{16}$ ")	1	1	1			5
X348/5	" " " ($\frac{3}{8}$ " B.S.F. $\times 4\frac{13}{16}$ ")	7	7	7			5
X348/6	" " " ($\frac{3}{8}$ " B.S.F. $\times 4\frac{13}{16}$ ")	8	8	8			5
X101/10	Cylinder head nut ($\frac{3}{8}$ " B.S.F.)	18	18	18	doz.	1	3
MG348/129	Cylinder head cover	1	1	1		2	1 0
MG348/279	Cylinder head cover gasket	1	1	1			2 9
X110/100	Cylinder head cover stud ($\frac{1}{4}$ " B.S.F. $\times 3\frac{1}{2}$ ")	6	6	6	doz.	1	0
P287/141	Cylinder head core plug Ceased Eng. No. 581	3	3	3			10
X110/38	" " " Comm. Eng. No. 582	3	3	3			4
X348/23	Cylinder head drain cock set screw ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{8}$ ")	1	1	1			4
X239/4	Cylinder head drain cock washer ($\frac{5}{16}$ " B.S.F.)	1	1	1	doz.		6
MG348/16	Cylinder head cover fixing nut	6	6	6		1	7
X348/53	Spring ring	6	6	6	doz.		6
MG348/283	Cylinder head cover plug	1	1	1			5
X363/16	Cylinder head cover plug washer	1	1	1	doz.	1	4
MG348/2	Water inlet pipe assembly	1	1	1		10	10
MG348/299	Water inlet pipe hose	1	1	1			6
A399	Nesthill clip	2	2	2			1 0
MG348/120	Water outlet pipe	1	1	1		1	1 3
X110/20	Water outlet pipe stud ($\frac{1}{4}$ " B.S.F. $\times 1\frac{3}{16}$ ")	6	6	6			3
X101/1	Water outlet pipe nut ($\frac{1}{4}$ " B.S.F. hex. headed)	6	6	6	doz.	1	3
X101/2	Water outlet pipe split spring washer	6	6	6	doz.		8
MG348/262	Water outlet pipe gasket	3	3	3			2
CAMSHAFT							
MG348/168	Camshaft	1	1	1		2	3 2
X363/31	Camshaft nut ($\frac{3}{8}$ " B.S.F.) (slotted)	1	1	1			3
X348/25	Camshaft washer ($\frac{3}{8}$ ")	1	1	1	doz.		6
X101/4	Camshaft key (Woodruff No. 3)	1	1	1			3
MG348/171	Camshaft bevel thrust washer	2	2	2			10
MG348/172	Camshaft Belleville washer	2	2	2			7
MG348/173	Camshaft rear bearing bush (bottom)	3	3	3		1	6
MG348/174	" " " " (top)	3	3	3		1	6
MG348/175	Camshaft front bearing bush (top)	2	2	2		1	0
MG348/176	" " " " (front bottom)	1	1	1		1	0
MG348/177	" " " " (rear bottom)	1	1	1		1	0
MG348/19	Camshaft front bearing housing (bushed with cap)	1	1	1		19	4
X348/26	Camshaft front bearing stud ($\frac{1}{4}$ " B.S.F. $\times 1\frac{7}{16}$ ")	2	2	2			5
X101/1	Camshaft front bearing stud nut ($\frac{1}{4}$ " B.S.F.)	2	2	2	doz.	1	3
X101/2	Camshaft front bearing stud washer ($\frac{1}{4}$ ")	2	2	2	doz.		8
X101/49	Camshaft front bearing dowel ($\frac{1}{16}$ " dia. $\times \frac{3}{8}$ ")	2	2	2	doz.		8
MG348/20	Camshaft bearing (rear) (bushed with cap)	3	3	3		14	8
X348/26	Camshaft bearing stud ($\frac{1}{4}$ " B.S.F. $\times 1\frac{7}{16}$ ")	3	3	3			3
X101/1	Camshaft bearing stud nut ($\frac{1}{4}$ " B.S.F.)	3	3	3	doz.	1	3
X101/2	Camshaft bearing stud washer ($\frac{1}{4}$ ")	3	3	3	doz.		8
X110/49	Camshaft bearing dowel ($\frac{3}{16}$ " dia. $\times \frac{3}{8}$ ")	6	6	6	doz.		8
X110/47	Camshaft bearing dowel screw ($\frac{1}{4}$ " B.S.F. $\times \frac{3}{8}$ ")	6	6	6			3
X110/48	Camshaft bearing dowel washer ($\frac{1}{4}$ ")	6	6	6	doz.		3
P287/145	Camshaft intermediate bearing plug	4	4	4			3
X110/6	Stud (camshaft bracket) ($\frac{1}{4}$ " B.S.F. $\times 1$ ")	8	8	8			3
MG348/17	Bell housing (bushed)	1	1	1		2	1 6
X110/10	Bell housing set screw ($\frac{3}{8}$ " B.S.F. $\times 1\frac{1}{8}$ " long)	1	1	1			3
X101/11	Bell housing washer ($\frac{3}{8}$ ")	3	3	3	doz.		8
X110/12	Bell housing bolt ($\frac{3}{8}$ " B.S.F. $\times 1\frac{1}{4}$ " long)	2	2	2	doz.		8
X101/10	Bell housing bolt nut ($\frac{3}{8}$ " B.S.F.)	2	2	2	doz.	1	3
X110/13	Bell housing grub screw ($\frac{5}{16}$ " B.S.F. $\times \frac{1}{4}$ " long)	1	1	1			2

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each		
					£	s.	d.
MG348/166	Bell housing union (banjo)	1	1	1			6
MG348/100	Bell housing set screw ($\frac{5}{16}$ " B.S.F. $\times 1$ ")	9	9	9			8
X239/4	Bell housing set screw washer ($\frac{5}{16}$ " (soft copper)	3	3	3	doz.		6
X105/4	Bell housing washer ($\frac{5}{16}$ "	6	6	6	doz.		8
MG348/252	Bell housing gasket	1	1	1			3
FLYWHEEL							
MG412/100	Flywheel	1	1	1	1	17	9
X412/1	Flywheel set screw ($\frac{5}{16}$ " B.S.F. $\times 2\frac{1}{8}$ ")	6	6	6			2
X105/4	Flywheel washer ($\frac{5}{16}$ "	6	6	6	doz.		8
MG348/148	Flywheel bolt	8	8	8			7
X363/31	Flywheel bolt nut (slotted) ($\frac{3}{8}$ " B.S.F.)	8	8	8			3
MG412/103	Flywheel spigot bearing housing	1	1	1			10 4
X110/28	Flywheel spigot ball bearing	1	1	1			8 9
VERTICAL DRIVE							
MG348/18	Camshaft and dynamo bevel wheels	1	1	1	1	12	10
X110/43	Camshaft driving bevel pinion key (Woodruff 2)	1	1	1			3
P110/196	Bevel pinion oil thrower	1	1	1			7
P110/197	Bevel pinion universal joint fork	1	1	1			4 9
X110/44	Hyatt roller bearing	2	2	2			5 10
P110/194	Bevel pinion bearing sleeve	1	1	1			9 0
P110/198	Camshaft driving bevel wheel nut	1	1	1			7
P110/199	Camshaft driving bevel wheel washer	1	1	1	doz.		8
P110/202	Bevel pinion washer	1	1	1			1 0
MG412/104	Bevel pinion thrust washer	1	1	1			1 0
P110/201	Bearing retaining plate... ..	1	1	1			3 4
X110/98	Bearing retaining felt washer	1	1	1			3
P110/4	Dynamo coupling assembly	1	1	1			5 6
P110/282	Dynamo coupling washer (.010" thick)	As required			doz.		1 4
P110/283	" " " (.020" thick)	As required			doz.		1 4
P110/284	" " " (.030" thick)	As required			doz.		1 4
P110/285	" " " (.040" thick)	As required			doz.		1 4
P110/286	" " " (.050" thick)	As required			doz.		1 4
P110/277	Dynamo coupling bolt	4	4	4			6
X101/1	Dynamo coupling nut	4	4	4	doz.		1 3
X101/2	Dynamo coupling washer ($\frac{1}{4}$ ")	4	4	4	doz.		8
X110/53	Dynamo coupling distance washer	4	4	4			2
P110/198	Dynamo spindle nut	1	1	1			7
P110/199	Dynamo spindle washer	1	1	1	doz.		8
P110/8	Dynamo universal joint fork (with oil thrower)	1	1	1			5 6
P110/276	Dynamo bottom bevel pinion tab washer	1	1	1	doz.		1 9
P110/257	Dynamo shim (.003" thick)	As required					4
P110/258	" " (.005" thick)	As required					4
P110/259	" " (.007" thick)	As required					5
P110/260	" " (.015" thick)	As required					7
P287/160	" " (for bottom gear) (.010" thick)	As required					7
X105/14	Dynamo set screw ($\frac{1}{4}$ " B.S.F. $\times \frac{7}{8}$ ")	4	4	4			3
ROCKERS AND VALVES							
992	Valve rocker	12	12	12			7 2
997	Valve rocker locking screw	12	12	12			2
MG363/106	Valve rocker eccentric bush	12	12	12			3 4
X363/11	Valve rocker spring ring	12	12	12	doz.		9
MG348/182	Valve rocker distance piece ($1\frac{1}{2}$ " long)	4	4	4			5
MG348/183	" " " ($1\frac{1}{2}$ " long)	4	4	4			4
MG348/184	" " " ($1\frac{1}{2}$ " long)	4	4	4			4
P110/179	" " " ($\frac{1}{2}$ " long)	4	4	4			4
MG348/185	Valve rocker-shaft Belleville washer	12	12	12	doz.		9
MG348/186	Valve rocker-shaft steady bracket	2	2	2			1 9
MG348/119	Valve rocker-shaft rear end support bracket	1	1	1			12 10
P287/145	Valve rocker-shaft rear end support bracket plug	2	2	2			2
X110/48	Valve rocker-shaft rear end support washer ($\frac{1}{4}$ ")	2	2	2	doz.		3
MG348/23	Rocker-shaft O/S	1	1	1			4 2
MG348/24	" " N/S	1	1	1			4 2
MG348/294	Inlet valve	6	6	6			3 6
MG348/295	Exhaust valve	6	6	6			3 6
P110/184	Split cotter for valves (halves)	24	24	24	pair		1 0
MG348/191	Valve spring (outer)	12	12	12			7
MG348/192	" " (inner)	12	12	12			4
MG348/193	Valve spring cup	12	12	12			8
MG348/194	Valve guide	12	12	12			2 3
MG468/121	Valve guide washer	12	12	12	doz.		1 9



CRANKSHAFT AND FRONT BEARING HOUSING*

MG348/25	Crankshaft with plugs	1	1	1			8 10	6
X110/23	Crankshaft key (Woodruff No. 11)	2	2	2				3
X348/17	" " (Woodruff No. 6)	1	1	1				3
MG412/101	Crankshaft flange	1	1	1			1 1	0
MG348/143	Plug for crank pin ($1\frac{1}{2}$ " dia. $\times$ 16 T.P.I. $\times \frac{5}{16}$ " long) ...	2	2	2				6
MG348/144	" " " " " " " " " " " " " " " "	3	3	3				3
MG348/145	Crankshaft "flange" nut	1	1	1				9
MG420/101	Crankshaft front bearing housing bush	1	1	1			14	8
MG348/181	Crankshaft front bearing thrust washer	1	1	1				6
X348/14	Crankshaft front bearing thrust washer grub screw ($2\text{ B.A.} \times \frac{1}{4}"$)	1	1	1		doz.		9
X110/2	Crankshaft front bearing housing set screw ($\frac{5}{16}"$ B.S.F. $\times \frac{7}{8}"$)	7	7	7				3
X105/4	Crankshaft front bearing housing washer ($\frac{5}{16}"$) ...	7	7	7		doz.		8
MG420/7	Crankshaft front bearing housing (bushed) ...	1	1	1			3 3	0
MG348/179	Crankshaft front bearing grub screw ($\frac{1}{4}"$ B.S.F. $\times 1\frac{1}{2}"$) ...	1	1	1				10
X348/14	Crankshaft front housing thrust ring grub screw ($2\text{ B.A.} \times \frac{1}{4}"$)	1	1	1		doz.		9
X110/6	Crankshaft front housing stud ($\frac{1}{4}"$ B.S.F. $\times 1"$) ...	2	2	2				3
X363/13	Crankshaft front housing cover bolt ($\frac{5}{16}"$ B.S.F. $\times 1\frac{1}{4}"$)	4	4	4				3
X110/93	Crankshaft front housing locating dowel ($\frac{5}{16}" \times \frac{5}{8}"$) ...	1	1	1		doz.		9
MG348/253	Crankshaft front bearing housing gasket	1	1	1				2
MG348/178	Crankshaft rear bearing	1	1	1			11	9
MG348/27	Crankshaft intermediate main bearing (front) (top and bottom halves)	1	1	1			1 17	9
X287/7	Crankshaft intermediate main bearing special bolt ($\frac{5}{16}"$ B.S.F. $\times 1\frac{3}{8}"$)	2	2	2				4
X105/3	Crankshaft intermediate main bearing special bolt nut ($\frac{5}{16}"$ B.S.F.)	2	2	2		doz.	1 3	
X105/4	Crankshaft intermediate main bearing special washer ($\frac{5}{16}"$)	2	2	2		doz.		8
MG348/28	Crankshaft intermediate main bearing (rear) (top and bottom halves)	1	1	1			2 2	10
MG348/300	Crankshaft intermediate main bearing bolt lock plate	4	4	4				3
P287/115	Crankshaft intermediate main bearing bolt ($\frac{3}{8}"$ B.S.F. $\times 6\frac{1}{2}"$)	4	4	4				5
MG348/260	Crankshaft intermediate main bearing oil feed flange gasket	2	2	2		doz.	1 0	
X287/7	Bolt (special shouldered) ($\frac{5}{16}"$ B.S.F. $\times 1\frac{3}{8}"$) ...	2	2	2				4
MG348/21	Crankshaft and dynamo bottom bevells	1	1	1			1 13	2
MG348/272	Crankshaft bevel wheel thrust ring	1	1	1				6
MG348/273	Crankshaft bevel wheel thrust washer	1	1	1				6
MG348/276	Crankshaft bevel wheel shim (.003")	As required						3
MG348/277	" " " " (.005")	As required						3
MG348/278	" " " " (.007")	As required						3
MG348/274	Crankshaft spiral gear (driver)	1	1	1				2
P110/265	Starting dog	1	1	1				2
MG348/128	Fan pulley (driver)	1	1	1				5
MG348/29	Engine nose piece with front bearing housing cover	1	1	1			1 17	2
MG348/251	Engine nose piece gaskets	1	1	1				1
X110/11	Engine nose piece set screw ($\frac{5}{16}"$ B.S.F. $\times \frac{7}{8}"$) ...	4	4	4				3
X105/4	Engine nose piece set screw washer ($\frac{5}{16}"$)	4	4	4		doz.		8
828	Engine mounting bush (front) (rubber)	2	2	2				4

WATER PUMP AND DETAILS

WATER PUMP AND DETAILS									
MG348/5	Water pump assembly	...	...	...	1	1	1	2 11	0
MG348/35	Water pump body (studded)	...	...	...	1	1	1	16	1
MG348/255	Water pump gasket	...	...	...	1	1	1		2
X348/12	Water pump bolt ($\frac{5}{16}$ " B.S.F. $\times 1 \frac{5}{16}$ " long)	...	...	...	2	2	2		2
X105/4	Water pump body bolt washer ($\frac{3}{16}$ ")	...	...	...	2	2	2	doz.	8
X110/101	Water pump body stud ($\frac{1}{4}$ " B.S.F. $\times 1 \frac{5}{8}$ ")	...	...	...	4	4	4	doz.	1 0
X348/18	" " " " ($\frac{1}{2}$ " B.S.F. $\times 2 \frac{1}{2}$ ")	...	...	...	2	2	2	doz.	1 0
X101/1	Water pump body stud nut ($\frac{1}{4}$ " B.S.F.)	...	...	...	6	6	6	doz.	1 3
X101/2	Water pump body stud washer	...	...	...	6	6	6	doz.	8
MG348/109	Water pump cover	...	...	...	1	1	1		6 8
MG348/151	Water pump rotor	...	...	...	1	1	1		4 2
1318	Water pump rotor bolt	...	...	...	1	1	1		2
1319	Water pump rotor tab washer	...	...	...	1	1	1		1 0
1315	Water pump bush	...	...	...	1	1	1		1 2
MG348/152	Water pump spindle	...	...	...	1	1	1		11 4
X110/43	Water pump spindle key (Woodruff No. 2)	...	...	...	1	1	1		3
MG348/153	Water pump spindle slip washer	...	...	...	1	1	1		1 8

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
MG348/154	Water pump pinion	1	1	1	6	2	
MG348/155	Water pump adaptor	1	1	1	9	10	
1316	Water pump adaptor gland packing	1	1	1	1	0	
1317	Water pump gland nut	1	1	1	2	7	
1310	Water pump felt	1	1	1		2	
X420/6	Water pump gland nut spring	1	1	1		3	
1309	Water pump felt retainer	1	1	1	10	0	
CONNECTING RODS AND PISTONS							
MG363/205	Connecting rod bush	6	6	6	1	2	
MG384/121	Connecting rod bolt	12	12	12		9	
984	Connecting rod nut	12	12	12		3	
MG348/30	Connecting rod and cap and small-end bush	6	6	6	1	4	10
MG363/4	Piston complete with rings and gudgeon pin	6	6	6	1	0	0
MG363/211	Piston ring (compression)	12	12	12		1	3
MG363/212	" " (scraper)	6	6	6		1	4
MG363/202	Gudgeon pin with pads	6	6	6		2	4
IGNITION AND DETAILS							
A465	Distributor DA11—I, Model D.F.H. 6A/4	1	1	1	2	17	6
MG420/105	Distributor adaptor	1	1	1		9	3
X287/13	Distributor adaptor securing screw ($\frac{1}{4}$ " B.S.F. $\times \frac{1}{2}$ ")	1	1	1			2
X101/2	Distributor adaptor securing screw washer ($\frac{1}{4}$ ")	1	1	1	doz.		8
MG420/106	Distributor drive shaft	1	1	1		4	2
MG420/107	Distributor drive shaft bush	1	1	1		2	0
MG348/298	Distributor drive shaft thrust washer	1	1	1			6
MG420/111	Distributor driving gear	1	1	1		7	9
A440	Sparking plug (Lodge Type H.D.14)	6	6	6		6	0
A426	High-tension cables	Set	1	1	set	9	6
LUBRICATING SYSTEM							
MG348/31	Oil filler with breather	1	1	1	11	8	
P110/469	Oil filler cap with knob	1	1	1		4	2
MG420/117	Oil filler baffle	1	1	1		1	4
X348/20	Oil filler gasket	1	1	1			3
MG348/3	Breather assembly	1	1	1			5
MG348/6	Oil pump assembly	1	1	1	1	17	9
MG348/111	Oil pump body	1	1	1		13	4
MG348/250	Oil pump gasket	1	1	1	doz.	1	0
MG348/135	Oil pump cover	1	1	1		5	7
MG348/164	Oil pump cover plug	1	1	1			4
MG348/159	Oil pump cover gasket	1	1	1			1
MG348/160	Oil pump driven gear	1	1	1	10	10	
MG348/161	Oil pump driven gear spindle	1	1	1			3
MG348/162	Oil pump spindle	1	1	1		6	8
P239/109	Oil pump relief valve	1	1	1			7
MG348/165	Oil pump relief valve cap nut	1	1	1		2	3
P110/158	Oil pump relief valve spring	1	1	1			4
X420/1	Oil pump set screw ($\frac{1}{4}$ " B.S.F. $\times 1\frac{7}{8}$ ")	2	2	2			7
X420/2	" " " " ($\frac{1}{4}$ " B.S.F. $\times 2\frac{3}{8}$ ")	2	2	2			9
X420/3	" " " " ($\frac{1}{4}$ " B.S.F. $\times 2\frac{1}{2}$ ")	1	1	1			9
OIL FILTER							
MG348/32	Oil filter assembly	1	1	1	1	16	9
MG348/36	Oil filter case (studded)	1	1	1		14	7
X348/34	Oil filter case stud ($\frac{5}{16}$ " B.S.F. $\times 1\frac{5}{16}$ ")	4	4	4	doz.	1	0
X105/3	Oil filter case stud nut ($\frac{5}{16}$ " B.S.F.)	4	4	4	doz.	1	3
X105/4	Oil filter case stud washer ($\frac{5}{16}$ " B.S.F.)	4	4	4	doz.		8
MG348/218	Oil filter cap	1	1	1		3	10
MG348/219	Oil relief valve body	1	1	1		3	6
X348/35	Oil relief valve spring	1	1	1	doz.	1	0
MG348/220	Oil relief valve plug	1	1	1			3
MG348/221	Oil filter element socket	1	1	1			9
MG348/222	Oil filter plate	1	1	1	doz.	2	3
MG348/293	Oil filter cap gasket	1	1	1			9
X348/38	Oil filter case plug	1	1	1			5
A522	Tecalemit oil cleaner element (Type 52/10)	1	1	1		8	9
X348/36	Tecalemit element location spring	1	1	1	doz.	1	2
MG348/223	Oil filter body gasket	1	1	1	doz.	1	0
OIL BASE							
MG348/107	Oil base	1	1	1	3	12	6
MG348/254	Oil base gasket	1	1	1		3	11
MG348/197	Oil base plug ($\frac{3}{8}$ " gas)	1	1	1		2	0
MG363/102	" " " ($\frac{3}{8}$ " gas) (for oil thermo hole)	1	1	1			4

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each	d.
X363/5	Oil base plug washer	1	1	1	doz.	6
MG420/1	Oil base dipstick	1	1	1		3 2
MG420/116	Oil base dipstick adaptor	1	1	1		4 2
MG348/261	Oil base dipstick adaptor joint	1	1	1	doz.	9
X363/22	Oil base dipstick adaptor stud ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{4}$ ")	2	2	2	doz.	1 0
X105/3	Oil base dipstick adaptor nut ($\frac{5}{16}$ " B.S.F.)	2	2	2	doz.	1 3
949	Oil base stud ($3\frac{3}{16}$ " long)	6	6	6		9
X348/1	" " ($\frac{1}{4}$ " B.S.F. $\times 3\frac{1}{2}$ " long)	8	8	8		4
X105/14	Oil base set screw ($\frac{1}{4}$ " B.S.F. $\times \frac{3}{8}$ ")	4	4	4		3
X101/1	Oil base set screw nut ($\frac{1}{4}$ " B.S.F.)	14	14	14	doz.	1 3
P279	Oil strainer assembly	1	1	1		10 0
P287/159	Oil strainer fibre washer	1	1	1	doz.	1 0
MG348/8	Front bearing and cylinder head feed pipe	1	1	1		4 4
P287/163	Front bearing and cylinder head feed pipe joint (cylinder head)	1	1	1		4
MG348/9	Main feed pipe (pump to cleaner)	1	1	1		2 2
MG420/9	Cylinder head oil drain pipe (front)	1	1	1		5 10
MG348/11	" " " " (rear)	1	1	1		4 7
MG348/12	Oil suction pipe	1	1	1		3 6
X348/57	Oil pump union washer	1	1	1		2
MG348/13	Main feed pipe	1	1	1		3 10
MG348/121	Cylinder head oil drain housing (front)	1	1	1		6 2
X348/49	Cylinder head oil drain pipe gasket (front bottom)	1	1	1		3
X348/50	" " " " " (top)	1	1	1		3
X348/51	" " " " " (top rear)	1	1	1		3
X348/52	" " " " " (bottom)	1	1	1		3
X110/6	Cylinder head oil drain flange stud ($\frac{1}{4}$ " B.S.F. $\times 1$ ") (front)	2	2	2		3
X110/39	Cylinder head oil feed set screw ($\frac{1}{4}$ " B.S.F. $\times 1\frac{1}{8}$ ")	1	1	1		3
P110/204	Cylinder head oil drain housing shim (.003")	As required				3
P110/205	" " " " " (.005")	As required				3
P110/206	" " " " " (.007")	As required				3
P110/207	" " " " " (.010")	As required				5
P110/208	" " " " " (.015")	As required				5
P110/209	" " " " " (.020")	As required				8
P287/144	Cylinder head oil feed choke	1	1	1		1 0
MG348/284	Oil gauge adaptor	1	1	1		4 0
P110/106	Oil gauge tap	1	1	1		2 3
X348/39	Oil gauge tap washer ($\frac{3}{8}$ ")	1	1	1		1
MG348/285	Oil gauge adaptor gasket	1	1	1		2
EXHAUST AND INLET MANIFOLD						
MG348/126	Exhaust manifold (front)	1	1	1	doz.	1 2 6
MG348/127	" " (rear)	1	1	1	doz.	1 2 6
MG348/256	Exhaust manifold gasket (front)	2	2	2		3
MG348/257	" " " (intermediate)	2	2	2		3
MG348/258	" " " (rear)	2	2	2		3
X420/4	Exhaust manifold stud ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{2}$ ")	8	8	8		2
X287/11	Exhaust manifold castle nut ($\frac{5}{16}$ " B.S.F.)	8	8	8		4
X110/37	Exhaust manifold washer ($\frac{5}{16}$ ")	8	8	8	doz.	8
MG420/10	Induction manifold (studded)	1	1	1	doz.	1 7 7
X110/6	Induction manifold stud ($\frac{1}{4}$ " B.S.F. $\times 1$ ")	4	4	4		3
X101/1	Induction manifold stud nut ($\frac{1}{4}$ " B.S.F.)	4	4	4	doz.	1 3
MG348/259	Induction manifold gasket	1	1	1		6 11
MG348/167	Induction manifold balance plug	1	1	1		7
X348/24	Induction manifold balance plug washer	1	1	1	doz.	9
X348/34	Induction manifold stud ($\frac{5}{16}$ " B.S.F. $\times 1\frac{5}{16}$ ")	5	5	5	doz.	1 0
X348/8	" " ($\frac{5}{16}$ " B.S.F. $\times 1\frac{1}{16}$ ")	2	2	2	doz.	1 0
X348/22	" " ($\frac{5}{16}$ " B.S.F. $\times 2\frac{3}{8}$ ")	2	2	2		2
X105/3	Induction manifold nut ($\frac{5}{16}$ " B.S.F.)	9	9	9	doz.	1 3
X105/4	Induction manifold washer ($\frac{5}{16}$ ")	9	9	9	doz.	8
CARBURETTORS						
A373	Carburettor (complete with coupling links)	1	1	1	pr.	12 0 0
MG420/114	Carburettor gasket	2	2	2	pr.	3
CLUTCH DETAILS						
MG412/5	Clutch plate (front)	1	1	1		11 10
MG412/6	" " (rear)	1	1	1		11 10
P239/125	Clutch fabric	4	4	4		4 8
P239/129	Clutch pressure plate	1	1	1		15 3

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
X412/2	Clutch pressure plate rivet	6	6	6	doz.		4
1575	Clutch centre driving plate	1	1	1		1	2 6
MG420/108	Clutch cover Comm. Eng. No. 653	1	1	1		1	14 11
MG348/200	" " " " " " Ceased Eng. No. 652	1	1	1		1	14 10
MG412/109	Clutch cover packing piece	1	1	1		1	6 2
X110/65	Clutch cover rivet ($\frac{3}{16}$ " dia. $\times$ $\frac{7}{16}$ ")	6	6	6	doz.		4
X110/65	Clutch centre driving plate rivet ($\frac{3}{16}$ " $\times$ $\frac{7}{16}$ ")	6	6	6	doz.		4
MG412/111	Clutch operating pin	3	3	3			3
P110/472	Clutch operating pin thrust button	3	3	3			4
MG348/202	Clutch operating disc	1	1	1		11	0
X412/4	Clutch operating disc spring pin	3	3	3			2
X412/5	Clutch operating disc washer	3	3	3	doz.	1	0
MG412/115	Clutch operating disc spring	6	6	6			2
MG412/112	Clutch operating disc lining	1	1	1			3 0
MG412/113	Clutch operating sleeve... ..	1	1	1			4 6
1034	Clutch operating shaft	1	1	1			10 10
S1/7	Clutch operating shaft greaser (straight type) ($\frac{1}{4}$ " B.S.F.)	1	1	1			3
MG412/105	Clutch operating pin bush	3	3	3		1	2
P110/338	Clutch thrust bearing (double purpose) (Type L.N.J.T.) ($1\frac{1}{2}$ ")	1	1	1		13	0
1584	Clutch thrust bearing cover	1	1	1		18	0
1585	Clutch thrust bearing cover washer	1	1	1			3
MG412/106	Clutch lever pin	3	3	3			6
MG420/109	Clutch finger Comm. Eng. No. 653	3	3	3		2	10
MG348/201	" " " " " " Ceased Eng. No. 652	3	3	3		2	10
1036	Clutch finger adjusting screw	3	3	3			2
X101/1	Clutch finger adjusting screw lock nut ($\frac{1}{4}$ " B.S.F.)	3	3	3	doz.	1	3
MG412/108	Clutch driving stud	6	6	6			6
MG412/107	Clutch spring	6	6	6			4
MG412/121	Clutch pedal	1	1	1		5	10
P110/422	Clutch pedal cotter (complete with nut and washer)	1	1	1			5
1144	Clutch pedal return spring	1	1	1			5
1248	Clutch pedal return spring anchor bracket	1	1	1			4
2569	Clutch pedal stop stud... ..	1	1	1			3
1287	Clutch pedal stop stud nut	1	1	1			8
2332	Clutch inspection cover... ..	1	1	1		1	4
MG412/102	Clutch spring locating dowel for flywheel	6	6	6		1	0

GEARBOX DETAILS

MG420/5	Gearbox unit complete with remote control	1	1	1	21	0	0
MG363/18	Gearbox casing (studded)	1	1	1		1	6 0
P110/109	Gearbox plug (filler and drain)	2	2	2			1 6
X110/67	Gearbox plug washer	2	2	2	doz.		10
MG363/164	Gearbox front cover	1	1	1		3	4
X363/27	Gearbox front cover bolt ($\frac{1}{4}$ " B.S.F. $\times$ $1\frac{3}{8}$ ")	4	4	4			3
X101/1	Gearbox front cover nut ($\frac{1}{4}$ " B.S.F.)... ..	4	4	4	doz.	1	3
X101/2	Gearbox front cover washer ($\frac{1}{4}$ ")	4	4	4	doz.		8
MG363/177	Gearbox rear cover	1	1	1		18	4
MG363/178	Gearbox rear cover plug	1	1	1			3
X363/19	Gearbox rear end stud ($\frac{5}{16}$ " B.S.F. $\times$ $2\frac{3}{4}$ ")	1	1	1			3
X363/20	" " " " ($\frac{5}{16}$ " B.S.F. $\times$ $1\frac{3}{8}$ ")	5	5	5			3
X363/21	" " " " ($\frac{5}{16}$ " B.S.F. $\times$ $1\frac{3}{8}$ ")	1	1	1			3
X105/3	Gearbox rear end stud nut ($\frac{5}{16}$ " B.S.F.)	7	7	7	doz.	1	3
X105/4	Gearbox rear end stud washer ($\frac{5}{16}$ ")	7	7	7	doz.		8
X363/12	Gearbox top stud ($\frac{1}{4}$ " B.S.F. $\times$ $1\frac{5}{16}$ ")	4	4	4			2
MG363/144	Constant mesh gear	1	1	1		14	8
MG363/145	3rd and top speed sliding gear	1	1	1		16	10
MG363/146	1st and 2nd speed sliding gear	1	1	1		18	4
MG363/147	3rd speed constant mesh gear... ..	1	1	1		19	6
MG363/151	Layshaft gear	1	1	1		1	8 2
MG363/24	Reverse gear (bushed)	1	1	1		13	2
MG363/154	Reverse gear bush	1	1	1			2 3
MG363/155	Reverse gear operating lever	1	1	1		5	8
MG363/156	Reverse lever pin	1	1	1			8
X101/10	Reverse lever pin nut ($\frac{3}{8}$ " B.S.F.)	1	1	1	doz.	1	3
X101/11	Reverse lever pin washer ($\frac{3}{8}$ ")... ..	1	1	1	doz.		8
MG363/157	Reverse gear operating fork	1	1	1			1 8
MG363/158	Reverse lever operating fork distance piece	1	1	1			3
MG363/159	Reverse fork rod	1	1	1			1 6
MG363/162	Reverse locking plunger	1	1	1			10
MG363/163	Reverse locking spring	1	1	1			11
MG363/160	Reverse locking plunger socket	1	1	1		2	0

Part No.	DESCRIPTION	No. Used			Price Each
		2-seater	4-seater	Saloon	
					£ s. d.
MG363/161	Reverse locking plunger socket plug...	1	1	1	3
X363/25	Reverse locking plunger socket nut ($\frac{3}{8}$ " dia. $\times$ 26 T.P.I.) ...	1	1	1	2
X363/26	Reverse locking plunger socket washer ($\frac{5}{8}$ ") ...	1	1	1	doz. 8
MG363/138	Roller bearing washer ...	4	4	4	1 3
MG363/148	Roller for gears ...	23	23	23	2
MG363/149	Washer for rollers ...	2	2	2	3
MG363/150	Spring ring for 3rd speed layshaft gear ...	1	1	1	doz. 1 4
MG363/152	Spring ring for constant mesh gear ...	2	2	2	doz. 1 8
MG363/142	Reverse shaft ...	1	1	1	3 5
MG363/141	Layshaft ...	1	1	1	5 0
MG412/118	1st motion shaft... ..	1	1	1	1 7 1
MG420/110	1st motion shaft oil feed choke ...	1	1	1	10
MG412/119	1st motion shaft oil feed choke plug ...	1	1	1	doz. 9
MG363/140	Mainshaft ...	1	1	1	13 4
X105/12	Mainshaft slotted nut ($\frac{1}{2}$ " B.S.F.) ...	1	1	1	3
X105/13	Mainshaft slotted nut washer ($\frac{1}{4}$ ") ...	1	1	1	3
MG363/179	Mainshaft bearing retaining plate ...	1	1	1	6
X112/1	Mainshaft bearing retaining plate bolt ($\frac{5}{16}$ " B.S.F. $\times$ 1 $\frac{1}{4}$ ") ...	2	2	2	3
X105/3	Mainshaft bearing retaining plate nut ($\frac{5}{16}$ " B.S.F.) ...	2	2	2	doz. 1 3
X105/7	Mainshaft bearing retaining plate set screw ($\frac{5}{16}$ " $\times$ $\frac{3}{4}$ ") ...	1	1	1	3
X105/4	Mainshaft bearing retaining plate washer ($\frac{5}{16}$ ") ...	3	3	3	doz. 8
X110/93	Dowel for rear cover ...	2	2	2	2
P110/362	Locking screw for layshaft ...	1	1	1	2
X101/2	Washer for layshaft ...	1	1	1	doz. 8
P110/389	Thrust button for speedometer gear... ..	1	1	1	1 0
P110/410	Speedometer driving gear (8/43 axle ratio) ...	1	1	1	4 2
P110/411	Speedometer driven gear (8/43 axle ratio) ...	1	1	1	4 10
P110/409	Speedometer driven gear bearing ...	1	1	1	8 9
X110/80	Speedometer driven gear bearing joint ...	1	1	1	4
P110/365	1st motion shaft oil thrower (2 $\frac{1}{16}$ " dia.) ...	1	1	1	4
P110/366	" " " " (2 $\frac{5}{16}$ " dia.) ...	1	1	1	4
X110/85	1st motion shaft ball bearing... ..	1	1	1	8 9
P110/367	1st motion shaft adjusting nut ...	1	1	1	5 2
X110/74	1st motion shaft adjusting nut locking wire ...	1	1	1	3
MG363/165	1st motion shaft retaining plate ...	1	1	1	5
X110/75	1st motion shaft bearing joint ...	1	1	1	6
MG363/166	1st and 2nd change speed rod ...	1	1	1	3 10
MG363/167	3rd and 4th change speed rod ...	1	1	1	3 9
MG363/168	1st and 2nd speed distance piece (rear) ...	1	1	1	3
MG363/169	" " " " (front) ...	1	1	1	4
MG363/170	1st and 2nd change speed fork ...	1	1	1	6 0
MG363/171	3rd and 4th change speed fork ...	1	1	1	6 0
X363/28	Spring for change speed fork ...	2	2	2	3
X110/84	Steel ball for change speed fork ...	2	2	2	doz. 1 6
MG363/8	Change speed lock plate assembly ...	1	1	1	3 0
MG363/180	Change speed bracket ...	1	1	1	1 19 2
X110/38	Change speed bracket plug ...	2	2	2	4
MG363/181	Change speed greaser (rear end) ...	1	1	1	4
P287/133	" " " " (front end) ...	1	1	1	5
MG363/182	Change speed bracket tray ...	1	1	1	1 6
MG363/183	Change speed gate ...	1	1	1	4 6
X105/14	Change speed gate bolt ($\frac{1}{4}$ " B.S.F. $\times$ $\frac{7}{8}$ ") ...	3	3	3	3
X101/2	Change speed gate washer ($\frac{1}{4}$ ") ...	3	3	3	doz. 8
MG363/198	Change speed gate shim ...	As required			doz. 1 2
X110/82	Change speed bracket tray and cover screw ...	5	5	5	doz. 7
MG363/193	Change speed lever ...	1	1	1	8 0
2747	Change speed lever spring ...	1	1	1	5
MG408/114	Change speed lever knob ...	1	1	1	2 0
X363/30	Change speed lever knob lock nut (C.P.) ...	1	1	1	2
MG363/23	Change speed shaft assembly ...	1	1	1	7 6
P110/404	Locking rivet for lever ball ...	1	1	1	doz. 2
X101/4	Key (Woodruff No. 3) ...	1	1	1	3
X363/31	Slotted nut ($\frac{1}{8}$ " B.S.F.) ...	1	1	1	3
X363/32	Washer ($\frac{1}{8}$ ") ...	1	1	1	doz. 4
X363/33	Peg ($\frac{3}{16}$ " dia. $\times$ $\frac{3}{4}$ " long) ...	2	2	2	doz. 7
MG363/189	Change speed operating lever ...	1	1	1	4 6
X363/34	Change speed operating lever set screw ($\frac{1}{4}$ " B.S.F. $\times$ 1") ...	1	1	1	3
X101/2	Change speed operating lever washer ($\frac{1}{4}$ ") ...	1	1	1	doz. 8
MG363/188	Selector lever ...	1	1	1	5 4
MG412/117	Clutch pit ...	1	1	1	1 16 8
X363/22	Clutch pit stud ($\frac{5}{16}$ " B.S.F. $\times$ 1 $\frac{1}{4}$ ") ...	6	6	6	doz. 1 0

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.	DESCRIPTION				2-seater	4-seater	Saloon	Price Each		
								£	s.	d.
X105/3	Clutch pit stud nut ($\frac{5}{16}$ " B.S.F.) ...	...	...	...	6	6	6	doz.	1	3
X105/4	Clutch pit stud washer ($\frac{5}{16}$ " B.S.F.) ...	...	...	...	6	6	6	doz.		8
P110/348	Clutch operating shaft bush O/S ...	...	...	...	1	1	1		3	5
P110/349	" " " " N/S ...	...	...	...	1	1	1		1	6
X110/70	Clutch operating shaft bush disc ...	...	...	...	1	1	1	doz.	1	8
X110/71	Clutch operating shaft bush locking screw ($\frac{1}{4}$ " B.S.F. $\times \frac{1}{2}$ ") ...	...	...	...	2	2	2			3
X101/2	Clutch operating shaft bush washer ($\frac{1}{2}$ ") ...	...	...	...	2	2	2	doz.		8
MG420/112	Engine rear bearer tube (through gearbox) ...	...	...	...	1	1	1		7	9
X363/23	Spigot bearing (Hyatt) ...	...	...	...	1	1	1		4	9
X110/86	Ball bearing ...	...	...	...	1	1	1		11	6
MG363/139	Universal joint flange (gearbox end) ...	...	...	...	1	1	1		9	4

BRAKE GEAR

P245	Brake push rod assembly ...	...	...	...	1	1	1		5	7
933	Brake push rod yoke clevis pin ...	...	...	...	2	2	2			6
MG376	Front brake cable assembly ...	...	...	...	2	2	2	1	0	8
P109/100	Front brake cable clevis pin ...	...	...	...	2	2	2			3
MG377	Rear brake cable assembly ...	...	...	...	2	2	2	18		6
P109/100	Rear brake cable clevis pin ...	...	...	...	2	2	2			3
269	Return spring (for foot brake pedal) ...	...	...	...	1	1	1			3
1071	Brake cross shaft fibre washer (Type 2) ...	...	...	...	2	2	2			4
1365	Roller for brake pedal ...	...	...	...	23	23	23	set	1	9
1007	Fulcrum pin for brake pedal ...	...	...	...	1	1	1			9
P239/140	Brake pedal ...	...	...	...	1	1	1		5	4
S2/20	Cable clip ...	...	...	...	2	2	2			3
1963	Rubber ferrule for brake cable ...	...	...	...	2	2	2			2
270	Foot brake pedal return spring bracket ...	...	...	...	1	1	1			7
P302	Brake cross shaft assembly ...	...	...	...	1	1	1	2	15	10
842	Brake cross shaft roller bearing retainer ...	...	...	...	1	1	1		2	6
841	Brake cross shaft roller ...	...	...	...	32	32	32	set	2	6
860	Foot brake adjusting rod ...	...	...	...	1	1	1			8
858	Foot brake adjusting rod clevis pin ...	...	...	...	1	1	1			4
840	Brake cross shaft steady bracket (free) ...	...	...	...	1	1	1		1	3
827	" " " " (fixed) ...	...	...	...	1	1	1		2	9
838	Brake cross shaft bush ...	...	...	...	1	1	1		1	6
846	Hand brake adjusting nut ...	...	...	...	2	2	2		2	9
857	Hand brake lever ratchet pawl ...	...	...	...	1	1	1		2	2
849	Hand brake lever knob ...	...	...	...	1	1	1		1	3
853	Hand brake lever knob screw ...	...	...	...	1	1	1			4
877	Hand brake ratchet ...	...	...	...	1	1	1		4	2
878	Hand brake lever stop ...	...	...	...	1	1	1		2	2
1051	Hand brake lever return spring ...	...	...	...	1	1	1			3
2933	Rubber buffer ...	...	...	...	1	1	1	doz.	1	8
854	Hand brake pawl rod ...	...	...	...	1	1	1			8
852	Hand brake pawl spring ...	...	...	...	1	1	1			4
856	Hand brake pawl screw ...	...	...	...	2	2	2			8
855	Hand brake pawl stud ...	...	...	...	1	1	1			4
845	Hand brake adjusting rod ...	...	...	...	1	1	1		3	11
851	Hand brake lever clevis pin ...	...	...	...	1	1	1			4
922	Brake cross shaft trunnion ...	...	...	...	2	2	2			8
2767	Brake cross shaft return spring ...	...	...	...	1	1	1	doz.	1	4
2764	Brake cross shaft return spring clip ...	...	...	...	1	1	1			5
270	Brake cross shaft anchor bracket ...	...	...	...	1	1	1			7

CONTROLS

MG432	Accelerator cross shaft assembly ...	...	...	...	1	1	1	14		7
1969	Jet control return spring ...	...	...	...	1	1	1			4
MG390	Coupling rod to throttle ...	...	...	...	1	1	1	1		4
265	Accelerator return spring ...	...	...	...	1	1	1			4
266	Accelerator return spring bracket ...	...	...	...	1	1	1			7
1113	Accelerator pedal stop ...	...	...	...	1	1	1			7
1108	Jet control rod ...	...	...	...	1	1	1			4
2541	Jet control connecting rod ...	...	...	...	1	1	1			3
1854	Slow-running control rod ...	...	...	...	1	1	1	1		6
1107	Slow-running control rod knob ...	...	...	...	2	2	2			8
132	Slow-running control rod spring ...	...	...	...	1	1	1			7
1112	Rubber bush for controls ...	...	...	...	2	2	2			3
1110	Slow-running rod bracket ...	...	...	...	1	1	1		1	0
2402	Control rod steady bracket ...	...	...	...	1	1	1		1	2
181	Control rod yoke end ...	...	...	...	1	1	1			6
1111	Anti-rattle springs ...	...	...	...	2	2	2	doz.	1	4

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.



DESCRIPTION



2-seater

4-seater

Saloon

Price Each

£ s. d.

STEERING GEAR

MG421	Steering gear assembly	1	1	1	6 15 0
P345/1	Assembly of follower and hemispheres	1	1	1	13 9
P345/2	Assembly of cage and balls for cup and cone bearings	1	1	1	3 0
MG453/1	Assembly of steering box and outer tube	1	1	1	1 12 6
MG453/2	Assembly of steering box and outer tube and cover-plate	1	1	1	2 6 7
MG453/3	Assembly of inner column and cam	1	1	1	1 16 0
P345/100	Key for steering wheel	1	1	1	10
P345/101	Follower	1	1	1	7 6
P345/103	Felt washer for drop arm	1	1	1	6
P345/104	Nut for rocker-shaft	1	1	1	6
P345/105	Hemisphere (L.H.)	4	4	4	set 6 4
P345/106	Bottom cap for box	1	1	1	3 6
P345/107	Bottom cap shims	As required			2
P345/108	Rocker shaft (L2 $\frac{13}{32}$ ")	1	1	1	19 0
P345/109	Felt bush for top column	1	1	1	10
P345/110	Ball race cup	2	2	2	2 7
P345/111	Ball race cone	2	2	2	2 0
P345/112	Cage for cup and cone bearing	2	2	2	1 5
P345/113	Cam (L.H.)	1	1	1	18 5
P345/114	Cover-plate (L1 $\frac{15}{32}$ ")	1	1	1	9 6
P345/115	Cover-plate shim	As required			6
P345/116	Dowel pin	2	2	2	2
P345/117	Steering box	1	1	1	14 4
MG421/100	Steering drop arm	1	1	1	10 8
MG453/101	Inner column	1	1	1	15 10
MG453/100	Outer tube	1	1	1	16 1
P345/120	Spring washer	2	2	2	doz. 6
MG345/121	Auto hex. nut ($\frac{5}{16}$ " B.S.F.)	5	5	5	2
MG345/122	Stud ($\frac{5}{16}$ " B.S.F. $\times$ 1" long, threaded $\frac{3}{8}$ " each end)	5	5	5	3
MG345/123	Flat washer ($\frac{3}{8}$ ")	1	1	1	doz. 1 9
MG345/124	Steel ball ($\frac{3}{32}$ " dia.)	30	30	30	doz. 1 7
MG345/125	Shake-proof external washer ($\frac{5}{16}$ " dia.)	3	3	3	doz. 1 2
1954	Steering box bracket dowel	2	2	2	2
1888	Steering column support bracket	1	1	1	2 1
1919	Steering column clamp	1	1	1	2 2
A310	Steering wheel (17")	1	1		2 2 0
A316	" " (16")			1	2 2 0
1952	Steering box bracket	1	1		3 0
1953	" " "			1	3 0

RADIATOR AND CONNECTIONS

MG414	Radiator complete	1	1	1	12 0 0
P214/109	Radiator stay rod lug	2	2	2	8
P282/100	Radiator drain tap	1	1	1	1 9
P214/103	Radiator drain tap fibre washer	1	1	1	2
A153/100	Radiator thermo union	1	1	1	1 0
P214/100	Radiator filler cap	1	1	1	12 0
1918	Radiator rest tape ($\frac{1}{8}$ " $\times$ $\frac{1}{2}$ " $\times$ 72")	1	1	1	2 0
P214/105	M.G. medallion	1	1	1	5 0
P214/101	Rubber ring for radiator filler cap	1	1	1	7
1066	Radiator mounting washer (fibre)	3	3	3	3
130	" " " (N.S.)	2	2	2	doz. 1 6
1068	Radiator stay rod eye bolt	2	2	2	4
1977	Radiator water hose connection (top)	1	1	1	1 11
1979	" " " (bottom)	1	1	1	1 6
2399	Radiator stay rod	2	2	2	1 2
1069	Radiator stay rod fork end	4	4	4	6
A332	Radiator water hose clip (1 $\frac{3}{8}$ " dia. top)	2	2	2	9
A110	Radiator water hose clip (bottom)	2	2	2	10
2626	Radiator rubber moulding	2	2	2	4
2594	Bracket, cylinder head to radiator	1	1	1	4 2

SILENCER AND EXHAUST PIPE

A300	Silencer (3 $\frac{1}{4}$ " dia. 30" long) (Burgess)	1	1	1	16 0
1868	Silencer clip	2	2	2	6
1865	Silencer clip bracket (front)	1	1	1	8
1904	" " " (rear)	1	1	1	9
831	Silencer extra clip	2	2	2	8
2397	Front exhaust pipe	1	1	1	16 3
1993	Front exhaust pipe gasket	2	2	2	6
1369	Exhaust pipe (rear tail pipe)	1	1		6 8
830	Exhaust tail pipe clip	1	1	1	1 10
2604	Exhaust pipe (rear tail pipe)			1	7 6

Please Quote Chassis and Engine Numbers when ordering Parts

PETROL TANK AND PIPES											
MG447	Petrol tank complete with cap and tap	...	...	1					3	9	0
2411	Petrol tank complete	...	...	...	...	1			2	1	0
2605	" "	...	...	...	...			1	2	2	0
1464	Petrol tank cap	...	...	...	...			1		4	2
1911	Petrol tap	...	...	...	...	1	1			6	8
MG476	Petrol tap with remote control Comm. Ch. No. LO496	...	...	...	...			1		16	0
1112	Rubber bush for petrol tap with remote control	...	...	...	...			2			3
2320	Petrol tap bracket	...	...	...	...			1			3
S3/2	Cone union adapter ($\frac{1}{4}$ " gas)	...	...	...	...	2	2	4			6
MG447/101	Main feed pipe union (tap to tank)	...	...	...	...	1			} pair	4	2
MG447/102	Reserve feed pipe union (tap to tank)	...	...	...	...	1					
1903	Petrol tank cap	...	...	...	...	1	1			12	4
2546	Petrol pipe with headed unions (56" long)	...	...	...	...	1	1			3	0
1200	Petrol tank tap ($\frac{1}{4}$ " gas) Ceased Ch. No. LO495	...	...	...	...			1		6	1
1196	Petrol pipe with headed unions ($27\frac{1}{2}$ " long)	...	...	...	...			1		2	3
1197	" " " " (30" long)	...	...	...	...			1		2	6
2865	" " " " (7" long)	...	...	...	...			1		1	0
A481	Petrol pipe connection with ferrules (rubber)	...	...	...	...	1	1			1	6
S2/9	Petrol pipe clips	...	...	...	...			2			4
2547	Petrol pipe (Petrolift to carburetter)	...	...	...	...	1	1	1		3	7
1859	Petrol pipe with headed unions ($35\frac{1}{2}$ " long)	...	...	...	...	2	2	2		2	3
1198	" " " " (52" long)	...	...	...	...			2		3	4
1415	Petrol pipe clip distance piece	...	...	...	...	1	1	2			2
S2/29	Petrol pipe and Tecalet clip	...	...	...	...	4	4	1			4
S2/30	Petrol pipe clip	...	...	...	...	1	1				4
S2/23	" " " " " " " "	...	...	...	...			1			7
S2/19	" " " " " " " "	...	...	...	...			3			4
S2/11	" " " " " " " "	...	...	...	...	2	2	2			3
S2/32	" " " " " " " "	...	...	...	...	3	2				4
S23/2	Petrol tank rubber packing ($1\frac{1}{4}$ " $\times$ $\frac{1}{2}$ " $\times$ 68")	...	...	...	...	1	1		per ft.	1	3
1904	Petrol tank rubber packing strip (17" long)	...	...	...	...		2				7
2450	Petrol tank strap	...	...	...	...		2		pair	3	6
1896	Petrol tank strap bracket	...	...	...	...		2			2	9
A444	Petrol pump (12-volt) Comm. { Ch. No. LO348 } 2-Str. Ch. No. LO2039	...	...	...	...	1	1	1		2	10
2701	Petrol pump support bracket	...	...	...	...	1	1	1		1	0
2770	Petrol pipe (petrol pump to carburettors)	...	...	...	...						
	Comm. { Ch. No. LO348 } 2-Str. Ch. No. LO2039	...	...	...	...	1	1	1		3	9
A242	S.U. Petrolift (12-volt)	...	...	...	...						
	Ceased { Ch. No. LO347 } 2-Str. Ch. No. LO2038	...	...	...	...	1	1	1		2	10

ACCESSORIES AND SUNDRIES

ACCESSORIES AND SPARE PARTS									
2955	Clip for tyre pump	...	...	...	...	2			5
A333	Wheels (3½" × 19") (side valves) (unpainted)...	...	...	...	...	5	5	5	2 2 0
1123	Hub caps O/S (R.W.)	...	...	...	...	2	2	2	9 7
1756	" " N/S (R.W.)	...	...	...	...	2	2	2	9 7
1870	Mixture control instruction plate	...	...	...	...	1	1	1	4
P371	Shock absorber (front and rear) less brackets and studs	...	...	...	...	1	1	1	7 19 0
						set	set	set	
178	Number-plate (front)	...	...	...	...	1	1	1	2 4
1124	" " (rear)	...	...	...	...	1	1	1	2 4
1227	Slow-running control instruction plate	...	...	...	...	1	1	1	4
1221	Instruction plate for grease nipples N/S	...	...	...	...	1	1	1	1 1
1220	" " " " O/S	...	...	...	...	1	1	1	1 1
2357	Spring clip for starting handle	...	...	...	...	3	3	3	doz. 2 3
1456	Rear number-plate bracket	...	...	...	...			2	1 0
1946	Sparking plug carrier	...	...	...	...	1	1	1	5 0
A289	Licence holder	...	...	...	...	1	1	1	6 0
2008	Starting handle	...	...	...	...	1	1	1	5 6
2319	Strap for lifting jack	...	...	...	...	1			1 6
1219	Instruction plate for foot brake adjustment	...	...	...	...	1			10
1914	" " " " " "	...	...	...	...		1	1	6

TECALEMIT GROUPED NIPPLE LUBRICATING SYSTEM

LUBRICATING SYSTEM											
P167/133	Pipe	($\frac{5}{32}$ " dia. $\times$ 1' 3" long)	...	...	...	...	1	1	1	1	6
P113/106	"	($\frac{5}{32}$ " dia. $\times$ 2' 6" long)	...	...	...	...	2	2	2	2	7
MG-431/100	"	($\frac{5}{32}$ " dia. $\times$ 3' 2" long)	...	...	...	...	2	2	2	2	6
P278/104	"	($\frac{5}{32}$ " dia. $\times$ 2' 11 $\frac{1}{2}$ " long)	...	...	...	...	2	2	2	2	9
MG-431/101	"	($\frac{5}{32}$ " dia. $\times$ 4' 11" long)	...	...	...	...	2	2	2	2	4
P278/103	"	($\frac{5}{32}$ " dia. $\times$ 2' 7" long)	...	...	...	...	2	2	2	2	7

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.	DESCRIPTION	2-seater	4-seater	Saloon	Price Each		
					£	s.	d.
P278/115	Pipe ($\frac{5}{32}$ " dia. $\times$ 5' 9" long)	2	2	2	4	4	
P278/1	Zerk battery plate fitting	4	4	4	1	6	
P278/2	Zerk battery plate fitting two-way	2	2	2	1	9	
P278/109	Adjusting feed plug one-way ($\frac{3}{16}$ " B.S.F.)	6	6	6	11		
P278/110	Adjusting feed plug two-way ($\frac{3}{16}$ " B.S.F.)	1	1	1	11		
P278/118	Adjusting feed plug three-way ($\frac{5}{16}$ " B.S.F.)	2	2	2	1	3	
P359/103	Open feed plug one-way	4	4	4	1	0	
P113/110	Fibre washer (thick)	13	13	13	doz.	1	0
P113/111	" " (thin)	38	38	38	doz.	6	
P113/109	Clip for one pipe	3	3	3	doz.	6	
P278/111	Clip for two pipes	4	4	4	doz.	1	6
P278/119	Support for three pipes	1	1	1		3	
MG369/106	Support for four pipes	2	2	2		2	
P278/113	2 B.A. $\times$ $\frac{3}{8}$ " bolt with nut	10	10	10	doz.	2	2
S1/5	T.Z.6 plug ($\frac{5}{16}$ " B.S.F.)	2	2	2		3	
S1/4	T.Z.65 plug ($\frac{5}{16}$ " B.S.F.)	10	10	10		5	
S1/7	P6/B plug ($\frac{1}{4}$ " B.S.F.)	1	1	1	1	0	
S1/6	T.Z./6 plug ($\frac{1}{8}$ " gas)	2	2	2		4	

DASHBOARD AND FUME EXCLUDERS

1121	Dashboard wall O/S	1	1	1	4	7	
1122	" " N/S	1	1	1	4	7	
2624	Dash panel	1			1	0	0
2400	" "		1		1	0	6
2614	" "			1	1	0	6
978	Fume excluder rubber (78" long)	1	1	1	length	3	8
1143	Rubber seal for clutch housing (30 $\frac{1}{2}$ ")	1	1	1	length	1	10
2401	Undertray	1	1	1		15	0
1869	Draught excluder block O/S	1	1	1		1	4
1962	" " " N/S	1	1	1		1	4
2003	Draught excluder for steering column (rubber)	1	1	1		3	7
2070	Draught excluder for steering column backing plate	1	1	1			7
2676	Toolbox support bracket		2	2		2	9

ELECTRICAL EQUIPMENT AND INSTRUMENTS

A366	Battery (12-volt) complete with lid and rods	1	1	1	5	1	6
A448	Dynamo ($4\frac{1}{8}$) not wired for half charge	1	1	1	7	12	6
A452	Starter, Lucas four-brush	1	1	1	6	2	0
P110/111	Starter packing piece	1	1	1		1	9
A247	Starter switch (foot-operated)	1	1	1		7	6
A473	Instrument panel	1	1	1	1	15	0
A413	Combined speedometer and revolution counter (head only)	Ceased { Ch. No. LO444 2-Str. Ch. No. L2056 }		1	1	1	6 13 0
A468	Combined speedometer and revolution counter (head only)	Comm. { Ch. No. LO445 2-Str. Ch. No. L2057 }		1	1	1	6 13 0
2639	Instrument mask for speedometer and revolution counter ($4\frac{3}{8}$ I./dia.)	Ceased { Ch. No. LO444 2-Str. Ch. No. L2056 }		1	1	1	5 6
2792	Instrument mask for speedometer and revolution counter ($4\frac{3}{8}$ I.D.)	Comm. { Ch. No. LO445 2-Str. Ch. No. L2057 }		1	1	1	5 6
2341	Instrument mask (small)	2	2	2		3	8
2727	Mask for switch	1	1	1		1	0
A339	Clock	1	1	1	1	15	0
A394	Oil thermo	1	1	1		1	5
A429	Oil pressure gauge (40 mm.—160 lb)	1	1	1		1	1
1192	Oil pressure gauge pipe line (6" 6")	1	1	1		3	6
335	Oil pressure gauge washer	2	2	2	doz.	1	0
A416	Petrol gauge (Archimedean)	1				1	5
A386	" " "		1			1	10
A412	" " (electric)			1		1	15
A357	Horn (chromium)	1	1	1		1	5
A306	Combined horn and dipper switch with cables	1	1			1	7
A400	Combined horn and dipper switch arm			1		1	17
2743	Rubber bush for horn leads	1	1	1			2
A301	Headlamp N/S (permanently dipped) (12-volt)	1	1	1	pair	4	17

pr. pr. pr.

Please Quote Chassis and Engine Numbers when ordering Parts

Price Each

A:307	Sidelamp with flat packings	...	...	...	...	1 pr.	1 pr.	1 pr.	1 pair	1	0
A405	Stop and tail-lamp less switch	...	...	...	...	1	1	1		16	6
2430	Rubber bush for stop-light cable	...	...	...	...		1				3
A431	Dashlamp	...	...	...	...	2	2	2		8	6
A382	Windscreen wiper motor	...	...	...	...	1	1	1		2	2
A401	Windscreen wiper blade assembly (dual)	...	...	...	...	1				14	10
A388	Windscreen wiper blade assembly	...	...	...	...		1	1		14	10
A390	Harnessed cables	...	...	...	...	1	1	1		2	10
A249	Cut-out and junction box	...	...	...	...	1	1	1		1	5
A391	Auxiliary junction box	...	...	...	...	1	1	1		3	0
A493	Stop-light switch	...	...	...	...		1	1		2	6
S2/2	Wiring clip	...	...	...	...	7	7	7			3
S2/3	" "	...	...	...	...	9	9	9			3
S2/4	" "	...	...	...	...	7	7	7			2
S2/5	" "	...	...	...	...	9	9	9			4
S2/6	" "	...	...	...	...	2	2	2			3
S2/12	" "	...	...	...	...	17	17	17			4
1393	Rubber bush for cables	...	...	...	...	1	1	1			4
1970	Cable carrier for drip channel	...	...	...	...	1				1	0
S2/21	Clip for stop-light control	...	...	...	...	1	1	1			4
A302	Ignition coil (12-volt)	...	...	...	...	1	1	1		1	0
A447	Dashlamp switch	...	...	...	...	1	1	1		3	6
2587	Wiring cover	...	...	...	...	1	1	1		1	8
A286	Driving mirror with bracket	...	...	...	...			1		5	0
A389	Driving mirror	...	...	...	...	1	1			13	6
2741	Petrol gauge washer	...	...	...	...	1	1				3
A459	Flexible cable for speedometer and counter	...	...	...	...	1	1			15	0
A460	Ditto	...	...	...	...			1		15	0
A461	Reduction box 100/143 ratio	...	...	...	...	1	1	1		1	1

BONNET, WINGS AND FAIRINGS

BONNET, WINGS AND FARRINGS											
2548	Front wing O/S (unpainted)	...	...	...	...	1	1	1	2	14	0
2549	" " N/S	...	...	...	...	1	1		2	14	0
2631	" " N/S	...	...	...	...			1	3	10	0
3006	Front wing support stay	...	...	...	...	2	2	2	9	0	0
2992	Top bracket for front wing support stay	...	...	...	...	2	2	2	1	0	0
S17/3	Silentbloc ...	...	...	...	...	2	2	2	3	8	8
2564	Headlamp bracket O/S	...	...	...	...	1	1	1	5	8	0
2565	" " N/S	...	...	...	...	1	1	1	5	8	0
2585	Rubber packing (interior)	...	...	...	...	2	2	2	4	6	4
2586	" " (exterior)	...	...	...	...	2	2	2	4	6	4
2577	Headlamp bracket bolt...	...	...	...	...	2	2	2	1	0	0
2562	Sidelamp bracket bolt ...	...	...	...	...	4	4	4	4	0	0
2563	Sidelamp rubber packing (interior)	...	...	...	...	2	2	2	3	0	0
2669	Rear wing O/S (unpainted)	...	...	...	...	1			1	11	6
2412	" " O/S	...	...	...	...		1		1	14	10
2617	" " O/S	...	...	...	...			1	1	15	10
2670	" " N/S	...	...	...	...	1			1	11	6
2413	" " N/S	...	...	...	...		1		1	14	10
2618	" " N/S	...	...	...	...			1	1	15	10
2625	Bonnet (unpainted)	...	...	...	...	1			4	0	0
2627	" "	...	...	...	...			1	3	1	9
2573	" "	...	...	...	...		1		3	1	9
A311	Bonnet fastener (C.P.)	...	...	...	...	4	4		3	4	0
A262	" "	...	...	...	...			4	4	2	0
2062	Bonnet hinge rod bracket	...	...	...	...	1	1	1	2	0	0
259	Bonnet rod lug ...	...	...	...	...	1	1	1	8	0	0
2321	Bonnet rest bracket	...	...	...	...	2	2	2	6	0	0
2592	Front fairing (unpainted)	...	...	...	...	1	1	1	13	10	0
P214/105	M.G. medallion ...	...	...	...	...	1	1	1	5	0	0
S23/1	Rubber insertion (18" x 1" x 1/8")	...	...	...	...	2	2	2	6	0	0
361	Dome nut (1/4" B.S.F.) (C.P.)	...	...	...	...	4	4	4	6	0	0
380	Plain washer (1/4") (C.P.)	...	...	...	...	4	4	4	4	0	0
2667	Running-board O/S	...	...	...	...	1			12	0	0
2574	" O/S	...	...	...	...		1		11	7	0
2632	" O/S	...	...	...	...			1	10	2	0
2668	" N/S	...	...	...	...	1			12	0	0
2575	" N/S	...	...	...	...		1		11	7	0
2633	" N/S	...	...	...	...			1	1	10	2
2590	Running-board step channelling (25" long)	...	...	...	...	4	4	2	3	3	0
2591	Running-board step channelling rubber (25" long)	...	...	...	...	4	4	2	1	8	0
380	Plain washer (1/4") (C.P.)	...	...	...	...	4	4	4	doz.	4	0

Please Quote Chassis and Engine Numbers in all Correspondence

Part No.	DESCRIPTION	No. Used			Price Each		
		2-seater	4-seater	Saloon	£	s.	d.
1931	Rain channel	1			1	2	
1633	" "		1		1	6	
2634	" "			1	1	0	
1932	Rain channel support bracket	1	1	1		2	
3071	Front wing rubber packing O/S	1	1	1	1	2	
3072	" " " " " N/S	1	1	1	1	2	
2807	Rear wing stay tie bar O/S	1			6	11	
2808	" " " " " N/S	1			6	11	
1945	Special bolt (C.P. head)	2				10	
318	Rubber packing	2				5	
419	Rubber bush			1		3	
2590	Step channelling (10" long)	2	2		1	4	
2591	Step channelling rubber (10" long)	2	2			8	
2590	Step channelling (15" long)			2	2	0	
2591	Step channelling rubber (15" long)			2	1	0	
S23/1	Front fairing rubber insertion (30" x 1" x $\frac{1}{8}$ ")	1	1	1		9	
1904	Rubber packing (26" long)	2				10	
2641	Spare wheel cover		1		14	0	
MG456	Spare wheel trough support assembly			1	5	6	
P309	Spare wheel centre assembly	1			7	0	
1972	Rubber buffer for spare wheel centre assembly	1			1	4	
361	Dome nut ($\frac{1}{4}$ " B.S.F.) (C.P.)	1				6	

PROPELLER SHAFT SHROUD AND FOOT WELL

2593	Propeller shaft shroud	1			1	2	6
2505	" " " " "		1	1	1	2	6
1223	Propeller shaft shroud bottom plate	1	1	1	3	11	
1438	Propeller shaft shroud platform	2	2	2	1	4	
361	Propeller shaft shroud platform dome nut ($\frac{1}{4}$ " B.S.F.)	4	4	4		6	
979	Propeller shaft shroud platform support bracket	1	1	1	2	7	
1001	Propeller shaft shroud platform "U" clips	1	1	1		4	
1211	Propeller shaft shroud platform support bracket (long)	1	1	1	3	0	
1212	Propeller shaft shroud platform "U" clip (long)	1	1	1		6	
1174	Foot well		1	1	9	10	
1436	Foot well front end angle plate		2	2		4	
1437	Foot well rear end angle plate		2	2		4	

SPARE WHEEL CARRIER ASSEMBLY

MG448	Spare wheel carrier (chromium plated and cellulosed)	1			3	0	6
1968	Spare wheel carrier thumb nut	1					
P214/105	M.G. medallion	1				5	0
1915	Spare wheel carrier bracket (top support)	1				5	4
1896	Spare wheel carrier bracket (bottom bracket on cross tube)	2				2	9
2511	Spare wheel carrier support bracket		1			3	7
2512	Spare wheel carrier (less lock nut, sleeve and hub)		1			16	8
MG457	Spare wheel top support assembly			1	1	5	10
1193	Spare wheel hub		1		1	7	0
1194	Spare wheel lock nut and sleeve		1				

TOOL ROLL

P330/100	Tool roll	1	1	1	4	0	
P330/101	Screwdriver (10")	1	1	1	1	6	
P330/103	Adjustable spanner	1	1	1	2	8	
P330/104	Pliers (6" pair)	1	1	1	1	0	
2867	Tappet spanner with .006" feeler gauge	1	1	1	1	0	
P330/113	Spanner ($\frac{1}{4}$ " and $\frac{3}{16}$ " D.E.)	1	1	1		6	
P330/114	Spanner ($\frac{3}{8}$ " and $\frac{1}{2}$ " D.E.)	1	1	1		10	
P330/115	Spanner ($\frac{1}{2}$ " and $\frac{9}{16}$ " D.E.)	1	1	1	1	3	
1733	Contact breaker spanner	1	1	1		6	
1734	Grease gun	1	1	1	10	6	
1735	Tyre pump	1	1	1	7	0	
P330/117	Hammer for Rudge hub	1	1	1	6	6	
A288	Grease gun for propeller shaft	1	1	1	6	0	
2368	Cylinder head spanner	1	1	1	2	6	
2372	Plug spanner	1	1	1	2	9	
1959	Spanner ($\frac{1}{8}$ " Whit. S.E.)	1	1	1		10	
1736	Jack with handle (Shelley double-lift type)	1	1	1	1	1	0

Please Quote Chassis and Engine Numbers when ordering Parts

Part No.		DESCRIPTION		No. Used			Price Each		
				2-seater	4-seater	Saloon	£	s.	d.
2742		Sump drain plug spanner		1	1	1	1	3	
2801		Box spanner ($\frac{1}{4}$ " Whit.)		1	1	1		11	
2802		" " ($\frac{7}{16}$ " Whit.)		1	1	1	1	3	
2860		Tommy bar for Part Nos. 2801 to 2802		1	1	1		2	

BODY SUNDRIES

1929	Body bracket (rear)	2			1	2
1408	Body mounting plate (rear)		4	4		7
2315	Body bracket for rear cross tube		2		3	4
2680	Body to dash tie bar		2	2	7	0
1930	Body bracket rear backing plate	2				6
1897	Body to dash tie bar	2			5	4
1630	Well board plate		2	2		4
978	Rubber draught excluder (10 $\frac{1}{4}$ " long)	2		2		8
2735	Retaining plate for bonnet rest	2		2		3
2740	Instruction plate (facia mounting)	1	1	1		3
815	Rubber buffer for rear wing	2				2
2707	Leather cover for speedometer reduction gearbox	1	1	1	5	4
2745	Bracket for screen window chain			1		10
2324	Seat to floorboard fixing plate			2	1	6
2540	Packing for seat adjuster			2	1	0

Please Quote Chassis and Engine Numbers when ordering Parts

BODY DETAILS FOR SALOON

Part No.	DESCRIPTION	No. Used	Price Each
			£ s. d.
B230/100	Bonnet rest O/S	1	17 0
B230/101	" " N/S	1	17 0
B230/154	Bonnet board O/S	1	15 0
B230/155	" " N/S	1	15 0
B237/122	" " O/S	1	15 0
B237/123	" " N/S	1	15 0
B230/102	Toolbox	1	1 5 0
WINDSCREEN			
B230/1	Windscreen complete with glass	1	15 0 0
B230/131	Windscreen rubber surround	3 lengths	7 6
B230/152	Windscreen glass (Triplex)	1	2 9 4
B230/2	Windscreen winder complete	1	3 4 0
FACIA BOARD			
B230/103	Facia board (walnut)	—	2 10 0
DOOR HANDLES, LOCKS AND GLASSES			
B230/104	Door glass (sliding) O/S and N/S (Triplex)	2	1 5 2
B230/105	" " (fixed) O/S and N/S (Triplex)	2	1 5 2
B230/107	Door handle complete with lock and key N/S (outside)	1	15 0
B230/108	Door handle O/S (outside)	1	6 0
B230/109	" " O/S and N/S (inside)	2	15 0
B230/110	Door check strap	2	6 0
B230/111	Door hinge (top) N/S	1	2 6
B230/112	" " (top) O/S	1	2 6
B230/113	" " (centre) N/S	1	2 6
B230/114	" " (centre) O/S	1	2 6
B230/115	" " (bottom) N/S	1	2 6
B230/116	" " (bottom) O/S	1	2 6
B230/117	Door rubber buffer	2	4 0
B230/118	Luggage carrier lid lock	1	4 0
B230/119	Luggage carrier handle	1	2 0
B230/120	Rear quarter panel glass N/S and O/S (Triplex)	2	1 6 7
B230/121	Rear light glass	1	1 5 7
B230/122	Sliding roof centre pull handle	1	4 0
B230/123	Sliding roof adjusting clamp and bracket	2	6 0
SEATS AND FIXINGS			
B230/124	Front seat O/S (less fixings)	1	1 10 6
B230/125	" " N/S (less fixings)	1	1 10 0
B230/126	Front seat adjusting spring lever (chromium plated)	2	5 0
B230/127	Front seat cushion O/S (complete)	1	3 15 0
B230/128	" " N/S (complete)	1	3 15 0
B230/129	Rear seat cushion (complete)	1	4 10 0
B230/130	Rear seat cushion case	1	3 0 0
B230/140	Rear seat cushion air bag	1	1 10 0
FLOORBOARDS AND FOOT REST			
B230/141	Floorboard O/S	1	1 10 0
B230/142	" " N/S	1	1 10 0
B230/143	Passenger's foot rest	1	7 0
CARPETS			
B230/144	Front carpet (less mats)	1	1 10 0
B230/146	Centre carpet	1	1 15 0
B230/147	Rear heel well carpet	1	1 15 0
MISCELLANEOUS (ELECTRICAL)			
A575	Roof lamp	1	10 0
A576	Roof lamp switch	1	1 6
A457	Ashtray O/S and N/S	2	1 6

BODY DETAILS FOR TOURER

Part No.		DESCRIPTION		No. Used	Price Each
					£ s. d.
B235/100	Bonnet rest	O/S		1	7 0
B235/101	" "	N/S		1	7 0
B235/154	Bonnet-board	O/S		1	1 0 0
B235/155	" "	N/S		1	1 0 0
B235/102	Toolbox			—	16 0
WINDSCREEN					
B235/103	Windscreen glass			1	1 13 3
B235/2	Windscreen (less glass) complete			1	6 10 0
B235/104	Windscreen (body) side support	O/S		1	1 10 0
B235/105	" "	N/S		1	1 10 0
B235/106	Windscreen adjusting thumb screw			2	9 0
B235/107	Windscreen adjusting thumb screw ratchet			2	6 0
B235/108	Windscreen rubber draught excluder			1	5 0
FACIA BOARD					
B235/109	Facia board (aluminium)			1	1 5 0
DOOR LOCKS, HANDLES AND HINGES					
B235/110	Door handle	O/S		1	5 0
B235/111	" "	N/S		1	5 0
B235/112	Door lock	O/S (silent travel) (not supplied separately)		1	19 0
B235/113	Door lock	N/S (silent travel) and key (not supplied separately)		1	19 0
B235/114	Door hinge	O/S		2	2 0
B235/115	" "	N/S		2	2 0
B235/116	Door rubber buffers			2	1 4
HOOD AND SIDESCREENS					
B235/117	Hood complete with frame			1	7 4 0
B235/118	Hood frame			1	3 8 0
B235/119	Hood canopy			1	3 16 0
B235/120	Hood bag			1	1 18 0
B235/121	Hood strap			2	1 6
B235/122	Hood to screen attachment complete with chromium-plated wing screws			1	5 6
B235/123	Rigid sidescreen	O/S		1	2 15 0
B235/124	" "	N/S		1	2 15 0
B235/125	Rear side-curtain	O/S		1	1 4 0
B235/126	" "	N/S		1	1 4 0
B235/127	Side-curtain thumb screw tightener (on door)			2	7 0
SEATS AND FIXINGS					
B235/128	Bucket seat	O/S (only)		1	3 0 0
B235/129	" "	N/S (only)		1	3 0 0
B235/130	Bucket seat air bag			2	15 0
B235/131	Bucket seat cushion less air bag	O/S		1	2 4 0
B235/132	" "	N/S		1	2 4 0
B235/133	Rear seat cushion less air bag			1	2 10 0
B235/134	Rear seat air bag			2	10 0
B235/135	Rear seat squab			1	5 0 0
FLOORBOARDS					
B235/136	Floorboard	O/S		1	10 0
B235/137	" "	N/S		1	10 0
B220/155	Passenger's foot rest complete with rubber mats			1	9 0
CARPETS					
B235/130	Large centre carpet			1	1 11 0
B235/140	Gearbox carpet complete with rubber mats			1	2 15 0
B235/141	Heel board carpet			1	17 0
B235/142	Foot well carpet			1	17 0
B235/143	Rubber mat for gearbox carpet			1	4 0

Please Quote Chassis and Engine Numbers when ordering Parts